

## **OsmoNITB VTY Reference**

Copyright © 2012-2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

---

**COLLABORATORS**

	<i>TITLE :</i> OsmoNITB VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		March 21, 2023	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	13th August 2012	Initial	hf
v2	5th March 2014	Update to match osmo-bsc version 0.13.0-305	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list	2
1.1.5	show running-config	3
1.1.6	write	3
1.1.7	write file	3
1.1.8	write memory	3
1.1.9	write terminal	4
1.2	view	4
1.2.1	enable	4
1.2.2	logging color (01)	4
1.2.3	logging disable	5
1.2.4	logging enable	5
1.2.5	logging filter all (01)	5
1.2.6	logging filter imsi IMSI	6
1.2.7	logging level (rllcclmmllrrlrsllnmlmncclpaglmeaslscclpmsclmgcplholdblreflgprslns...	6
1.2.8	logging level force-all (debug info notice error fatal)	9
1.2.9	logging level set-all (debug info notice error fatal)	10
1.2.10	logging print category (01)	10
1.2.11	logging print category-hex (01)	11
1.2.12	logging print extended-timestamp (01)	11
1.2.13	logging print file (01 basename) [last]	12
1.2.14	logging print level (01)	12
1.2.15	logging set-log-mask MASK	13
1.2.16	logging timestamp (01)	13
1.2.17	no logging level force-all	13
1.2.18	show alarms	14

1.2.19	show asciidoc counters	14
1.2.20	show bts [<0-255>]	14
1.2.21	show e1_driver	15
1.2.22	show e1_line [line_nr] [stats]	15
1.2.23	show e1_timeslot [line_nr] [ts_nr]	15
1.2.24	show fsm NAME	16
1.2.25	show fsm all	16
1.2.26	show fsm-instances NAME	16
1.2.27	show fsm-instances all	17
1.2.28	show history	17
1.2.29	show lchan [<0-255>] [<0-255>] [<0-7>] [lchan_nr]	17
1.2.30	show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan_nr]	18
1.2.31	show logging vty	18
1.2.32	show network	19
1.2.33	show online-help	19
1.2.34	show paging [<0-255>]	19
1.2.35	show paging-group <0-255> IMSI	20
1.2.36	show rate-counters	20
1.2.37	show smpp esme	20
1.2.38	show sms-queue	21
1.2.39	show statistics	21
1.2.40	show stats	21
1.2.41	show stats level (globalpeerlsubscriber)	22
1.2.42	show subscriber (extensionlimsiltmsilid) ID	22
1.2.43	show subscriber cache	23
1.2.44	show timeslot [<0-255>] [<0-255>] [<0-7>]	23
1.2.45	show trx [<0-255>] [<0-255>]	23
1.2.46	show version	24
1.2.47	sms send pending	24
1.2.48	subscriber (extensionlimsiltmsilid) ID ms-test close-loop (alblcldlfli)	24
1.2.49	subscriber (extensionlimsiltmsilid) ID ms-test open-loop	25
1.2.50	subscriber (extensionlimsiltmsilid) ID silent-call start (anyltch/fltch/anylsdcc...	26
1.2.51	subscriber (extensionlimsiltmsilid) ID silent-call stop	27
1.2.52	subscriber (extensionlimsiltmsilid) ID silent-sms sender (extensionlimsiltmsilid...	27
1.2.53	subscriber (extensionlimsiltmsilid) ID sms sender (extensionlimsiltmsilid) SENDE...	28
1.2.54	subscriber (extensionlimsiltmsilid) ID update	29
1.2.55	subscriber (extensionlimsiltmsilid) ID ussd-notify (0112) .TEXT	30
1.2.56	subscriber create imsi ID	31
1.2.57	terminal length <0-512>	31

1.2.58	terminal no length	31
1.2.59	who	32
1.3	enable	32
1.3.1	bts <0-255> om2000 class (trxcrlstlftflislcndplcfltxlrx) <0-255> <0-255> <0-255>	32
1.3.2	bts <0-255> om2000 class <0-255> <0-255> <0-255> <0-255>	33
1.3.3	bts <0-255> oml class (site-managerlbtslradio-carrierlbaseband-transceiverlchann...	34
1.3.4	bts <0-255> oml class <0-255> instance <0-255> <0-255> <0-255>	35
1.3.5	bts <0-255> resend-system-information	36
1.3.6	bts <0-255> smscb-command <1-4> HEXSTRING	36
1.3.7	bts <0-255> trx <0-255> timeslot <0-7> pdch (activate deactivate)	37
1.3.8	bts <0-255> trx <0-255> timeslot <0-7> sub-slot <0-7> (activate deactivate) (hrl...	37
1.3.9	bts <0-255> trx <0-255> timeslot <0-7> sub-slot <0-7> mdcx A.B.C.D <0-65535>	38
1.3.10	configure terminal	39
1.3.11	copy running-config startup-config	39
1.3.12	ctrl-interface generate-trap TRAP VALUE	40
1.3.13	disable	40
1.3.14	drop bts connection <0-65535> (omlrlsl)	40
1.3.15	logging color (0 1)	41
1.3.16	logging disable	41
1.3.17	logging enable	41
1.3.18	logging filter all (0 1)	42
1.3.19	logging filter imsi IMSI	42
1.3.20	logging level (rllclmlmlrrlrslnmlmncclpaglmeaslscplmsclmgcplholdblreflgrslns...	43
1.3.21	logging level force-all (debug info notice error fatal)	46
1.3.22	logging level set-all (debug info notice error fatal)	46
1.3.23	logging print category (0 1)	47
1.3.24	logging print category-hex (0 1)	47
1.3.25	logging print extended-timestamp (0 1)	48
1.3.26	logging print file (0 1 basename) [last]	48
1.3.27	logging print level (0 1)	49
1.3.28	logging set-log-mask MASK	49
1.3.29	logging timestamp (0 1)	49
1.3.30	meas-feed scenario NAME	50
1.3.31	no logging level force-all	50
1.3.32	restart-bts <0-65535>	51
1.3.33	show alarms	51
1.3.34	show asciidoc counters	51
1.3.35	show bts [<0-255>]	52
1.3.36	show e1_driver	52

1.3.37	show e1_line [line_nr] [stats]	52
1.3.38	show e1_timeslot [line_nr] [ts_nr]	53
1.3.39	show fsm NAME	53
1.3.40	show fsm all	53
1.3.41	show fsm-instances NAME	54
1.3.42	show fsm-instances all	54
1.3.43	show history	54
1.3.44	show lchan [<0-255>] [<0-255>] [<0-7>] [lchan_nr]	55
1.3.45	show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan_nr]	55
1.3.46	show logging vty	56
1.3.47	show network	56
1.3.48	show online-help	56
1.3.49	show paging [<0-255>]	57
1.3.50	show paging-group <0-255> IMSI	57
1.3.51	show rate-counters	57
1.3.52	show smpp esme	58
1.3.53	show sms-queue	58
1.3.54	show startup-config	58
1.3.55	show statistics	59
1.3.56	show stats	59
1.3.57	show stats level (globalpeer subscriber)	59
1.3.58	show subscriber (extension ims tms id) ID	60
1.3.59	show subscriber cache	60
1.3.60	show timeslot [<0-255>] [<0-255>] [<0-7>]	61
1.3.61	show trx [<0-255>] [<0-255>]	61
1.3.62	show version	61
1.3.63	sms send pending	62
1.3.64	sms-queue clear	62
1.3.65	sms-queue max-failure <1-500>	62
1.3.66	sms-queue max-pending <1-500>	63
1.3.67	sms-queue trigger	63
1.3.68	subscriber (extension ims tms id) ID a3a8 (non xor comp128v1 comp128v2 comp12...	63
1.3.69	subscriber (extension ims tms id) ID authorized (0 1)	64
1.3.70	subscriber (extension ims tms id) ID delete	65
1.3.71	subscriber (extension ims tms id) ID expire	65
1.3.72	subscriber (extension ims tms id) ID extension EXTENSION	66
1.3.73	subscriber (extension ims tms id) ID handover BTS_NR	66
1.3.74	subscriber (extension ims tms id) ID ms-test close-loop (ab cl d l f l)	67
1.3.75	subscriber (extension ims tms id) ID ms-test open-loop	68

1.3.76	subscriber (extensionlimsiltmsilid) ID name .NAME	69
1.3.77	subscriber (extensionlimsiltmsilid) ID silent-call start (anytch/fltch/anylsdcc...	69
1.3.78	subscriber (extensionlimsiltmsilid) ID silent-call stop	70
1.3.79	subscriber (extensionlimsiltmsilid) ID silent-sms sender (extensionlimsiltmsilid...	71
1.3.80	subscriber (extensionlimsiltmsilid) ID sms pending-send	72
1.3.81	subscriber (extensionlimsiltmsilid) ID sms sender (extensionlimsiltmsilid) SENDE...	72
1.3.82	subscriber (extensionlimsiltmsilid) ID update	73
1.3.83	subscriber (extensionlimsiltmsilid) ID ussd-notify (0112) .TEXT	74
1.3.84	subscriber create imsi ID	75
1.3.85	subscriber purge-inactive	75
1.3.86	terminal length <0-512>	75
1.3.87	terminal monitor	76
1.3.88	terminal no length	76
1.3.89	terminal no monitor	76
1.3.90	who	77
1.4	config	77
1.4.1	banner motd default	77
1.4.2	banner motd file [FILE]	77
1.4.3	ctrl	78
1.4.4	e1_input	78
1.4.5	enable password (8l) WORD	78
1.4.6	enable password LINE	79
1.4.7	hostname WORD	79
1.4.8	line vty	79
1.4.9	log alarms <2-32700>	80
1.4.10	log file .FILENAME	80
1.4.11	log gsmmap [HOSTNAME]	80
1.4.12	log stderr	81
1.4.13	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	81
1.4.14	log syslog local <0-7>	82
1.4.15	mnc-int	82
1.4.16	network	82
1.4.17	nitb	82
1.4.18	no banner motd	83
1.4.19	no enable password	83
1.4.20	no hostname [HOSTNAME]	83
1.4.21	no log alarms	84
1.4.22	no log file .FILENAME	84
1.4.23	no log stderr	84



1.4.24	no log syslog . . . . .	85
1.4.25	no service advanced-vty . . . . .	85
1.4.26	no service terminal-length [<0-512>] . . . . .	85
1.4.27	no stats reporter log . . . . .	86
1.4.28	no stats reporter statsd . . . . .	86
1.4.29	password (8l) WORD . . . . .	86
1.4.30	password LINE . . . . .	87
1.4.31	service advanced-vty . . . . .	87
1.4.32	service terminal-length <0-512> . . . . .	87
1.4.33	show history . . . . .	88
1.4.34	smpp . . . . .	88
1.4.35	stats interval <1-65535> . . . . .	88
1.4.36	stats reporter log . . . . .	89
1.4.37	stats reporter statsd . . . . .	89
1.5	config-log . . . . .	89
1.5.1	logging color (0l1) . . . . .	89
1.5.2	logging filter all (0l1) . . . . .	90
1.5.3	logging filter imsi IMSI . . . . .	90
1.5.4	logging level (rllcclmmlrrlrslnmlmncclpaglmeaslscclpmsclmgcplholdblreflgprslns... . . . .	91
1.5.5	logging level force-all (debuglinfofnoticeerrorlfatal) . . . . .	94
1.5.6	logging level set-all (debuglinfofnoticeerrorlfatal) . . . . .	94
1.5.7	logging print category (0l1) . . . . .	95
1.5.8	logging print category-hex (0l1) . . . . .	95
1.5.9	logging print extended-timestamp (0l1) . . . . .	96
1.5.10	logging print file (0l1 basename) [last] . . . . .	96
1.5.11	logging print level (0l1) . . . . .	97
1.5.12	logging timestamp (0l1) . . . . .	97
1.5.13	no logging level force-all . . . . .	98
1.6	config-stats . . . . .	98
1.6.1	disable . . . . .	98
1.6.2	enable . . . . .	98
1.6.3	level (globalpeerlsubscriber) . . . . .	99
1.6.4	local-ip ADDR . . . . .	99
1.6.5	mtu <100-65535> . . . . .	99
1.6.6	no local-ip . . . . .	100
1.6.7	no mtu . . . . .	100
1.6.8	no prefix . . . . .	100
1.6.9	prefix PREFIX . . . . .	100
1.6.10	remote-ip ADDR . . . . .	101

1.6.11	remote-port <1-65535>	101
1.7	config-line	101
1.7.1	bind A.B.C.D [<0-65535>]	101
1.7.2	login	102
1.7.3	no login	102
1.8	config-e1_input	102
1.8.1	e1_line <0-255> driver (misdnmisdn_lapldahdilipalunixsocket)	102
1.8.2	e1_line <0-255> keepalive	103
1.8.3	e1_line <0-255> keepalive <1-300> <1-20> <1-300>	103
1.8.4	e1_line <0-255> name .LINE	104
1.8.5	e1_line <0-255> port <0-255>	104
1.8.6	e1_line <0-255> socket .SOCKET	104
1.8.7	ipa bind A.B.C.D	105
1.8.8	no e1_line <0-255> keepalive	105
1.9	config-ctrl	106
1.9.1	bind A.B.C.D	106
1.10	config-net	106
1.10.1	auth policy (closedlaccept-allregexptoken)	106
1.10.2	authorized-regexp REGEXP	107
1.10.3	bts <0-255>	107
1.10.4	dyn_ts_allow_tch_f (0 1)	107
1.10.5	encryption a5 (0 1 2 3)	108
1.10.6	handover (0 1)	108
1.10.7	handover maximum distance <0-9999>	108
1.10.8	handover power budget hysteresis <0-999>	109
1.10.9	handover power budget interval <1-99>	109
1.10.10	handover window rxlev averaging <1-10>	110
1.10.11	handover window rxlev neighbor averaging <1-10>	110
1.10.12	handover window rxqual averaging <1-10>	111
1.10.13	location updating reject cause <2-111>	111
1.10.14	long name NAME	112
1.10.15	mm info (0 1)	112
1.10.16	mobile network code <0-999>	112
1.10.17	neci (0 1)	113
1.10.18	network country code <1-999>	113
1.10.19	no timezone	113
1.10.20	paging any use tch (0 1)	114
1.10.21	rrlp mode (nonelms-basedlms-preferredlass-preferred)	114
1.10.22	short name NAME	115

1.10.23 subscriber-keep-in-ram (011)	115
1.10.24 timer t3101 (default<1-65535>)	115
1.10.25 timer t3103 (default<1-65535>)	116
1.10.26 timer t3105 (default<1-65535>)	116
1.10.27 timer t3107 (default<1-65535>)	116
1.10.28 timer t3109 (default<1-65535>)	117
1.10.29 timer t3111 (default<1-65535>)	117
1.10.30 timer t3113 (default<1-65535>)	118
1.10.31 timer t3115 (default<1-65535>)	118
1.10.32 timer t3117 (default<1-65535>)	118
1.10.33 timer t3119 (default<1-65535>)	119
1.10.34 timer t3122 (default<1-65535>)	119
1.10.35 timer t3141 (default<1-65535>)	120
1.10.36 timezone <-19-19> (0115130145)	120
1.10.37 timezone <-19-19> (0115130145) <0-2>	121
1.11 config-net-bts	121
1.11.1 abis-lower-transport (single-timeslotsuper-channel)	121
1.11.2 access-control-class-ramping	122
1.11.3 access-control-class-ramping-step-interval (<30-600> dynamic)	122
1.11.4 access-control-class-ramping-step-size (<1-10>)	122
1.11.5 amr tch-f hysteresis (mslbits) <0-15>	123
1.11.6 amr tch-f hysteresis (mslbits) <0-15> <0-15>	123
1.11.7 amr tch-f hysteresis (mslbits) <0-15> <0-15> <0-15>	124
1.11.8 amr tch-f modes (011 2 3 4 5 6 7)	124
1.11.9 amr tch-f modes (011 2 3 4 5 6 7) (011 2 3 4 5 6 7)	125
1.11.10 amr tch-f modes (011 2 3 4 5 6 7) (011 2 3 4 5 6 7) (011 2 3 4 5 6 7)	126
1.11.11 amr tch-f modes (011 2 3 4 5 6 7) (011 2 3 4 5 6 7) (011 2 3 4 5 6 7) (011 2 3 4...	128
1.11.12 amr tch-f start-mode (auto 1 2 3 4)	130
1.11.13 amr tch-f threshold (mslbits) <0-63>	130
1.11.14 amr tch-f threshold (mslbits) <0-63> <0-63>	131
1.11.15 amr tch-f threshold (mslbits) <0-63> <0-63> <0-63>	131
1.11.16 amr tch-h hysteresis (mslbits) <0-15>	132
1.11.17 amr tch-h hysteresis (mslbits) <0-15> <0-15>	132
1.11.18 amr tch-h hysteresis (mslbits) <0-15> <0-15> <0-15>	133
1.11.19 amr tch-h modes (011 2 3 4 5)	133
1.11.20 amr tch-h modes (011 2 3 4 5) (011 2 3 4 5)	134
1.11.21 amr tch-h modes (011 2 3 4 5) (011 2 3 4 5) (011 2 3 4 5)	135
1.11.22 amr tch-h modes (011 2 3 4 5) (011 2 3 4 5) (011 2 3 4 5) (011 2 3 4 5)	136
1.11.23 amr tch-h start-mode (auto 1 2 3 4)	138

1.11.24 amr tch-h threshold (mslmts) <0-63> . . . . .	138
1.11.25 amr tch-h threshold (mslmts) <0-63> <0-63> . . . . .	139
1.11.26 amr tch-h threshold (mslmts) <0-63> <0-63> <0-63> . . . . .	140
1.11.27 band BAND . . . . .	140
1.11.28 base_station_id_code <0-63> . . . . .	141
1.11.29 cell bar qualify (0 1) . . . . .	141
1.11.30 cell barred (0 1) . . . . .	141
1.11.31 cell reselection hysteresis <0-14> . . . . .	142
1.11.32 cell reselection offset <0-126> . . . . .	142
1.11.33 cell_identity <0-65535> . . . . .	142
1.11.34 channel allocator (ascending descending) . . . . .	143
1.11.35 channel-description attach (0 1) . . . . .	143
1.11.36 channel-description bs-ag-blks-res <0-7> . . . . .	143
1.11.37 channel-description bs-pa-mfrms <2-9> . . . . .	144
1.11.38 codec-support fr . . . . .	144
1.11.39 codec-support fr (hrlefrlamlr) . . . . .	144
1.11.40 codec-support fr (hrlefrlamlr) (hrlefrlamlr) . . . . .	145
1.11.41 codec-support fr (hrlefrlamlr) (hrlefrlamlr) (hrlefrlamlr) . . . . .	145
1.11.42 codec-support fr (hrlefrlamlr) (hrlefrlamlr) (hrlefrlamlr) (hrlefrlamlr) . . . . .	146
1.11.43 con-connection-group <1-31> . . . . .	147
1.11.44 del-connection-group <1-31> . . . . .	147
1.11.45 depends-on-bts <0-255> . . . . .	147
1.11.46 depeneds-on-bts <0-255> . . . . .	148
1.11.47 description .TEXT . . . . .	148
1.11.48 dtx downlink . . . . .	148
1.11.49 dtx uplink [force] . . . . .	149
1.11.50 early-classmark-sending (allowed forbidden) . . . . .	149
1.11.51 early-classmark-sending-3g (allowed forbidden) . . . . .	149
1.11.52 force-combined-si . . . . .	150
1.11.53 gprs 11bit_rach_support_for_egprs (0 1) . . . . .	150
1.11.54 gprs cell bvci <2-65535> . . . . .	150
1.11.55 gprs cell timer (blocking-timer blocking-retries unblocking-retries reset-timer ... . . . .	151
1.11.56 gprs control-ack-type-rach . . . . .	152
1.11.57 gprs mode (none gprslegprs) . . . . .	152
1.11.58 gprs network-control-order (nc0 nc1 nc2) . . . . .	152
1.11.59 gprs ns timer (tns-block tns-block-retries tns-reset tns-reset-retries tns-testl... . . . .	153
1.11.60 gprs nsei <0-65535> . . . . .	154
1.11.61 gprs nsvc <0-1> local udp port <0-65535> . . . . .	154
1.11.62 gprs nsvc <0-1> nsvci <0-65535> . . . . .	155

1.11.63 gprs nsvc <0-1> remote ip A.B.C.D . . . . .	155
1.11.64 gprs nsvc <0-1> remote udp port <0-65535> . . . . .	156
1.11.65 gprs routing area <0-255> . . . . .	156
1.11.66 ip.access rsl-ip A.B.C.D . . . . .	157
1.11.67 ip.access unit_id <0-65534> <0-255> . . . . .	157
1.11.68 is-connection-list (add del) <0-2047> <0-2047> <0-255> . . . . .	157
1.11.69 location_area_code <0-65535> . . . . .	158
1.11.70 ms max power <0-40> . . . . .	158
1.11.71 neighbor-list (add del) arfcn <0-1023> . . . . .	159
1.11.72 neighbor-list mode (automatic manuallmanual-si5) . . . . .	159
1.11.73 no access-control-class-ramping . . . . .	160
1.11.74 no description . . . . .	160
1.11.75 no dtx downlink . . . . .	160
1.11.76 no dtx uplink . . . . .	161
1.11.77 no force-combined-si . . . . .	161
1.11.78 no gprs control-ack-type-rach . . . . .	161
1.11.79 no periodic location update . . . . .	162
1.11.80 no rf-lock-exclude . . . . .	162
1.11.81 nokia_site bts-reset-timer <15-100> . . . . .	162
1.11.82 nokia_site no-local-rel-conf (0 1) . . . . .	163
1.11.83 nokia_site skip-reset (0 1) . . . . .	163
1.11.84 oml e1 line E1_LINE timeslot <1-31> sub-slot (0 1 2 3 full) . . . . .	163
1.11.85 oml e1 tei <0-63> . . . . .	164
1.11.86 oml ip.access stream_id <0-255> line E1_LINE . . . . .	165
1.11.87 paging free <-1-1024> . . . . .	165
1.11.88 pcu-socket PATH . . . . .	165
1.11.89 penalty time <20-620> . . . . .	166
1.11.90 penalty time reserved . . . . .	166
1.11.91 periodic location update <6-1530> . . . . .	166
1.11.92 rach access-control-class (0 1 2 3 4 5 6 7 8 9 11 12 13 14 15) (barred allowed) . . . . .	167
1.11.93 rach emergency call allowed (0 1) . . . . .	168
1.11.94 rach max transmission (1 2 4 7) . . . . .	168
1.11.95 rach nm busy threshold <0-255> . . . . .	169
1.11.96 rach nm load average <0-65535> . . . . .	169
1.11.97 rach tx integer <0-15> . . . . .	170
1.11.98 radio-link-timeout <4-64> . . . . .	170
1.11.99 radio-link-timeout infinite . . . . .	170
1.11.100 rf-lock-exclude . . . . .	171
1.11.101 rxlev access min <0-63> . . . . .	171

1.11.10	neighbor-list add earfcn <0-65535> thresh-hi <0-31> thresh-lo <0-32> p...	171
1.11.103	neighbor-list add uarfcn <0-16383> <0-511> <0-1>	172
1.11.104	neighbor-list del earfcn <0-65535>	173
1.11.105	neighbor-list del uarfcn <0-16383> <0-511>	173
1.11.106	neighbor-list (add del) arfcn <0-1023>	174
1.11.107	system-information (1 2 3 4 5 6 7 8 9 10 13 16 17 18 19 20 2bis 2ter 2quater 5bi...	174
1.11.108	system-information (1 2 3 4 5 6 7 8 9 10 13 16 17 18 19 20 2bis 2ter 2quater 5bi...	176
1.11.109	temporary offset <0-60>	177
1.11.110	temporary offset infinite	177
1.11.111	trx <0-255>	178
1.11.112	type (unknown bs1 nanobts lrbs2000 nokia_sitelsysmobts)	178
1.12	config-net-bts-trx	178
1.12.1	arfcn <0-1023>	178
1.12.2	description .TEXT	179
1.12.3	max_power_red <0-100>	179
1.12.4	no description	179
1.12.5	nominal power <0-100>	180
1.12.6	rf_locked (0 1)	180
1.12.7	rsl e1 line E1_LINE timeslot <1-31> sub-slot (0 1 2 3 full)	180
1.12.8	rsl e1 tei <0-63>	181
1.12.9	timeslot <0-7>	182
1.13	config-net-bts-trx-ts	182
1.13.1	e1 line E1_LINE timeslot <1-31> sub-slot (0 1 2 3 full)	182
1.13.2	hopping arfcn add <0-1023>	183
1.13.3	hopping arfcn del <0-1023>	183
1.13.4	hopping enabled (0 1)	183
1.13.5	hopping maio <0-63>	184
1.13.6	hopping sequence-number <0-63>	184
1.13.7	phys_chan_config (none ccc lcccch+sdccch4 tch/ftch/hlsdccch8 pdch tch/f_pdch unkno...	185
1.13.8	training_sequence_code <0-7>	186
1.14	oml	186
1.14.1	change-adm-state (locked unlocked shutdown null)	186
1.14.2	opstart	186
1.15	om2k	187
1.15.1	capabilities-request	187
1.15.2	configuration-request	187
1.15.3	connect-command	187
1.15.4	disable-request	187
1.15.5	disconnect-command	188

1.15.6	enable-request	188
1.15.7	operational-info <0-1>	188
1.15.8	reset-command	188
1.15.9	start-request	189
1.15.10	status-request	189
1.15.11	test-request	189
1.16	om2k-con-group	189
1.16.1	con-path (addl)del <0-2047> <0-255> concentrated <1-16>	189
1.16.2	con-path (addl)del <0-2047> <0-255> deconcentrated <0-63>	190
1.17	config-mncc-int	190
1.17.1	default-codec tch-f (frlefrlamr)	191
1.17.2	default-codec tch-h (hrlamr)	191
1.17.3	meas-feed destination ADDR <0-65535>	191
1.17.4	meas-feed scenario NAME	192
1.18	config-nitb	192
1.18.1	assign-tmsi	192
1.18.2	no assign-tmsi	192
1.18.3	no subscriber-create-on-demand	193
1.18.4	subscriber-create-on-demand [no-extension]	193
1.18.5	subscriber-create-on-demand random <1-999999999> <2-999999999>	193
1.19	config-smpp	194
1.19.1	esme NAME	194
1.19.2	local-tcp-ip A.B.C.D <1-65535>	194
1.19.3	local-tcp-port <1-65535>	194
1.19.4	no esme NAME	195
1.19.5	no smpp-first	195
1.19.6	policy (accept-allclosed)	195
1.19.7	smpp-first	196
1.19.8	system-id ID	196
1.20	config-smpp-esme	196
1.20.1	alert-notifications	196
1.20.2	dcs-transparent	196
1.20.3	default-route	197
1.20.4	deliver-src-imsi	197
1.20.5	no alert-notifications	197
1.20.6	no dcs-transparent	197
1.20.7	no default-route	198
1.20.8	no deliver-src-imsi	198
1.20.9	no osmocom-extensions	198

---

---

1.20.10 no password . . . . .	198
1.20.11 no route prefix (unknowninternationalnationalnetworksubscriberlphalabbrev)... . . . . .	199
1.20.12 osmocom-extensions . . . . .	200
1.20.13 password PASSWORD . . . . .	200
1.20.14 route prefix (unknowninternationalnationalnetworksubscriberlphalabbrev) (u... . . . .	200

---



# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list

#### Command

```
list
```

#### Parameters

list

Print command list

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

##### show

Show running system information

##### running-config

running configuration

### 1.1.6 write

#### Command

```
write
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

### 1.1.7 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

### 1.1.8 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

---

### 1.1.9 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable

#### Command

```
enable
```

#### Parameters

##### enable

Turn on privileged mode command

### 1.2.2 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

##### 0

Don't use color for printing messages

##### 1

Use color for printing messages

---

### 1.2.3 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

## 1.2.6 logging filter imsi IMSI

### Command

```
logging filter imsi IMSI
```

### Parameters

#### logging

Configure logging

#### filter

Filter log messages

#### imsi

Filter log messages by IMSI

#### IMSI

IMSI to be used as filter

## 1.2.7 logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns...

### Command

```
logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns|bssgp| ↔
llc|sndcp|nat|ctrl|smpp|filter|ranap|sua|pcu|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ↔
lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info ↔
|notice|error|fatal)
```

### Parameters

#### logging

Configure logging

#### level

Set the log level for a specified category

#### rll

A-bis Radio Link Layer (RLL)

#### cc

Layer3 Call Control (CC)

#### mm

Layer3 Mobility Management (MM)

#### rr

Layer3 Radio Resource (RR)

#### rsl

A-bis Radio Siganlling Link (RSL)

#### nm

A-bis Network Management / O&M (NM/OML)

mncc  
MNCC API for Call Control application

pag  
Paging Subsystem

meas  
Radio Measurement Processing

sccp  
SCCP Protocol

msc  
Mobile Switching Center

mgcp  
Media Gateway Control Protocol

ho  
Hand-Over

db  
Database Layer

ref  
Reference Counting

gprs  
GPRS Packet Service

ns  
GPRS Network Service (NS)

bssgp  
GPRS BSS Gateway Protocol (BSSGP)

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDTCP)

nat  
GSM 08.08 NAT/Multiplexer

ctrl  
Control interface

smpp  
SMPP interface for external SMS apps

filter  
BSC/NAT IMSI based filtering

ranap  
Radio Access Network Application Part Protocol

---



---

sua  
    SCCP User Adaptation Protocol

pcu  
    PCU Interface

lglobal  
    Library-internal global log family

llapd  
    LAPD in libosmogsm

linp  
    A-bis Input Subsystem

lmux  
    A-bis B-Subchannel TRAU Frame Multiplex

lmi  
    A-bis Input Driver for Signalling

lmib  
    A-bis Input Driver for B-Channels (voice)

lsms  
    Layer3 Short Message Service (SMS)

lctrl  
    Control Interface

lgtp  
    GPRS GTP library

lstats  
    Statistics messages and logging

lgsup  
    Generic Subscriber Update Protocol

loap  
    Osmocom Authentication Protocol

lss7  
    libosmo-sigtran Signalling System 7

lscpp  
    libosmo-sigtran SCCP Implementation

lsua  
    libosmo-sigtran SCCP User Adaptation

lm3ua  
    libosmo-sigtran MTP3 User Adaptation

lmgcp  
    libosmo-mgcp Media Gateway Control Protocol

---

**ljibuf**

libosmo-netif Jitter Buffer

**lrspro**

Remote SIM protocol

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.8 logging level force-all (debug|info|notice|error|fatal)

**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.9 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.2.10 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with category/subsystem name

---

### 1.2.11 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.12 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnn

### 1.2.13 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.14 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.2.15 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

#### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.16 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.17 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.18 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.19 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.2.20 show bts [<0-255>]

#### Command

```
show bts [<0-255>]
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

[<0-255>]

BTS number

---

### 1.2.21 show e1\_driver

#### Command

```
show e1_driver
```

#### Parameters

show

Show running system information

e1\_driver

Display information about available E1 drivers

### 1.2.22 show e1\_line [line\_nr] [stats]

#### Command

```
show e1_line [line_nr] [stats]
```

#### Parameters

show

Show running system information

e1\_line

Display information about a E1 line

[line\_nr]

E1 Line Number

[stats]

Include statistics

### 1.2.23 show e1\_timeslot [line\_nr] [ts\_nr]

#### Command

```
show e1_timeslot [line_nr] [ts_nr]
```

#### Parameters

show

Show running system information

e1\_timeslot

Display information about a E1 timeslot

[line\_nr]

E1 Line Number

[ts\_nr]

E1 Timeslot Number



### 1.2.24 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### NAME

Display information about a single named finite state machine

### 1.2.25 show fsm all

#### Command

```
show fsm all
```

#### Parameters

##### show

Show running system information

##### fsm

Show information about finite state machines

##### all

Display a list of all registered finite state machines

### 1.2.26 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

##### show

Show running system information

##### fsm-instances

Show information about finite state machine instances

##### NAME

Display a list of all FSM instances of the named finite state machine

---

### 1.2.27 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

### 1.2.28 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.2.29 show lchan [<0-255>] [<0-255>] [<0-7>] [lchan\_nr]

#### Command

```
show lchan [<0-255>] [<0-255>] [<0-7>] [lchan_nr]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[lchan\_nr]

Logical Channel Number

### 1.2.30 show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan\_nr]

#### Command

```
show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan_nr]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

summary

Short summary

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[lchan\_nr]

Logical Channel Number

### 1.2.31 show logging vty

#### Command

```
show logging vty
```

#### Parameters

show

Show running system information

logging

Show current logging configuration

vtty

Show current logging configuration for this vty

### 1.2.32 show network

#### Command

```
show network
```

#### Parameters

##### show

Show running system information

##### network

Display information about a GSM NETWORK

### 1.2.33 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.34 show paging [<0-255>]

#### Command

```
show paging [<0-255>]
```

#### Parameters

##### show

Show running system information

##### paging

Display information about paging requests of a BTS

##### [<0-255>]

BTS Number

---

### 1.2.35 show paging-group <0-255> IMSI

#### Command

```
show paging-group <0-255> IMSI
```

#### Parameters

show

Show running system information

paging-group

Display the paging group

<0-255>

BTS Number

IMSI

IMSI

### 1.2.36 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

### 1.2.37 show smpp esme

#### Command

```
show smpp esme
```

#### Parameters

show

Show running system information

smpp

SMPP Interface

esme

SMPP External SMS Entity

### 1.2.38 show sms-queue

#### Command

```
show sms-queue
```

#### Parameters

show

Show running system information

sms-queue

Display SMSQueue statistics

### 1.2.39 show statistics

#### Command

```
show statistics
```

#### Parameters

show

Show running system information

statistics

Display network statistics

### 1.2.40 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.2.41 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.2.42 show subscriber (extension|imsi|tmsi|id) ID

#### Command

```
show subscriber (extension|imsi|tmsi|id) ID
```

#### Parameters

show

Show running system information

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

### 1.2.43 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

### 1.2.44 show timeslot [<0-255>] [<0-255>] [<0-7>]

#### Command

```
show timeslot [<0-255>] [<0-255>] [<0-7>]
```

#### Parameters

show

Show running system information

timeslot

Display information about a TS

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

### 1.2.45 show trx [<0-255>] [<0-255>]

#### Command

```
show trx [<0-255>] [<0-255>]
```

#### Parameters

show

Show running system information



trx

Display information about a TRX

[<0-255>]

BTS Number

[<0-255>]

TRX Number

### 1.2.46 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

### 1.2.47 sms send pending

Command

```
sms send pending
```

Parameters

sms

SMS related commands

send

SMS Sending related commands

pending

Send all pending SMS

### 1.2.48 subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)
```

Parameters

subscriber

Operations on a Subscriber

**extension**

Identify subscriber by extension (phone number)

**imsi**

Identify subscriber by IMSI

**tmsi**

Identify subscriber by TMSI

**id**

Identify subscriber by database ID

**ID**

Identifier for the subscriber

**ms-test**

Send a TS 04.14 MS Test Command to subscriber

**close-loop**

Close a TCH Loop inside the MS

**a**

Loop Type A

**b**

Loop Type B

**c**

Loop Type C

**d**

Loop Type D

**e**

Loop Type E

**f**

Loop Type F

**i**

Loop Type I

### 1.2.49 subscriber (extension|imsi|tmsi|id) ID ms-test open-loop

**Command**

```
subscriber (extension|imsi|tmsi|id) ID ms-test open-loop
```

**Parameters****subscriber**

Operations on a Subscriber

**extension**

Identify subscriber by extension (phone number)

---

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

open-loop

Open a TCH Loop inside the MS

### 1.2.50 subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdccch)
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-call

Silent call operation

start

Start silent call

any

Any channel

tch/f

TCH/F channel

tch/any

Any TCH channel

sdccch

SDCCCH channel

### 1.2.51 subscriber (extension|imsi|tmsi|id) ID silent-call stop

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call stop
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-call

Silent call operation

stop

Stop silent call

### 1.2.52 subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id...

Command

```
subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id) ←  
SENDER_ID send .LINE
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

silent-sms

Silent SMS Operations

sender

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

SENDER\_ID

Identifier for the subscriber

send

Send SMS

.LINE

Actual SMS Text

### 1.2.53 subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDE...

Command

```
subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDER_ID ↔  
send .LINE
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

sms

SMS Operations

sender

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

SENDER\_ID

Identifier for the subscriber

send

Send SMS

.LINE

Actual SMS Text

### 1.2.54 subscriber (extension|imsi|tmsi|id) ID update

Command

```
subscriber (extension|imsi|tmsi|id) ID update
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

update

Update the subscriber data from the dabase.

### 1.2.55 subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT

Command

```
subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ussd-notify

Send a USSD notify to the subscriber

0

Alerting Level 0

1

Alerting Level 1

2

Alerting Level 2

.TEXT

Text of USSD message to send

---

### 1.2.56 subscriber create imsi ID

#### Command

```
subscriber create imsi ID
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### create

Create new subscriber

##### imsi

Identify the subscriber by his IMSI

##### ID

Identifier for the subscriber

### 1.2.57 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.58 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---



## 1.2.59 who

### Command

```
who
```

### Parameters

who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 **bts <0-255> om2000 class (trxc|ts|tf|is|con|dp|cf|tx|rx) <0-255> <0-255> <0-255>**

### Command

```
bts <0-255> om2000 class (trxc|ts|tf|is|con|dp|cf|tx|rx) <0-255> <0-255> <0-255>
```

### Parameters

bts

BTS related commands

<0-255>

BTS Number

om2000

Manipulate the OM2000 managed objects

class

Object Class

trxc

TRX Controller

ts

Timeslot

tf

Timing Function

is

Interface Switch

con

Abis Concentrator

dp  
Digital Path

cf  
Central Function

tx  
Transmitter

rx  
Receiver

<0-255>  
BTS Number

<0-255>  
Associated SO Instance

<0-255>  
Instance Number

### 1.3.2 **bts <0-255> om2000 class <0-255> <0-255> <0-255> <0-255>**

#### Command

```
bts <0-255> om2000 class <0-255> <0-255> <0-255> <0-255>
```

#### Parameters

bts  
BTS related commands

<0-255>  
BTS Number

om2000  
Manipulate the OML managed objects

class  
Object Class

<0-255>  
Object Class

<0-255>  
BTS Number

<0-255>  
Associated SO Instance

<0-255>  
Instance Number

### 1.3.3 **bts <0-255> oml class (site-manager|bts|radio-carrier|baseband-transceiver|chann...**

#### Command

```
bts <0-255> oml class (site-manager|bts|radio-carrier|baseband-transceiver|channel|adjc ↔  
|handover|power-contorl|btse|rack|test|envabtse|bport|gprs-nse|gprs-cell|gprs-nsvc| ↔  
siemenshw) instance <0-255> <0-255> <0-255>
```

#### Parameters

bts

BTS related commands

<0-255>

BTS Number

oml

Manipulate the OML managed objects

class

Object Class

site-manager

Site Manager Object

bts

BTS Object

radio-carrier

Radio Carrier Object

baseband-transceiver

Baseband Transceiver Object

channel

Channel (Timeslot) Object

adjc

Adjacent Object (Siemens)

handover

Handover Object (Siemens)

power-contorl

Power Control Object (Siemens)

btse

BTSE Object (Siemens)

rack

Rack Object (Siemens)

test

Test Object (Siemens)

envabtse

ENVABTSE Object (Siemens)

bport

BPORT Object (Siemens)

gprs-nse

GPRS NSE Object (ip.access/osmo-bts)

gprs-cell

GPRS Cell Object (ip.acecss/osmo-bts)

gprs-nsvc

GPRS NSVC Object (ip.acecss/osmo-bts)

siemenshw

SIEMENSHW Object (Siemens)

instance

Object Instance

<0-255>

BTS Number

<0-255>

TRX Number

<0-255>

TS Number

### 1.3.4 **bts <0-255> oml class <0-255> instance <0-255> <0-255> <0-255>**

Command

```
bts <0-255> oml class <0-255> instance <0-255> <0-255> <0-255>
```

Parameters

bts

BTS related commands

<0-255>

BTS Number

oml

Manipulate the OML managed objects

class

Object Class

<0-255>

Object Class

instance

Object Instance

<0-255>

BTS Number

<0-255>

TRX Number

<0-255>

TS Number

### 1.3.5 **bts <0-255> resend-system-information**

Command

```
bts <0-255> resend-system-information
```

Parameters

bts

BTS Specific Commands

<0-255>

BTS Number

resend-system-information

Re-generate + re-send BCCH SYSTEM INFORMATION

### 1.3.6 **bts <0-255> smscb-command <1-4> HEXSTRING**

Command

```
bts <0-255> smscb-command <1-4> HEXSTRING
```

Parameters

bts

BTS related commands

<0-255>

BTS Number

smscb-command

SMS Cell Broadcast

<1-4>

Last Valid Block

HEXSTRING

Hex Encoded SMSCB message (up to 88 octets)

### 1.3.7 **bts <0-255> trx <0-255> timeslot <0-7> pdch (activate|deactivate)**

#### Command

```
bts <0-255> trx <0-255> timeslot <0-7> pdch (activate|deactivate)
```

#### Parameters

bts

BTS related commands

<0-255>

BTS Number

trx

Transceiver

<0-255>

Transceiver Number

timeslot

TRX Timeslot

<0-7>

Timeslot Number

pdch

Packet Data Channel

activate

Activate Dynamic PDCH/TCH (-> PDCH mode)

deactivate

Deactivate Dynamic PDCH/TCH (-> TCH mode)

### 1.3.8 **bts <0-255> trx <0-255> timeslot <0-7> sub-slot <0-7> (activate|deactivate) (hr|...)**

#### Command

```
bts <0-255> trx <0-255> timeslot <0-7> sub-slot <0-7> (activate|deactivate) (hr|fr|efr| ←  
amr) [<0-7>]
```

#### Parameters

bts

BTS related commands

<0-255>

BTS Number

trx

Transceiver

<0-255>

Transceiver Number

timeslot

TRX Timeslot

<0-7>

Timeslot Number

sub-slot

Sub-Slot Number

<0-7>

Sub-Slot Number

activate

Manual Channel Activation (e.g. for BER test)

deactivate

Manual Channel Deactivation (e.g. for BER test)

hr

Half-Rate v1

fr

Full-Rate

efr

Enhanced Full Rate

amr

Adaptive Multi-Rate

[<0-7>]

AMR Mode

### 1.3.9 **bts** <0-255> **trx** <0-255> **timeslot** <0-7> **sub-slot** <0-7> **mdcx** A.B.C.D <0-65535>

Command

```
bts <0-255> trx <0-255> timeslot <0-7> sub-slot <0-7> mdcx A.B.C.D <0-65535>
```

Parameters

bts

BTS related commands

<0-255>

BTS Number

trx

Transceiver

<0-255>

Transceiver Number

timeslot

TRX Timeslot

<0-7>

Timeslot Number

sub-slot

Sub-Slot

<0-7>

Sub-Slot Number

mdcx

Modify RTP Connection

A.B.C.D

MGW IP Address

<0-65535>

MGW UDP Port

### 1.3.10 configure terminal

Command

```
configure terminal
```

Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.3.11 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)



### 1.3.12 ctrl-interface generate-trap TRAP VALUE

#### Command

```
ctrl-interface generate-trap TRAP VALUE
```

#### Parameters

##### ctrl-interface

Commands related to the CTRL Interface

##### generate-trap

Generate a TRAP for test purpose

##### TRAP

Identity/Name of the TRAP variable

##### VALUE

Value of the TRAP variable

### 1.3.13 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.3.14 drop bts connection <0-65535> (oml|rs1)

#### Command

```
drop bts connection <0-65535> (oml|rs1)
```

#### Parameters

##### drop

Debug/Simulation command to drop Abis/IP BTS

##### bts

Debug/Simulation command to drop Abis/IP BTS

##### connection

Debug/Simulation command to drop Abis/IP BTS

##### <0-65535>

BTS NR

##### oml

Drop OML Connection

##### rs1

Drop RSL Connection

### 1.3.15 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.3.16 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.17 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.3.18 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.19 logging filter imsi IMSI

#### Command

```
logging filter imsi IMSI
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### imsi

Filter log messages by IMSI

##### IMSI

IMSI to be used as filter

### 1.3.20 logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns...

#### Command

```
logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns|bssgp| ↔
llc|sndcp|nat|ctrl|smpp|filter|ranap|sua|pcu|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ↔
lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info ↔
|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### rll

A-bis Radio Link Layer (RLL)

##### cc

Layer3 Call Control (CC)

##### mm

Layer3 Mobility Management (MM)

##### rr

Layer3 Radio Resource (RR)

##### rsl

A-bis Radio Signalling Link (RSL)

##### nm

A-bis Network Management / O&M (NM/OML)

##### mncc

MNCC API for Call Control application

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### sccp

SCCP Protocol

##### msc

Mobile Switching Center

##### mgcp

Media Gateway Control Protocol

##### ho

Hand-Over

---

db  
Database Layer

ref  
Reference Counting

gprs  
GPRS Packet Service

ns  
GPRS Network Service (NS)

bssgp  
GPRS BSS Gateway Protocol (BSSGP)

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

nat  
GSM 08.08 NAT/Multiplexer

ctrl  
Control interface

smpp  
SMPP interface for external SMS apps

filter  
BSC/NAT IMSI based filtering

ranap  
Radio Access Network Application Part Protocol

sua  
SCCP User Adaptation Protocol

pcu  
PCU Interface

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

---

---

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.3.21 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.3.22 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

---

- info  
Log informational messages and higher levels
- notice  
Log noticeable messages and higher levels
- error  
Log error messages and higher levels
- fatal  
Log only fatal messages

### 1.3.23 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

- logging  
Configure logging
- print  
Log output settings
- category  
Configure log message
- 0  
Don't prefix each log message
- 1  
Prefix each log message with category/subsystem name

### 1.3.24 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

- logging  
Configure logging
- print  
Log output settings
- category-hex  
Configure log message
- 0  
Don't prefix each log message
- 1  
Prefix each log message with category/subsystem nr in hex ('<000b>')



### 1.3.25 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.26 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.27 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.3.28 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.29 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

### logging

Configure logging

### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

## 1.3.30 meas-feed scenario NAME

### Command

```
meas-feed scenario NAME
```

### Parameters

#### meas-feed

Measurement export related

#### scenario

scenario

#### NAME

Name up to 31 characters included in report

## 1.3.31 no logging level force-all

### Command

```
no logging level force-all
```

### Parameters

#### no

Negate a command or set its defaults

#### logging

Configure logging

#### level

Set the log level for a specified category

#### force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.32 restart-bts <0-65535>

#### Command

```
restart-bts <0-65535>
```

#### Parameters

restart-bts

Restart ip.access nanoBTS through OML

<0-65535>

BTS Number

### 1.3.33 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.3.34 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

---

### 1.3.35 show bts [<0-255>]

#### Command

```
show bts [<0-255>]
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

[<0-255>]

BTS number

### 1.3.36 show e1\_driver

#### Command

```
show e1_driver
```

#### Parameters

show

Show running system information

e1\_driver

Display information about available E1 drivers

### 1.3.37 show e1\_line [line\_nr] [stats]

#### Command

```
show e1_line [line_nr] [stats]
```

#### Parameters

show

Show running system information

e1\_line

Display information about a E1 line

[line\_nr]

E1 Line Number

[stats]

Include statistics

---

### 1.3.38 show e1\_timeslot [line\_nr] [ts\_nr]

#### Command

```
show e1_timeslot [line_nr] [ts_nr]
```

#### Parameters

show

Show running system information

e1\_timeslot

Display information about a E1 timeslot

[line\_nr]

E1 Line Number

[ts\_nr]

E1 Timeslot Number

### 1.3.39 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

NAME

Display information about a single named finite state machine

### 1.3.40 show fsm all

#### Command

```
show fsm all
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

all

Display a list of all registered finite state machines

---

### 1.3.41 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

NAME

Display a list of all FSM instances of the named finite state machine

### 1.3.42 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

### 1.3.43 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.3.44 show lchan [<0-255>] [<0-255>] [<0-7>] [lchan\_nr]

#### Command

```
show lchan [<0-255>] [<0-255>] [<0-7>] [lchan_nr]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[lchan\_nr]

Logical Channel Number

### 1.3.45 show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan\_nr]

#### Command

```
show lchan summary [<0-255>] [<0-255>] [<0-7>] [lchan_nr]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

summary

Short summary

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[lchan\_nr]

Logical Channel Number



### 1.3.46 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.3.47 show network

#### Command

```
show network
```

#### Parameters

##### show

Show running system information

##### network

Display information about a GSM NETWORK

### 1.3.48 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.3.49 show paging [<0-255>]

#### Command

```
show paging [<0-255>]
```

#### Parameters

show

Show running system information

paging

Display information about paging reuquests of a BTS

[<0-255>]

BTS Number

### 1.3.50 show paging-group <0-255> IMSI

#### Command

```
show paging-group <0-255> IMSI
```

#### Parameters

show

Show running system information

paging-group

Display the paging group

<0-255>

BTS Number

IMSI

IMSI

### 1.3.51 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

### 1.3.52 show smpp esme

#### Command

```
show smpp esme
```

#### Parameters

show

Show running system information

smpp

SMPP Interface

esme

SMPP External SMS Entity

### 1.3.53 show sms-queue

#### Command

```
show sms-queue
```

#### Parameters

show

Show running system information

sms-queue

Display SMSqueue statistics

### 1.3.54 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.3.55 show statistics

#### Command

```
show statistics
```

#### Parameters

show

Show running system information

statistics

Display network statistics

### 1.3.56 show stats

#### Command

```
show stats
```

#### Parameters

show

Show running system information

stats

Show statistical values

### 1.3.57 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

### 1.3.58 show subscriber (extension|imsi|tmsi|id) ID

#### Command

```
show subscriber (extension|imsi|tmsi|id) ID
```

#### Parameters

##### show

Show running system information

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

### 1.3.59 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

##### show

Show running system information

##### subscriber

Show information about subscribers

##### cache

Display contents of subscriber cache

### 1.3.60 show timeslot [<0-255>] [<0-255>] [<0-7>]

#### Command

```
show timeslot [<0-255>] [<0-255>] [<0-7>]
```

#### Parameters

show

Show running system information

timeslot

Display information about a TS

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

### 1.3.61 show trx [<0-255>] [<0-255>]

#### Command

```
show trx [<0-255>] [<0-255>]
```

#### Parameters

show

Show running system information

trx

Display information about a TRX

[<0-255>]

BTS Number

[<0-255>]

TRX Number

### 1.3.62 show version

#### Command

```
show version
```

#### Parameters

show

Show running system information

version

Displays program version

### 1.3.63 sms send pending

#### Command

```
sms send pending
```

#### Parameters

sms

SMS related commands

send

SMS Sending related commands

pending

Send all pending SMS

### 1.3.64 sms-queue clear

#### Command

```
sms-queue clear
```

#### Parameters

sms-queue

SMS Queue

clear

Clear the queue of pending SMS

### 1.3.65 sms-queue max-failure <1-500>

#### Command

```
sms-queue max-failure <1-500>
```

#### Parameters

sms-queue

SMS Queue

max-failure

Maximum amount of delivery failures

<1-500>

Amount

---

### 1.3.66 sms-queue max-pending <1-500>

#### Command

```
sms-queue max-pending <1-500>
```

#### Parameters

sms-queue

SMS Queue

max-pending

SMS to deliver in parallel

<1-500>

Amount

### 1.3.67 sms-queue trigger

#### Command

```
sms-queue trigger
```

#### Parameters

sms-queue

SMS Queue

trigger

Trigger sending messages

### 1.3.68 subscriber (extension|imsi|tmsi|id) ID a3a8 (none|xor|comp128v1|comp128v2|comp128v3) [ ← KI]

#### Command

```
subscriber (extension|imsi|tmsi|id) ID a3a8 (none|xor|comp128v1|comp128v2|comp128v3) [ ← KI]
```

#### Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI



id  
Identify subscriber by database ID

ID  
Identifier for the subscriber

a3a8  
Set a3a8 parameters for the subscriber

none  
Use No A3A8 algorithm

xor  
Use XOR algorithm

comp128v1  
Use COMP128v1 algorithm

comp128v2  
Use COMP128v2 algorithm

comp128v3  
Use COMP128v3 algorithm

[KI]  
Encryption Key Ki

### 1.3.69 subscriber (extension|imsi|tmsi|id) ID authorized (0|1)

#### Command

```
subscriber (extension|imsi|tmsi|id) ID authorized (0|1)
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

##### authorized

(De-)Authorize subscriber in HLR

0

Subscriber should NOT be authorized

1

Subscriber should be authorized

### 1.3.70 subscriber (extension|imsi|tmsi|id) ID delete

Command

```
subscriber (extension|imsi|tmsi|id) ID delete
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

delete

Delete subscriber in HLR

### 1.3.71 subscriber (extension|imsi|tmsi|id) ID expire

Command

```
subscriber (extension|imsi|tmsi|id) ID expire
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

expire

Expire the subscriber Now

### 1.3.72 subscriber (extension|imsi|tmsi|id) ID extension EXTENSION

Command

```
subscriber (extension|imsi|tmsi|id) ID extension EXTENSION
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

extension

Set the extension (phone number) of the subscriber

EXTENSION

Extension (phone number)

### 1.3.73 subscriber (extension|imsi|tmsi|id) ID handover BTS\_NR

Command

```
subscriber (extension|imsi|tmsi|id) ID handover BTS_NR
```

Parameters

---

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

handover

Handover the active connection

BTS\_NR

Number of the BTS to handover to

### 1.3.74 subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)

Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test close-loop (a|b|c|d|e|f|i)
```

Parameters

subscriber

Operations on a Subscriber

extension

Identify subscriber by extension (phone number)

imsi

Identify subscriber by IMSI

tmsi

Identify subscriber by TMSI

id

Identify subscriber by database ID

ID

Identifier for the subscriber

ms-test

Send a TS 04.14 MS Test Command to subscriber

close-loop

Close a TCH Loop inside the MS

---

- a  
Loop Type A
- b  
Loop Type B
- c  
Loop Type C
- d  
Loop Type D
- e  
Loop Type E
- f  
Loop Type F
- i  
Loop Type I

### 1.3.75 subscriber (extension|imsi|tmsi|id) ID ms-test open-loop

#### Command

```
subscriber (extension|imsi|tmsi|id) ID ms-test open-loop
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

##### ms-test

Send a TS 04.14 MS Test Command to subscriber

##### open-loop

Open a TCH Loop inside the MS

### 1.3.76 subscriber (extension|imsi|tmsi|id) ID name .NAME

#### Command

```
subscriber (extension|imsi|tmsi|id) ID name .NAME
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

##### name

Set the name of the subscriber

##### .NAME

Name of the Subscriber

### 1.3.77 subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...

#### Command

```
subscriber (extension|imsi|tmsi|id) ID silent-call start (any|tch/f|tch/any|sdcc...
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

**ID**

Identifier for the subscriber

**silent-call**

Silent call operation

**start**

Start silent call

**any**

Any channel

**tch/f**

TCH/F channel

**tch/any**

Any TCH channel

**sdccch**

SDCCCH channel

### 1.3.78 subscriber (extension|imsi|tmsi|id) ID silent-call stop

**Command**

```
subscriber (extension|imsi|tmsi|id) ID silent-call stop
```

**Parameters****subscriber**

Operations on a Subscriber

**extension**

Identify subscriber by extension (phone number)

**imsi**

Identify subscriber by IMSI

**tmsi**

Identify subscriber by TMSI

**id**

Identify subscriber by database ID

**ID**

Identifier for the subscriber

**silent-call**

Silent call operation

**stop**

Stop silent call

### 1.3.79 subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id...

#### Command

```
subscriber (extension|imsi|tmsi|id) ID silent-sms sender (extension|imsi|tmsi|id) ←  
SENDER_ID send .LINE
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

##### silent-sms

Silent SMS Operations

##### sender

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### SENDER\_ID

Identifier for the subscriber

##### send

Send SMS

##### .LINE

Actual SMS Text



### 1.3.80 subscriber (extension|imsi|tmsi|id) ID sms pending-send

#### Command

```
subscriber (extension|imsi|tmsi|id) ID sms pending-send
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

##### id

Identify subscriber by database ID

##### ID

Identifier for the subscriber

##### sms

SMS Operations

##### pending-send

Send pending SMS

### 1.3.81 subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDE...

#### Command

```
subscriber (extension|imsi|tmsi|id) ID sms sender (extension|imsi|tmsi|id) SENDER_ID ↔  
send .LINE
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### extension

Identify subscriber by extension (phone number)

##### imsi

Identify subscriber by IMSI

##### tmsi

Identify subscriber by TMSI

id  
Identify subscriber by database ID

ID  
Identifier for the subscriber

sms  
SMS Operations

sender  
Operations on a Subscriber

extension  
Identify subscriber by extension (phone number)

imsi  
Identify subscriber by IMSI

tmsi  
Identify subscriber by TMSI

id  
Identify subscriber by database ID

SENDER\_ID  
Identifier for the subscriber

send  
Send SMS

.LINE  
Actual SMS Text

### 1.3.82 subscriber (extension|imsi|tmsi|id) ID update

#### Command

```
subscriber (extension|imsi|tmsi|id) ID update
```

#### Parameters

subscriber  
Operations on a Subscriber

extension  
Identify subscriber by extension (phone number)

imsi  
Identify subscriber by IMSI

tmsi  
Identify subscriber by TMSI

id  
Identify subscriber by database ID

**ID**

Identifier for the subscriber

**update**

Update the subscriber data from the dabase.

**1.3.83 subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT****Command**

```
subscriber (extension|imsi|tmsi|id) ID ussd-notify (0|1|2) .TEXT
```

**Parameters****subscriber**

Operations on a Subscriber

**extension**

Identify subscriber by extension (phone number)

**imsi**

Identify subscriber by IMSI

**tmsi**

Identify subscriber by TMSI

**id**

Identify subscriber by database ID

**ID**

Identifier for the subscriber

**ussd-notify**

Send a USSD notify to the subscriber

**0**

Alerting Level 0

**1**

Alerting Level 1

**2**

Alerting Level 2

**.TEXT**

Text of USSD message to send

---

### 1.3.84 subscriber create imsi ID

#### Command

```
subscriber create imsi ID
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### create

Create new subscriber

##### imsi

Identify the subscriber by his IMSI

##### ID

Identifier for the subscriber

### 1.3.85 subscriber purge-inactive

#### Command

```
subscriber purge-inactive
```

#### Parameters

##### subscriber

Operations on a Subscriber

##### purge-inactive

Purge subscribers with a zero use count.

### 1.3.86 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

---

### 1.3.87 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.88 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.89 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

---

### 1.3.90 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

banner

Set banner string

motd

Strings for motd

default

Default string

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

banner

Set banner

motd

Banner for motd

file

Banner from a file

[FILE]

Filename

---

### 1.4.3 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.4.4 e1\_input

#### Command

```
e1_input
```

#### Parameters

e1\_input

Configure E1/T1/J1 TDM input

### 1.4.5 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

---

## 1.4.6 enable password LINE

### Command

```
enable password LINE
```

### Parameters

#### enable

Modify enable password parameters

#### password

Assign the privileged level password

#### LINE

The UNENCRYPTED (cleartext) 'enable' password

## 1.4.7 hostname WORD

### Command

```
hostname WORD
```

### Parameters

#### hostname

Set system's network name

#### WORD

This system's network name

## 1.4.8 line vty

### Command

```
line vty
```

### Parameters

#### line

Configure a terminal line

#### vtty

Virtual terminal

---



### 1.4.9 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.10 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.11 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

---

### 1.4.12 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.13 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

### 1.4.14 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.4.15 mncc-int

#### Command

```
mncc-int
```

#### Parameters

mncc-int

Configure internal MNCC handler

### 1.4.16 network

#### Command

```
network
```

#### Parameters

network

Configure the GSM network

### 1.4.17 nitb

#### Command

```
nitb
```

#### Parameters

nitb

Configure NITB options

---

### 1.4.18 no banner motd

#### Command

```
no banner motd
```

#### Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.19 no enable password

#### Command

```
no enable password
```

#### Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

---

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.23 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.24 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.25 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.26 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.4.27 no stats reporter log

#### Command

```
no stats reporter log
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.28 no stats reporter statsd

#### Command

```
no stats reporter statsd
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.4.29 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.4.30 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.4.31 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.4.32 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

---



### 1.4.33 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.34 smpp

#### Command

```
smpp
```

#### Parameters

##### smpp

Configure SMPP SMS Interface

### 1.4.35 stats interval <1-65535>

#### Command

```
stats interval <1-65535>
```

#### Parameters

##### stats

Configure stats sub-system

##### interval

Set the reporting interval

##### <1-65535>

Interval in seconds

---

### 1.4.36 stats reporter log

#### Command

```
stats reporter log
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.37 stats reporter statsd

#### Command

```
stats reporter statsd
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

## logging

Configure logging

## color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

## logging

Configure logging

## filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.5.3 logging filter imsi IMSI

#### Command

```
logging filter imsi IMSI
```

#### Parameters

## logging

Configure logging

**filter**

Filter log messages

**imsi**

Filter log messages by IMSI

**IMSI**

IMSI to be used as filter

**1.5.4 logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns...****Command**

```
logging level (rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns|bssgp| ←
llc|sndcp|nat|ctrl|smpp|filter|ranap|sua|pcu|lglobal|llapd|linp|lmux|lmi|lmib|lsms| ←
lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info ←
|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**rll**

A-bis Radio Link Layer (RLL)

**cc**

Layer3 Call Control (CC)

**mm**

Layer3 Mobility Management (MM)

**rr**

Layer3 Radio Resource (RR)

**rsl**

A-bis Radio Signalling Link (RSL)

**nm**

A-bis Network Management / O&amp;M (NM/OML)

**mncc**

MNCC API for Call Control application

**pag**

Paging Subsystem

**meas**

Radio Measurement Processing

**sccp**

SCCP Protocol

---

msc  
Mobile Switching Center

mgcp  
Media Gateway Control Protocol

ho  
Hand-Over

db  
Database Layer

ref  
Reference Counting

gprs  
GPRS Packet Service

ns  
GPRS Network Service (NS)

bssgp  
GPRS BSS Gateway Protocol (BSSGP)

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

nat  
GSM 08.08 NAT/Multiplexer

ctrl  
Control interface

smpp  
SMPP interface for external SMS apps

filter  
BSC/NAT IMSI based filtering

ranap  
Radio Access Network Application Part Protocol

sua  
SCCP User Adaptation Protocol

pcu  
PCU Interface

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

---

---

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

---

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.5 logging level force-all (debug|info|notice|error|fatal)

**Command**

```
logging level force-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.6 logging level set-all (debug|info|notice|error|fatal)

**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

---

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.7 logging print category (0|1)

**Command**

```
logging print category (0|1)
```

**Parameters****logging**

Configure logging

**print**

Log output settings

**category**

Configure log message

**0**

Don't prefix each log message

**1**

Prefix each log message with category/subsystem name

### 1.5.8 logging print category-hex (0|1)

**Command**

```
logging print category-hex (0|1)
```

**Parameters**



## logging

Configure logging

## print

Log output settings

## category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.9 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

## logging

Configure logging

## print

Log output settings

## extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.10 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

## logging

Configure logging

## print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.11 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.12 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.13 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

#### Command

```
disable
```

#### Parameters

disable

Disable the reporter

### 1.6.2 enable

#### Command

```
enable
```

#### Parameters

enable

Enable the reporter

---

### 1.6.3 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

##### level

Set the maximum group level

##### global

Report global groups only

##### peer

Report global and network peer related groups

##### subscriber

Report global, peer, and subscriber groups

### 1.6.4 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.5 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

---

### 1.6.6 no local-ip

#### Command

```
no local-ip
```

#### Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

### 1.6.7 no mtu

#### Command

```
no mtu
```

#### Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

### 1.6.8 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.9 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

## 1.6.10 remote-ip ADDR

### Command

```
remote-ip ADDR
```

### Parameters

#### remote-ip

Set the remote IP address to which we connect

#### ADDR

IP Address

## 1.6.11 remote-port <1-65535>

### Command

```
remote-port <1-65535>
```

### Parameters

#### remote-port

Set the remote port to which we connect

#### <1-65535>

Remote port number

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

### Command

```
bind A.B.C.D [<0-65535>]
```

### Parameters

#### bind

Accept VTY telnet connections on local interface

#### A.B.C.D

Local interface IP address (default: 127.0.0.1)

#### [<0-65535>]

Local TCP port number

---

## 1.7.2 login

### Command

```
login
```

### Parameters

login

Enable password checking

## 1.7.3 no login

### Command

```
no login
```

### Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-e1\_input

### 1.8.1 e1\_line <0-255> driver (misdn|misdn\_lapd|dahdi|ipa|unixsocket)

### Command

```
e1_line <0-255> driver (misdn|misdn_lapd|dahdi|ipa|unixsocket)
```

### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

driver

Set driver for this line

misdn

mISDN supported E1 Card (kernel LAPD)

misdn\_lapd

mISDN supported E1 Card (userspace LAPD)

---

dahdi

DAHDI supported E1/T1/J1 Card

ipa

IPA TCP/IP input

unixsocket

HSL TCP/IP input

### 1.8.2 e1\_line <0-255> keepalive

Command

```
e1_line <0-255> keepalive
```

Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

keepalive

Enable keep-alive probing

### 1.8.3 e1\_line <0-255> keepalive <1-300> <1-20> <1-300>

Command

```
e1_line <0-255> keepalive <1-300> <1-20> <1-300>
```

Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

keepalive

Enable keep-alive probing

<1-300>

Idle interval in seconds before probes are sent

<1-20>

Number of probes to sent

<1-300>

Delay between probe packets in seconds

---



### 1.8.4 e1\_line <0-255> name .LINE

#### Command

```
e1_line <0-255> name .LINE
```

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

name

Set name for this line

.LINE

Human readable name

### 1.8.5 e1\_line <0-255> port <0-255>

#### Command

```
e1_line <0-255> port <0-255>
```

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

port

Set physical port/span/card number

<0-255>

E1/T1 Port/Span/Card number

### 1.8.6 e1\_line <0-255> socket .SOCKET

#### Command

```
e1_line <0-255> socket .SOCKET
```

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

socket

Set socket path for unixsocket

.SOCKET

socket path

### 1.8.7 ipa bind A.B.C.D

Command

```
ipa bind A.B.C.D
```

Parameters

ipa

ipa driver config

bind

Set ipa local bind address

A.B.C.D

Listen on this IP address (default 0.0.0.0)

### 1.8.8 no e1\_line <0-255> keepalive

Command

```
no e1_line <0-255> keepalive
```

Parameters

no

Negate a command or set its defaults

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

keepalive

Enable keep-alive probing

## 1.9 config-ctrl

### 1.9.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

**bind**

Set bind address to listen for Control connections

**A.B.C.D**

Local IP address (default 127.0.0.1)

## 1.10 config-net

### 1.10.1 auth policy (closed|accept-all|regex|token)

Command

```
auth policy (closed|accept-all|regex|token)
```

Parameters

**auth**

Authentication (not cryptographic)

**policy**

Set the GSM network authentication policy

**closed**

Require the MS to be activated in HLR

**accept-all**

Accept all MS, whether in HLR or not

**regex**

Use regular expression for IMSI authorization decision

**token**

Use SMS-token based authentication

---

### 1.10.2 authorized-regexp REGEXP

#### Command

```
authorized-regexp REGEXP
```

#### Parameters

##### authorized-regexp

Set regexp for IMSI which will be used for authorization decision

##### REGEXP

Regular expression, IMSIs matching it are allowed to use the network

### 1.10.3 bts <0-255>

#### Command

```
bts <0-255>
```

#### Parameters

##### bts

Select a BTS to configure

##### <0-255>

BTS Number

### 1.10.4 dyn\_ts\_allow\_tch\_f (0|1)

#### Command

```
dyn_ts_allow_tch_f (0|1)
```

#### Parameters

##### dyn\_ts\_allow\_tch\_f

Allow or disallow allocating TCH/F on TCH\_F\_TCH\_H\_PDCH timeslots

##### 0

Disallow TCH/F on TCH\_F\_TCH\_H\_PDCH (default)

##### 1

Allow TCH/F on TCH\_F\_TCH\_H\_PDCH

---

### 1.10.5 encryption a5 (0|1|2|3)

#### Command

```
encryption a5 (0|1|2|3)
```

#### Parameters

##### encryption

Encryption options

a5

A5 encryption

0

A5/0: No encryption

1

A5/1: Encryption

2

A5/2: Export-grade Encryption

3

A5/3: 'New' Secure Encryption

### 1.10.6 handover (0|1)

#### Command

```
handover (0|1)
```

#### Parameters

##### handover

Handover Options

0

Don't perform in-call handover

1

Perform in-call handover

### 1.10.7 handover maximum distance <0-9999>

#### Command

```
handover maximum distance <0-9999>
```

#### Parameters

---

handover

Handover Options

maximum

How big is the maximum timing advance before HO is forced

distance

Distance

<0-9999>

Number

### 1.10.8 handover power budget hysteresis <0-999>

Command

```
handover power budget hysteresis <0-999>
```

Parameters

handover

Handover Options

power

Power Budget

budget

How many dB does a neighbor to be stronger to become a HO candidate

hysteresis

Hysteresis

<0-999>

Number

### 1.10.9 handover power budget interval <1-99>

Command

```
handover power budget interval <1-99>
```

Parameters

handover

Handover Options

power

Power Budget

budget

How often to check if we have a better cell (SACCH frames)

interval

Interval

<1-99>

Number

### 1.10.10 handover window rxlev averaging <1-10>

#### Command

```
handover window rxlev averaging <1-10>
```

#### Parameters

handover

Handover Options

window

Measurement Window

rxlev

Received Level Averaging

averaging

How many RxLev measurements are used for averaging

<1-10>

Amount to use for Averaging

### 1.10.11 handover window rxlev neighbor averaging <1-10>

#### Command

```
handover window rxlev neighbor averaging <1-10>
```

#### Parameters

handover

Handover Options

window

Measurement Window

rxlev

Received Level Averaging

neighbor

Neighbor

averaging

How many RxQual measurements are used for averaging

<1-10>

Amount to use for Averaging

---

### 1.10.12 handover window rxqual averaging <1-10>

#### Command

```
handover window rxqual averaging <1-10>
```

#### Parameters

##### handover

Handover Options

##### window

Measurement Window

##### rxqual

Received Quality Averaging

##### averaging

How many RxQual measurements are used for averaging

##### <1-10>

Amount to use for Averaging

### 1.10.13 location updating reject cause <2-111>

#### Command

```
location updating reject cause <2-111>
```

#### Parameters

##### location

Set the reject cause of location updating reject

##### updating

Set the reject cause of location updating reject

##### reject

Set the reject cause of location updating reject

##### cause

Set the reject cause of location updating reject

##### <2-111>

Cause Value as Per GSM TS 04.08

---



### 1.10.14 long name NAME

#### Command

```
long name NAME
```

#### Parameters

long

Set the long GSM network name

name

Name Commands

NAME

Name to use

### 1.10.15 mm info (0|1)

#### Command

```
mm info (0|1)
```

#### Parameters

mm

Mobility Management

info

Send MM INFO after LOC UPD ACCEPT

0

Disable

1

Enable

### 1.10.16 mobile network code <0-999>

#### Command

```
mobile network code <0-999>
```

#### Parameters

mobile

Set the GSM mobile network code

network

Network Commands

code

Code commands

<0-999>

Mobile Network Code to use

---

### 1.10.17 neci (0|1)

#### Command

```
neci (0|1)
```

#### Parameters

neci

New Establish Cause Indication

0

Don't set the NECI bit

1

Set the NECI bit

### 1.10.18 network country code <1-999>

#### Command

```
network country code <1-999>
```

#### Parameters

network

Set the GSM network country code

country

Country commands

code

Code commands

<1-999>

Network Country Code to use

### 1.10.19 no timezone

#### Command

```
no timezone
```

#### Parameters

no

Negate a command or set its defaults

timezone

Disable network timezone override, use system tz

### 1.10.20 paging any use tch (0|1)

#### Command

```
paging any use tch (0|1)
```

#### Parameters

##### paging

Assign a TCH when receiving a Paging Any request

##### any

Any Channel

##### use

Use

##### tch

TCH

##### 0

Do not use TCH for Paging Request Any

##### 1

Do use TCH for Paging Request Any

### 1.10.21 rrlp mode (none|ms-based|ms-preferred|ass-preferred)

#### Command

```
rrlp mode (none|ms-based|ms-preferred|ass-preferred)
```

#### Parameters

##### rrlp

Radio Resource Location Protocol

##### mode

Set the Radio Resource Location Protocol Mode

##### none

Don't send RRLP request

##### ms-based

Request MS-based location

##### ms-preferred

Request any location, prefer MS-based

##### ass-preferred

Request any location, prefer MS-assisted

### 1.10.22 short name NAME

#### Command

```
short name NAME
```

#### Parameters

##### short

Set the short GSM network name

##### name

Name Commands

##### NAME

Name to use

### 1.10.23 subscriber-keep-in-ram (0|1)

#### Command

```
subscriber-keep-in-ram (0|1)
```

#### Parameters

##### subscriber-keep-in-ram

Keep unused subscribers in RAM.

##### 0

Delete unused subscribers

##### 1

Keep unused subscribers

### 1.10.24 timer t3101 (default|<1-65535>)

#### Command

```
timer t3101 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3101

Set the timeout value for IMMEDIATE ASSIGNMENT (default: 10 seconds)

##### default

Set to default timer value (10 seconds)

##### <1-65535>

Timer Value in seconds

---

### 1.10.25 timer t3103 (default|<1-65535>)

#### Command

```
timer t3103 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3103

Set the timeout value for HANDOVER (default: 5 seconds)

##### default

Set to default timer value (5 seconds)

##### <1-65535>

Timer Value in seconds

### 1.10.26 timer t3105 (default|<1-65535>)

#### Command

```
timer t3105 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3105

Set the timer for repetition of PHYSICAL INFORMATION (default: 100 seconds)

##### default

Set to default timer value (100 seconds)

##### <1-65535>

Timer Value in seconds

### 1.10.27 timer t3107 (default|<1-65535>)

#### Command

```
timer t3107 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

t3107

Currently not used (default: 5 seconds)

default

Set to default timer value (5 seconds)

<1-65535>

Timer Value in seconds

### 1.10.28 timer t3109 (default|<1-65535>)

Command

```
timer t3109 (default|<1-65535>)
```

Parameters

timer

Configure GSM Timers

t3109

Set the RSL SACCH deactivation timeout (default: 19 seconds)

default

Set to default timer value (19 seconds)

<1-65535>

Timer Value in seconds

### 1.10.29 timer t3111 (default|<1-65535>)

Command

```
timer t3111 (default|<1-65535>)
```

Parameters

timer

Configure GSM Timers

t3111

Set the RSL timeout to wait before releasing the RF Channel (default: 2 seconds)

default

Set to default timer value (2 seconds)

<1-65535>

Timer Value in seconds

### 1.10.30 timer t3113 (default|<1-65535>)

#### Command

```
timer t3113 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3113

Set the time to try paging a subscriber (default: 60 seconds)

##### default

Set to default timer value (60 seconds)

##### <1-65535>

Timer Value in seconds

### 1.10.31 timer t3115 (default|<1-65535>)

#### Command

```
timer t3115 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3115

Currently not used (default: 10 seconds)

##### default

Set to default timer value (10 seconds)

##### <1-65535>

Timer Value in seconds

### 1.10.32 timer t3117 (default|<1-65535>)

#### Command

```
timer t3117 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

t3117

Currently not used (default: 10 seconds)

default

Set to default timer value (10 seconds)

<1-65535>

Timer Value in seconds

### 1.10.33 timer t3119 (default|<1-65535>)

Command

```
timer t3119 (default|<1-65535>)
```

Parameters

timer

Configure GSM Timers

t3119

Currently not used (default: 10 seconds)

default

Set to default timer value (10 seconds)

<1-65535>

Timer Value in seconds

### 1.10.34 timer t3122 (default|<1-65535>)

Command

```
timer t3122 (default|<1-65535>)
```

Parameters

timer

Configure GSM Timers

t3122

Default waiting time (seconds) after IMM ASS REJECT (default: 10 seconds)

default

Set to default timer value (10 seconds)

<1-65535>

Timer Value in seconds



### 1.10.35 timer t3141 (default|<1-65535>)

#### Command

```
timer t3141 (default|<1-65535>)
```

#### Parameters

##### timer

Configure GSM Timers

##### t3141

Currently not used (default: 10 seconds)

##### default

Set to default timer value (10 seconds)

##### <1-65535>

Timer Value in seconds

### 1.10.36 timezone <-19-19> (0|15|30|45)

#### Command

```
timezone <-19-19> (0|15|30|45)
```

#### Parameters

##### timezone

Set the Timezone Offset of the network

##### <-19-19>

Timezone offset (hours)

##### 0

Timezone offset (00 minutes)

##### 15

Timezone offset (15 minutes)

##### 30

Timezone offset (30 minutes)

##### 45

Timezone offset (45 minutes)

### 1.10.37 **timezone** <-19-19> (0|15|30|45) <0-2>

#### Command

```
timezone <-19-19> (0|15|30|45) <0-2>
```

#### Parameters

##### timezone

Set the Timezone Offset of the network

##### <-19-19>

Timezone offset (hours)

##### 0

Timezone offset (00 minutes)

##### 15

Timezone offset (15 minutes)

##### 30

Timezone offset (30 minutes)

##### 45

Timezone offset (45 minutes)

##### <0-2>

DST offset (hours)

## 1.11 **config-net-bts**

### 1.11.1 **abis-lower-transport** (single-timeslot|super-channel)

#### Command

```
abis-lower-transport (single-timeslot|super-channel)
```

#### Parameters

##### abis-lower-transport

Configure thee Abis Lower Transport

##### single-timeslot

Single Timeslot (classic Abis)

##### super-channel

SuperChannel (Packet Abis)

### 1.11.2 access-control-class-ramping

#### Command

```
access-control-class-ramping
```

#### Parameters

access-control-class-ramping

Enable Access Control Class ramping

### 1.11.3 access-control-class-ramping-step-interval (<30-600>|dynamic)

#### Command

```
access-control-class-ramping-step-interval (<30-600>|dynamic)
```

#### Parameters

access-control-class-ramping-step-interval

Configure Access Control Class ramping step interval

<30-600>

Set a fixed step interval (in seconds)

dynamic

Use dynamic step interval based on BTS channel load

### 1.11.4 access-control-class-ramping-step-size (<1-10>)

#### Command

```
access-control-class-ramping-step-size (<1-10>)
```

#### Parameters

access-control-class-ramping-step-size

Configure Access Control Class ramping step size

<1-10>

Set the number of Access Control Classes to enable per ramping step

---

### 1.11.5 amr tch-f hysteresis (ms|bts) <0-15>

#### Command

```
amr tch-f hysteresis (ms|bts) <0-15>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

### 1.11.6 amr tch-f hysteresis (ms|bts) <0-15> <0-15>

#### Command

```
amr tch-f hysteresis (ms|bts) <0-15> <0-15>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

### 1.11.7 amr tch-f hysteresis (ms|bts) <0-15> <0-15> <0-15>

#### Command

```
amr tch-f hysteresis (ms|bts) <0-15> <0-15> <0-15>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

### 1.11.8 amr tch-f modes (0|1|2|3|4|5|6|7)

#### Command

```
amr tch-f modes (0|1|2|3|4|5|6|7)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

modes

Codec modes to use with AMR codec

0

4,75k

1

5,15k

2	5,90k
3	6,70k
4	7,40k
5	7,95k
6	10,2k
7	12,2k

### 1.11.9 amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7)

#### Command

```
amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

modes

Codec modes to use with AMR codec

0	4,75k
1	5,15k
2	5,90k
3	6,70k
4	7,40k
5	7,95k
6	10,2k

7	12,2k
0	4,75k
1	5,15k
2	5,90k
3	6,70k
4	7,40k
5	7,95k
6	10,2k
7	12,2k

### 1.11.10 amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7)

#### Command

```
amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

modes

Codec modes to use with AMR codec

0	4,75k
1	5,15k
2	5,90k
3	6,70k

---

4	7,40k
5	7,95k
6	10,2k
7	12,2k
0	4,75k
1	5,15k
2	5,90k
3	6,70k
4	7,40k
5	7,95k
6	10,2k
7	12,2k
0	4,75k
1	5,15k
2	5,90k
3	6,70k
4	7,40k
5	7,95k
6	10,2k
7	12,2k

---



### 1.11.11 amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4...

#### Command

```
amr tch-f modes (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7) (0|1|2|3|4|5|6|7)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

modes

Codec modes to use with AMR codec

0

4,75k

1

5,15k

2

5,90k

3

6,70k

4

7,40k

5

7,95k

6

10,2k

7

12,2k

0

4,75k

1

5,15k

2

5,90k

3

6,70k

4

7,40k

- 
- 5  
7,95k
  - 6  
10,2k
  - 7  
12,2k
  - 0  
4,75k
  - 1  
5,15k
  - 2  
5,90k
  - 3  
6,70k
  - 4  
7,40k
  - 5  
7,95k
  - 6  
10,2k
  - 7  
12,2k
  - 0  
4,75k
  - 1  
5,15k
  - 2  
5,90k
  - 3  
6,70k
  - 4  
7,40k
  - 5  
7,95k
  - 6  
10,2k
  - 7  
12,2k
-

### 1.11.12 amr tch-f start-mode (auto|1|2|3|4)

#### Command

```
amr tch-f start-mode (auto|1|2|3|4)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

start-mode

Initial codec to use with AMR

auto

Automatically

1

First codec

2

Second codec

3

Third codec

4

Fourth codec

### 1.11.13 amr tch-f threshold (ms|bts) <0-63>

#### Command

```
amr tch-f threshold (ms|bts) <0-63>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

---

### 1.11.14 amr tch-f threshold (ms|bts) <0-63> <0-63>

#### Command

```
amr tch-f threshold (ms|bts) <0-63> <0-63>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

### 1.11.15 amr tch-f threshold (ms|bts) <0-63> <0-63> <0-63>

#### Command

```
amr tch-f threshold (ms|bts) <0-63> <0-63> <0-63>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-f

Full Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

### 1.11.16 amr tch-h hysteresis (ms|bts) <0-15>

Command

```
amr tch-h hysteresis (ms|bts) <0-15>
```

Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

### 1.11.17 amr tch-h hysteresis (ms|bts) <0-15> <0-15>

Command

```
amr tch-h hysteresis (ms|bts) <0-15> <0-15>
```

Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

### 1.11.18 amr tch-h hysteresis (ms|bts) <0-15> <0-15> <0-15>

Command

```
amr tch-h hysteresis (ms|bts) <0-15> <0-15> <0-15>
```

Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

hysteresis

AMR hysteresis between codecs

ms

MS side

bts

BTS side

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

<0-15>

Hysteresis between codec 1 and 2

### 1.11.19 amr tch-h modes (0|1|2|3|4|5)

Command

```
amr tch-h modes (0|1|2|3|4|5)
```

Parameters

amr

Adaptive Multi Rate settings

---

tch-h

Half Rate

modes

Codec modes to use with AMR codec

0

4,75k

1

5,15k

2

5,90k

3

6,70k

4

7,40k

5

7,95k

### 1.11.20 amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5)

Command

```
amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5)
```

Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

modes

Codec modes to use with AMR codec

0

4,75k

1

5,15k

2

5,90k

3

6,70k

4

7,40k

5  
7,95k  
0  
4,75k  
1  
5,15k  
2  
5,90k  
3  
6,70k  
4  
7,40k  
5  
7,95k

### 1.11.21 amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5)

#### Command

```
amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

modes

Codec modes to use with AMR codec

0  
4,75k  
1  
5,15k  
2  
5,90k  
3  
6,70k  
4  
7,40k  
5  
7,95k



0  
4,75k

1  
5,15k

2  
5,90k

3  
6,70k

4  
7,40k

5  
7,95k

0  
4,75k

1  
5,15k

2  
5,90k

3  
6,70k

4  
7,40k

5  
7,95k

### 1.11.22 amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5)

#### Command

```
amr tch-h modes (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5) (0|1|2|3|4|5)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

modes

Codec modes to use with AMR codec

0

4,75k

---

1  
5,15k

2  
5,90k

3  
6,70k

4  
7,40k

5  
7,95k

0  
4,75k

1  
5,15k

2  
5,90k

3  
6,70k

4  
7,40k

5  
7,95k

0  
4,75k

1  
5,15k

2  
5,90k

3  
6,70k

4  
7,40k

5  
7,95k

0  
4,75k

1  
5,15k

- 2  
5,90k
- 3  
6,70k
- 4  
7,40k
- 5  
7,95k

### 1.11.23 amr tch-h start-mode (auto|1|2|3|4)

#### Command

```
amr tch-h start-mode (auto|1|2|3|4)
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

start-mode

Initial codec to use with AMR

auto

Automatically

1

First codec

2

Second codec

3

Third codec

4

Fourth codec

### 1.11.24 amr tch-h threshold (ms|bts) <0-63>

#### Command

```
amr tch-h threshold (ms|bts) <0-63>
```

#### Parameters

---

amr

Adaptive Multi Rate settings

tch-h

Half Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

### 1.11.25 amr tch-h threshold (ms|bts) <0-63> <0-63>

Command

```
amr tch-h threshold (ms|bts) <0-63> <0-63>
```

Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

### 1.11.26 amr tch-h threshold (ms|bts) <0-63> <0-63> <0-63>

#### Command

```
amr tch-h threshold (ms|bts) <0-63> <0-63> <0-63>
```

#### Parameters

amr

Adaptive Multi Rate settings

tch-h

Half Rate

threshold

AMR threshold between codecs

ms

MS side

bts

BTS side

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

<0-63>

Threshold between codec 1 and 2

### 1.11.27 band BAND

#### Command

```
band BAND
```

#### Parameters

band

Set the frequency band of this BTS

BAND

Frequency band

### 1.11.28 base\_station\_id\_code <0-63>

#### Command

```
base_station_id_code <0-63>
```

#### Parameters

base\_station\_id\_code

Set the Base Station Identity Code (BSIC) of this BTS

<0-63>

BSIC of this BTS

### 1.11.29 cell\_bar\_qualify (0|1)

#### Command

```
cell_bar_qualify (0|1)
```

#### Parameters

cell

Cell Parameters

bar

Cell Bar Qualify

qualify

Cell Bar Qualify

0

Set CBQ to 0

1

Set CBQ to 1

### 1.11.30 cell\_barred (0|1)

#### Command

```
cell_barred (0|1)
```

#### Parameters

cell

Should this cell be barred from access?

barred

Should this cell be barred from access?

0

Cell should NOT be barred

1

Cell should be barred

### 1.11.31 cell reselection hysteresis <0-14>

#### Command

```
cell reselection hysteresis <0-14>
```

#### Parameters

cell

Cell Parameters

reselection

Cell re-selection parameters

hysteresis

Cell Re-Selection Hysteresis in dB

<0-14>

Cell Re-Selection Hysteresis in dB

### 1.11.32 cell reselection offset <0-126>

#### Command

```
cell reselection offset <0-126>
```

#### Parameters

cell

Cell Parameters

reselection

Cell Re-Selection Parameters

offset

Cell Re-Selection Offset (CRO) in dB

<0-126>

Cell Re-Selection Offset (CRO) in dB

### 1.11.33 cell\_identity <0-65535>

#### Command

```
cell_identity <0-65535>
```

#### Parameters

cell\_identity

Set the Cell identity of this BTS

<0-65535>

Cell Identity

---

### 1.11.34 channel allocator (ascending|descending)

#### Command

```
channel allocator (ascending|descending)
```

#### Parameters

##### channel

Channel Allocator

##### allocator

Channel Allocator

##### ascending

Allocate Timeslots and Transceivers in ascending order

##### descending

Allocate Timeslots and Transceivers in descending order

### 1.11.35 channel-description attach (0|1)

#### Command

```
channel-description attach (0|1)
```

#### Parameters

##### channel-description

Channel Description

##### attach

Set if attachment is required

##### 0

Attachment is NOT required

##### 1

Attachment is required (standard)

### 1.11.36 channel-description bs-ag-blks-res <0-7>

#### Command

```
channel-description bs-ag-blks-res <0-7>
```

#### Parameters

##### channel-description

Channel Description

##### bs-ag-blks-res

Set number of blocks reserved for access grant

##### <0-7>

Number of blocks reserved for access grant

---



### 1.11.37 channel-description bs-pa-mfrms <2-9>

#### Command

```
channel-description bs-pa-mfrms <2-9>
```

#### Parameters

channel-description

Channel Description

bs-pa-mfrms

Set number of multiframe periods for paging groups

<2-9>

Number of multiframe periods for paging groups

### 1.11.38 codec-support fr

#### Command

```
codec-support fr
```

#### Parameters

codec-support

Codec Support settings

fr

Fullrate

### 1.11.39 codec-support fr (hr|efr|amr)

#### Command

```
codec-support fr (hr|efr|amr)
```

#### Parameters

codec-support

Codec Support settings

fr

Fullrate

hr

Half Rate

efr

Enhanced Full Rate

amr

Adaptive Multirate

---

### 1.11.40 codec-support fr (hr|efr|amr) (hr|efr|amr)

#### Command

```
codec-support fr (hr|efr|amr) (hr|efr|amr)
```

#### Parameters

codec-support

Codec Support settings

fr

Fullrate

hr

Half Rate

efr

Enhanced Full Rate

amr

Adaptive Multirate

hr

Half Rate

efr

Enhanced Full Rate

amr

Adaptive Multirate

### 1.11.41 codec-support fr (hr|efr|amr) (hr|efr|amr) (hr|efr|amr)

#### Command

```
codec-support fr (hr|efr|amr) (hr|efr|amr) (hr|efr|amr)
```

#### Parameters

codec-support

Codec Support settings

fr

Fullrate

hr

Half Rate

efr

Enhanced Full Rate

amr

Adaptive Multirate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

### 1.11.42 **codec-support fr (hr|efr|amr) (hr|efr|amr) (hr|efr|amr) (hr|efr|amr)**

Command

```
codec-support fr (hr|efr|amr) (hr|efr|amr) (hr|efr|amr) (hr|efr|amr)
```

Parameters

codec-support  
Codec Support settings

fr  
Fullrate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

hr  
Half Rate

efr  
Enhanced Full Rate

amr  
Adaptive Multirate

### 1.11.43 con-connection-group <1-31>

#### Command

```
con-connection-group <1-31>
```

#### Parameters

con-connection-group  
Configure a CON (Concentrator) Connection Group

<1-31>  
CON Connection Group Number

### 1.11.44 del-connection-group <1-31>

#### Command

```
del-connection-group <1-31>
```

#### Parameters

del-connection-group  
Delete a CON (Concentrator) Connection Group

<1-31>  
CON Connection Group Number

### 1.11.45 depends-on-bts <0-255>

#### Command

```
depends-on-bts <0-255>
```

#### Parameters

depends-on-bts  
This BTS can only be started if another one is up

<0-255>  
BTS Number

### 1.11.46 **depeneds-on-bts <0-255>**

#### Command

```
depeneds-on-bts <0-255>
```

#### Parameters

##### depeneds-on-bts

Negate a command or set its defaults

##### <0-255>

This BTS can only be started if another one is up

### 1.11.47 **description .TEXT**

#### Command

```
description .TEXT
```

#### Parameters

##### description

Save human-readable description of the object

##### .TEXT

Text until the end of the line

### 1.11.48 **dtx downlink**

#### Command

```
dtx downlink
```

#### Parameters

##### dtx

Configure discontinuous transmission

##### downlink

Enable Downlink DTX for this BTS

---

### 1.11.49 dtx uplink [force]

#### Command

```
dtx uplink [force]
```

#### Parameters

dtx

Configure discontinuous transmission

uplink

Enable Uplink DTX for this BTS

[force]

MS 'shall' use DTXu instead of 'may' use (might not be supported by older phones).

### 1.11.50 early-classmark-sending (allowed|forbidden)

#### Command

```
early-classmark-sending (allowed|forbidden)
```

#### Parameters

early-classmark-sending

Early Classmark Sending

allowed

Early Classmark Sending is allowed

forbidden

Early Classmark Sending is forbidden

### 1.11.51 early-classmark-sending-3g (allowed|forbidden)

#### Command

```
early-classmark-sending-3g (allowed|forbidden)
```

#### Parameters

early-classmark-sending-3g

3G Early Classmark Sending

allowed

3G Early Classmark Sending is allowed

forbidden

3G Early Classmark Sending is forbidden

### 1.11.52 force-combined-si

#### Command

```
force-combined-si
```

#### Parameters

force-combined-si

Force the generation of a single SI (no ter/bis)

### 1.11.53 gprs 11bit\_rach\_support\_for\_egprs (0|1)

#### Command

```
gprs 11bit_rach_support_for_egprs (0|1)
```

#### Parameters

gprs

GPRS Packet Network

11bit\_rach\_support\_for\_egprs

11 bit RACH options

0

Disable 11 bit RACH for EGPRS

1

Enable 11 bit RACH for EGPRS

### 1.11.54 gprs cell bvci <2-65535>

#### Command

```
gprs cell bvci <2-65535>
```

#### Parameters

gprs

GPRS Packet Network

cell

GPRS Cell Settings

bvci

GPRS BSSGP VC Identifier

<2-65535>

GPRS BSSGP VC Identifier

---

### 1.11.55 gprs cell timer (blocking-timer|blocking-retries|unblocking-retries|reset-timer|...

#### Command

```
gprs cell timer (blocking-timer|blocking-retries|unblocking-retries|reset-timer|reset- ↵
retries|suspend-timer|suspend-retries|resume-timer|resume-retries|capability-update ↵
-timer|capability-update-retries) <0-255>
```

#### Parameters

##### gprs

GPRS Packet Network

##### cell

Cell / BSSGP

##### timer

Cell/BSSGP Timer

##### blocking-timer

Tbvc-block timeout

##### blocking-retries

Tbvc-block retries

##### unblocking-retries

Tbvc-unblock retries

##### reset-timer

Tbvcc-reset timeout

##### reset-retries

Tbvc-reset retries

##### suspend-timer

Tbvc-suspend timeout

##### suspend-retries

Tbvc-suspend retries

##### resume-timer

Tbvc-resume timeout

##### resume-retries

Tbvc-resume retries

##### capability-update-timer

Tbvc-capa-update timeout

##### capability-update-retries

Tbvc-capa-update retries

##### <0-255>

Timer Value



### 1.11.56 gprs control-ack-type-rach

#### Command

```
gprs control-ack-type-rach
```

#### Parameters

gprs

GPRS Packet Network

control-ack-type-rach

Set GPRS Control Ack Type for PACKET CONTROL ACKNOWLEDGMENT message to four access bursts format instead of default RLC/MAC control block

### 1.11.57 gprs mode (none|gprs|egprs)

#### Command

```
gprs mode (none|gprs|egprs)
```

#### Parameters

gprs

GPRS Packet Network

mode

GPRS Mode for this BTS

none

GPRS Disabled on this BTS

gprs

GPRS Enabled on this BTS

egprs

EGPRS (EDGE) Enabled on this BTS

### 1.11.58 gprs network-control-order (nc0|nc1|nc2)

#### Command

```
gprs network-control-order (nc0|nc1|nc2)
```

#### Parameters

gprs

GPRS Packet Network

network-control-order

GPRS Network Control Order

nc0

MS controlled cell re-selection, no measurement reporting

nc1

MS controlled cell re-selection, MS sends measurement reports

nc2

Network controlled cell re-selection, MS sends measurement reports

### 1.11.59 gprs ns timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|...

Command

```
gprs ns timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns- ↵  
alive|tns-alive-retries|tsns-prov) <0-255>
```

Parameters

gprs

GPRS Packet Network

ns

Network Service

timer

Network Service Timer

tns-block

(un)blocking Timer (Tns-block) timeout

tns-block-retries

(un)blocking Timer (Tns-block) number of retries

tns-reset

Reset Timer (Tns-reset) timeout

tns-reset-retries

Reset Timer (Tns-reset) number of retries

tns-test

Test Timer (Tns-test) timeout

tns-alive

Alive Timer (Tns-alive) timeout

tns-alive-retries

Alive Timer (Tns-alive) number of retries

tsns-prov

SNS Provision Timer (Tsns-prov) timeout

<0-255>

Timer Value

### 1.11.60 gprs nsei <0-65535>

#### Command

```
gprs nsei <0-65535>
```

#### Parameters

gprs

GPRS Packet Network

nsei

GPRS NS Entity Identifier

<0-65535>

GPRS NS Entity Identifier

### 1.11.61 gprs nsvc <0-1> local udp port <0-65535>

#### Command

```
gprs nsvc <0-1> local udp port <0-65535>
```

#### Parameters

gprs

GPRS Packet Network

nsvc

Network Service Virtual Connection (NS-VC)

<0-1>

NSVC Logical Number

local

GPRS NS Local UDP Port

udp

GPRS NS Local UDP Port

port

GPRS NS Local UDP Port

<0-65535>

GPRS NS Local UDP Port Number

---

### 1.11.62 gprs nsvc <0-1> nsvci <0-65535>

#### Command

```
gprs nsvc <0-1> nsvci <0-65535>
```

#### Parameters

##### gprs

GPRS Packet Network

##### nsvc

Network Service Virtual Connection (NS-VC)

##### <0-1>

NSVC Logical Number

##### nsvci

NS Virtual Connection Identifier

##### <0-65535>

GPRS NS VC Identifier

### 1.11.63 gprs nsvc <0-1> remote ip A.B.C.D

#### Command

```
gprs nsvc <0-1> remote ip A.B.C.D
```

#### Parameters

##### gprs

GPRS Packet Network

##### nsvc

Network Service Virtual Connection (NS-VC)

##### <0-1>

NSVC Logical Number

##### remote

GPRS NS Remote IP Address

##### ip

GPRS NS Remote IP Address

##### A.B.C.D

GPRS NS Remote IP Address

### 1.11.64 gprs nsvc <0-1> remote udp port <0-65535>

#### Command

```
gprs nsvc <0-1> remote udp port <0-65535>
```

#### Parameters

gprs

GPRS Packet Network

nsvc

Network Service Virtual Connection (NS-VC)

<0-1>

NSVC Logical Number

remote

GPRS NS Remote UDP Port

udp

GPRS NS Remote UDP Port

port

GPRS NS Remote UDP Port

<0-65535>

GPRS NS Remote UDP Port Number

### 1.11.65 gprs routing area <0-255>

#### Command

```
gprs routing area <0-255>
```

#### Parameters

gprs

GPRS Packet Network

routing

GPRS Routing Area Code

area

GPRS Routing Area Code

<0-255>

GPRS Routing Area Code

### 1.11.66 ip.access rsl-ip A.B.C.D

#### Command

```
ip.access rsl-ip A.B.C.D
```

#### Parameters

##### ip.access

Abis/IP specific options

##### rsl-ip

Set the IPA RSL IP Address of the BSC

##### A.B.C.D

Destination IP address for RSL connection

### 1.11.67 ip.access unit\_id <0-65534> <0-255>

#### Command

```
ip.access unit_id <0-65534> <0-255>
```

#### Parameters

##### ip.access

Abis/IP specific options

##### unit\_id

Set the IPA BTS Unit ID

##### <0-65534>

Unit ID (Site)

##### <0-255>

Unit ID (BTS)

### 1.11.68 is-connection-list (add|del) <0-2047> <0-2047> <0-255>

#### Command

```
is-connection-list (add|del) <0-2047> <0-2047> <0-255>
```

#### Parameters

##### is-connection-list

Interface Switch Connection List

##### add

Add to IS list

del

Delete from IS list

<0-2047>

ICP1

<0-2047>

ICP2

<0-255>

Contiguity Index

### 1.11.69 location\_area\_code <0-65535>

Command

```
location_area_code <0-65535>
```

Parameters

location\_area\_code

Set the Location Area Code (LAC) of this BTS

<0-65535>

LAC

### 1.11.70 ms max power <0-40>

Command

```
ms max power <0-40>
```

Parameters

ms

MS Options

max

Maximum transmit power of the MS

power

Maximum transmit power of the MS

<0-40>

Maximum transmit power of the MS in dBm

---

### 1.11.71 neighbor-list (add|del) arfcn <0-1023>

#### Command

```
neighbor-list (add|del) arfcn <0-1023>
```

#### Parameters

neighbor-list

Neighbor List

add

Add to manual neighbor list

del

Delete from manual neighbor list

arfcn

ARFCN of neighbor

<0-1023>

ARFCN of neighbor

### 1.11.72 neighbor-list mode (automatic|manual|manual-si5)

#### Command

```
neighbor-list mode (automatic|manual|manual-si5)
```

#### Parameters

neighbor-list

Neighbor List

mode

Mode of Neighbor List generation

automatic

Automatically from all BTS in this OpenBSC

manual

Manual

manual-si5

Manual with different lists for SI2 and SI5



### 1.11.73 no access-control-class-ramping

#### Command

```
no access-control-class-ramping
```

#### Parameters

no

Negate a command or set its defaults

access-control-class-ramping

Disable Access Control Class ramping

### 1.11.74 no description

#### Command

```
no description
```

#### Parameters

no

Negate a command or set its defaults

description

Remove description of the object

### 1.11.75 no dtx downlink

#### Command

```
no dtx downlink
```

#### Parameters

no

Negate a command or set its defaults

dtx

Configure discontinuous transmission

downlink

Disable Downlink DTX for this BTS

---

### 1.11.76 no dtx uplink

#### Command

```
no dtx uplink
```

#### Parameters

no

Negate a command or set its defaults

dtx

Configure discontinuous transmission

uplink

Disable Uplink DTX for this BTS

### 1.11.77 no force-combined-si

#### Command

```
no force-combined-si
```

#### Parameters

no

Negate a command or set its defaults

force-combined-si

Force the generation of a single SI (no ter/bis)

### 1.11.78 no gprs control-ack-type-rach

#### Command

```
no gprs control-ack-type-rach
```

#### Parameters

no

Negate a command or set its defaults

gprs

GPRS Packet Network

control-ack-type-rach

Set GPRS Control Ack Type for PACKET CONTROL ACKNOWLEDGMENT message to four access bursts format instead of default RLC/MAC control block

---

### 1.11.79 no periodic location update

#### Command

```
no periodic location update
```

#### Parameters

no

Negate a command or set its defaults

periodic

Periodic Location Updating Interval

location

Periodic Location Updating Interval

update

Periodic Location Updating Interval

### 1.11.80 no rf-lock-exclude

#### Command

```
no rf-lock-exclude
```

#### Parameters

no

Negate a command or set its defaults

rf-lock-exclude

Exclude this BTS from the global RF Lock

### 1.11.81 nokia\_site bts-reset-timer <15-100>

#### Command

```
nokia_site bts-reset-timer <15-100>
```

#### Parameters

nokia\_site

Nokia \*Site related commands

bts-reset-timer

The amount of time (in sec.) between BTS\_RESET is sent,

<15-100>

and the BTS is being bootstrapped.

---

### 1.11.82 nokia\_site no-local-rel-conf (0|1)

#### Command

```
nokia_site no-local-rel-conf (0|1)
```

#### Parameters

##### nokia\_site

Nokia \*Site related commands

##### no-local-rel-conf

Do not wait for RELease CONFirm message when releasing channel locally

0

Wait for RELease CONFirm

1

Do not wait for RELease CONFirm

### 1.11.83 nokia\_site skip-reset (0|1)

#### Command

```
nokia_site skip-reset (0|1)
```

#### Parameters

##### nokia\_site

Nokia \*Site related commands

##### skip-reset

Skip the reset step during bootstrap process of this BTS

0

Do NOT skip the reset

1

Skip the reset

### 1.11.84 oml e1 line E1\_LINE timeslot <1-31> sub-slot (0|1|2|3|full)

#### Command

```
oml e1 line E1_LINE timeslot <1-31> sub-slot (0|1|2|3|full)
```

#### Parameters

##### oml

Organization & Maintenance Link

---

e1  
OML E1/T1 Configuration

line  
E1/T1 line number to be used for OML

E1\_LINE  
E1/T1 line number to be used for OML

timeslot  
E1/T1 timeslot to be used for OML

<1-31>  
E1/T1 timeslot to be used for OML

sub-slot  
E1/T1 sub-slot to be used for OML

0  
Use E1/T1 sub-slot 0

1  
Use E1/T1 sub-slot 1

2  
Use E1/T1 sub-slot 2

3  
Use E1/T1 sub-slot 3

full  
Use full E1 slot 3

### 1.11.85 oml e1 tei <0-63>

#### Command

```
oml e1 tei <0-63>
```

#### Parameters

oml  
Organization & Maintenance Link

e1  
OML E1/T1 Configuration

tei  
Set the TEI to be used for OML

<0-63>  
TEI Number

### 1.11.86 oml ip.access stream\_id <0-255> line E1\_LINE

#### Command

```
oml ip.access stream_id <0-255> line E1_LINE
```

#### Parameters

oml

Organization & Maintenance Link

ip.access

A-bis/IP Specific Options

stream\_id

Set the ip.access Stream ID of the OML link of this BTS

<0-255>

Stream Identifier

line

Virtual E1 Line Number

E1\_LINE

Virtual E1 Line Number

### 1.11.87 paging free <-1-1024>

#### Command

```
paging free <-1-1024>
```

#### Parameters

paging

Paging options

free

Only page when having a certain amount of free slots

<-1-1024>

amount of required free paging slots. -1 to disable

### 1.11.88 pcu-socket PATH

#### Command

```
pcu-socket PATH
```

#### Parameters

pcu-socket

PCU Socket Path for using OsmoPCU co-located with BSC (legacy BTS)

PATH

Path in the file system for the unix-domain PCU socket

---

### 1.11.89 penalty time <20-620>

#### Command

```
penalty time <20-620>
```

#### Parameters

##### penalty

Cell selection penalty time

##### time

Cell selection penalty time

##### <20-620>

Cell selection penalty time in seconds (by 20s increments)

### 1.11.90 penalty time reserved

#### Command

```
penalty time reserved
```

#### Parameters

##### penalty

Cell selection penalty time

##### time

Cell selection penalty time

##### reserved

Set cell selection penalty time to reserved value 31, (indicate that CELL\_RESELECT\_OFFSET is subtracted from C2 and TEMPORARY\_OFFSET is ignored)

### 1.11.91 periodic location update <6-1530>

#### Command

```
periodic location update <6-1530>
```

#### Parameters

##### periodic

Periodic Location Updating Interval

##### location

Periodic Location Updating Interval

##### update

Periodic Location Updating Interval

##### <6-1530>

Periodic Location Updating Interval in Minutes

---

### 1.11.92 rach access-control-class (0|1|2|3|4|5|6|7|8|9|11|12|13|14|15) (barred|allowed)

#### Command

```
rach access-control-class (0|1|2|3|4|5|6|7|8|9|11|12|13|14|15) (barred|allowed)
```

#### Parameters

##### rach

Random Access Control Channel

##### access-control-class

Set access control class

0

Access control class 0

1

Access control class 1

2

Access control class 2

3

Access control class 3

4

Access control class 4

5

Access control class 5

6

Access control class 6

7

Access control class 7

8

Access control class 8

9

Access control class 9

11

Access control class 11 for PLMN use

12

Access control class 12 for security services

13

Access control class 13 for public utilities (e.g. water/gas suppliers)

14

Access control class 14 for emergency services



15

Access control class 15 for PLMN staff

barred

barred to use access control class

allowed

allowed to use access control class

### 1.11.93 rach emergency call allowed (0|1)

Command

```
rach emergency call allowed (0|1)
```

Parameters

rach

Random Access Control Channel

emergency

Should this cell allow emergency calls?

call

Should this cell allow emergency calls?

allowed

Should this cell allow emergency calls?

0

Do NOT allow emergency calls

1

Allow emergency calls

### 1.11.94 rach max transmission (1|2|4|7)

Command

```
rach max transmission (1|2|4|7)
```

Parameters

rach

Random Access Control Channel

max

Set the maximum number of RACH burst transmissions

transmission

Set the maximum number of RACH burst transmissions

---

- 1  
Maximum number of 1 RACH burst transmissions
- 2  
Maximum number of 2 RACH burst transmissions
- 4  
Maximum number of 4 RACH burst transmissions
- 7  
Maximum number of 7 RACH burst transmissions

### 1.11.95 rach nm busy threshold <0-255>

#### Command

```
rach nm busy threshold <0-255>
```

#### Parameters

##### rach

Random Access Control Channel

##### nm

Network Management

##### busy

Set the NM Busy Threshold

##### threshold

Set the NM Busy Threshold

##### <0-255>

NM Busy Threshold in dB

### 1.11.96 rach nm load average <0-65535>

#### Command

```
rach nm load average <0-65535>
```

#### Parameters

##### rach

Random Access Control Channel

##### nm

Network Management

##### load

Set the NM Loadaverage Slots value

##### average

Set the NM Loadaverage Slots value

##### <0-65535>

NM Loadaverage Slots value

### 1.11.97 rach tx integer <0-15>

#### Command

```
rach tx integer <0-15>
```

#### Parameters

##### rach

Random Access Control Channel

##### tx

Set the raw tx integer value in RACH Control parameters IE

##### integer

Set the raw tx integer value in RACH Control parameters IE

##### <0-15>

Raw tx integer value in RACH Control parameters IE

### 1.11.98 radio-link-timeout <4-64>

#### Command

```
radio-link-timeout <4-64>
```

#### Parameters

##### radio-link-timeout

Radio link timeout criterion (BTS side)

##### <4-64>

Radio link timeout value (lost SACCH block)

### 1.11.99 radio-link-timeout infinite

#### Command

```
radio-link-timeout infinite
```

#### Parameters

##### radio-link-timeout

Radio link timeout criterion (BTS side)

##### infinite

Infinite Radio link timeout value (use only for BTS RF testing)

### 1.11.100 rf-lock-exclude

#### Command

```
rf-lock-exclude
```

#### Parameters

##### rf-lock-exclude

Exclude this BTS from the global RF Lock

### 1.11.101 rxlev access min <0-63>

#### Command

```
rxlev access min <0-63>
```

#### Parameters

##### rxlev

Minimum RxLev needed for cell access

##### access

Minimum RxLev needed for cell access

##### min

Minimum RxLev needed for cell access

##### <0-63>

Minimum RxLev needed for cell access (better than -110dBm)

### 1.11.102 si2quarter neighbor-list add earfcn <0-65535> thresh-hi <0-31> thresh-lo <0-32> p...

#### Command

```
si2quarter neighbor-list add earfcn <0-65535> thresh-hi <0-31> thresh-lo <0-32> prio ←  
<0-8> qrxlv <0-32> meas <0-8>
```

#### Parameters

##### si2quarter

SI2quarter Neighbor List

##### neighbor-list

SI2quarter Neighbor List

##### add

Add to manual SI2quarter neighbor list

##### earfcn

EARFCN of neighbor

<0-65535>

EARFCN of neighbor

thresh-hi

threshold high bits

<0-31>

threshold high bits

thresh-lo

threshold low bits

<0-32>

threshold low bits (32 means NA)

prio

priority

<0-8>

priority (8 means NA)

qrxlv

QRXLEVMIN

<0-32>

QRXLEVMIN (32 means NA)

meas

measurement bandwidth

<0-8>

measurement bandwidth (8 means NA)

### 1.11.103 si2quater neighbor-list add uarfcn <0-16383> <0-511> <0-1>

Command

```
si2quater neighbor-list add uarfcn <0-16383> <0-511> <0-1>
```

Parameters

si2quater

SI2quater Neighbor List

neighbor-list

SI2quater Neighbor List

add

Add to manual SI2quater neighbor list

uarfcn

UARFCN of neighbor

<0-16383>

UARFCN of neighbor

<0-511>

scrambling code

<0-1>

diversity bit

### 1.11.104 si2quater neighbor-list del earfcn <0-65535>

Command

```
si2quater neighbor-list del earfcn <0-65535>
```

Parameters

si2quater

SI2quater Neighbor List

neighbor-list

SI2quater Neighbor List

del

Delete from SI2quater manual neighbor list

earfcn

EARFCN of neighbor

<0-65535>

EARFCN

### 1.11.105 si2quater neighbor-list del uarfcn <0-16383> <0-511>

Command

```
si2quater neighbor-list del uarfcn <0-16383> <0-511>
```

Parameters

si2quater

SI2quater Neighbor List

neighbor-list

SI2quater Neighbor List

del

Delete from SI2quater manual neighbor list

uarfcn

UARFCN of neighbor

<0-16383>

UARFCN

<0-511>

scrambling code

---

### 1.11.106 si5 neighbor-list (add|del) arfcn <0-1023>

#### Command

```
si5 neighbor-list (add|del) arfcn <0-1023>
```

#### Parameters

si5

SI5 Neighbor List

neighbor-list

SI5 Neighbor List

add

Add to manual SI5 neighbor list

del

Delete from SI5 manual neighbor list

arfcn

ARFCN of neighbor

<0-1023>

ARFCN of neighbor

### 1.11.107 system-information (1|2|3|4|5|6|7|8|9|10|13|16|17|18|19|20|2bis|2ter|2quater|5bi...

#### Command

```
system-information (1|2|3|4|5|6|7|8|9|10|13|16|17|18|19|20|2bis|2ter|2quater|5bis|5ter) ←  
mode (static|computed)
```

#### Parameters

system-information

System Information Messages

1

System Information Type 1

2

System Information Type 2

3

System Information Type 3

4

System Information Type 4

5

System Information Type 5

---

6  
System Information Type 6

7  
System Information Type 7

8  
System Information Type 8

9  
System Information Type 9

10  
System Information Type 10

13  
System Information Type 13

16  
System Information Type 16

17  
System Information Type 17

18  
System Information Type 18

19  
System Information Type 19

20  
System Information Type 20

2bis  
System Information Type 2bis

2ter  
System Information Type 2ter

2quater  
System Information Type 2quater

5bis  
System Information Type 5bis

5ter  
System Information Type 5ter

mode  
System Information Mode

static  
Static user-specified

computed  
Dynamic, BSC-computed

---



### 1.11.108 system-information (1|2|3|4|5|6|7|8|9|10|13|16|17|18|19|20|2bis|2ter|2quater|5bi...

#### Command

```
system-information (1|2|3|4|5|6|7|8|9|10|13|16|17|18|19|20|2bis|2ter|2quater|5bis|5ter) ↔  
static HEXSTRING
```

#### Parameters

##### system-information

System Information Messages

1

System Information Type 1

2

System Information Type 2

3

System Information Type 3

4

System Information Type 4

5

System Information Type 5

6

System Information Type 6

7

System Information Type 7

8

System Information Type 8

9

System Information Type 9

10

System Information Type 10

13

System Information Type 13

16

System Information Type 16

17

System Information Type 17

18

System Information Type 18

19

System Information Type 19

20  
System Information Type 20

2bis  
System Information Type 2bis

2ter  
System Information Type 2ter

2quarter  
System Information Type 2quarter

5bis  
System Information Type 5bis

5ter  
System Information Type 5ter

static  
Static System Information filling

HEXSTRING  
Static user-specified SI content in HEX notation

### 1.11.109 temporary offset <0-60>

Command

```
temporary offset <0-60>
```

Parameters

temporary

Cell selection temporary negative offset

offset

Cell selection temporary negative offset

<0-60>

Cell selection temporary negative offset in dB

### 1.11.110 temporary offset infinite

Command

```
temporary offset infinite
```

Parameters

temporary

Cell selection temporary negative offset

offset

Cell selection temporary negative offset

infinite

Sets cell selection temporary negative offset to infinity

### 1.11.111 **trx <0-255>**

#### Command

```
trx <0-255>
```

#### Parameters

trx

Radio Transceiver

<0-255>

Select a TRX to configure

### 1.11.112 **type (unknown|bs11|nanobts|rbs2000|nokia\_site|sysmobts)**

#### Command

```
type (unknown|bs11|nanobts|rbs2000|nokia_site|sysmobts)
```

#### Parameters

type

BTS Vendor/Type

unknown

Unknown BTS Type

bs11

Siemens BTS (BS-11 or compatible)

nanobts

ip.access nanoBTS or compatible

rbs2000

Ericsson RBS2000 Series

nokia\_site

Nokia {Metro,Ultra,In}Site

sysmobts

sysmocom sysmoBTS

## 1.12 **config-net-bts-trx**

### 1.12.1 **arfcn <0-1023>**

#### Command

```
arfcn <0-1023>
```

## Parameters

### arfcn

Set the ARFCN for this TRX

<0-1023>

Absolute Radio Frequency Channel Number

## 1.12.2 description .TEXT

### Command

```
description .TEXT
```

## Parameters

### description

Save human-readable description of the object

.TEXT

Text until the end of the line

## 1.12.3 max\_power\_red <0-100>

### Command

```
max_power_red <0-100>
```

## Parameters

### max\_power\_red

Reduction of maximum BS RF Power (relative to nominal power)

<0-100>

Reduction of maximum BS RF Power in dB

## 1.12.4 no description

### Command

```
no description
```

## Parameters

### no

Negate a command or set its defaults

### description

Remove description of the object

---

### 1.12.5 nominal power <0-100>

#### Command

```
nominal power <0-100>
```

#### Parameters

##### nominal

Nominal TRX RF Power in dBm

##### power

Nominal TRX RF Power in dBm

##### <0-100>

Nominal TRX RF Power in dBm

### 1.12.6 rf\_locked (0|1)

#### Command

```
rf_locked (0|1)
```

#### Parameters

##### rf\_locked

Set or unset the RF Locking (Turn off RF of the TRX)

0

TRX is NOT RF locked (active)

1

TRX is RF locked (turned off)

### 1.12.7 rsl e1 line E1\_LINE timeslot <1-31> sub-slot (0|1|2|3|full)

#### Command

```
rsl e1 line E1_LINE timeslot <1-31> sub-slot (0|1|2|3|full)
```

#### Parameters

##### rsl

RSL Parameters

##### e1

E1/T1 interface to be used for RSL

##### line

E1/T1 interface to be used for RSL

---

**E1\_LINE**

E1/T1 Line Number to be used for RSL

**timeslot**

E1/T1 Timeslot to be used for RSL

**<1-31>**

E1/T1 Timeslot to be used for RSL

**sub-slot**

E1/T1 Sub-slot to be used for RSL

**0**

E1/T1 Sub-slot 0 is to be used for RSL

**1**

E1/T1 Sub-slot 1 is to be used for RSL

**2**

E1/T1 Sub-slot 2 is to be used for RSL

**3**

E1/T1 Sub-slot 3 is to be used for RSL

**full**

E1/T1 full timeslot is to be used for RSL

**1.12.8 rsl e1 tei <0-63>****Command**

```
rsl e1 tei <0-63>
```

**Parameters****rsl**

RSL Parameters

**e1**

Set the TEI to be used for RSL

**tei**

Set the TEI to be used for RSL

**<0-63>**

TEI to be used for RSL

### 1.12.9 timeslot <0-7>

#### Command

```
timeslot <0-7>
```

#### Parameters

##### timeslot

Select a Timeslot to configure

##### <0-7>

Timeslot number

## 1.13 config-net-bts-trx-ts

### 1.13.1 e1 line E1\_LINE timeslot <1-31> sub-slot (0|1|2|3|full)

#### Command

```
e1 line E1_LINE timeslot <1-31> sub-slot (0|1|2|3|full)
```

#### Parameters

##### e1

E1/T1 channel connected to this on-air timeslot

##### line

E1/T1 channel connected to this on-air timeslot

##### E1\_LINE

E1/T1 line connected to this on-air timeslot

##### timeslot

E1/T1 timeslot connected to this on-air timeslot

##### <1-31>

E1/T1 timeslot connected to this on-air timeslot

##### sub-slot

E1/T1 sub-slot connected to this on-air timeslot

##### 0

E1/T1 sub-slot 0 connected to this on-air timeslot

##### 1

E1/T1 sub-slot 1 connected to this on-air timeslot

##### 2

E1/T1 sub-slot 2 connected to this on-air timeslot

##### 3

E1/T1 sub-slot 3 connected to this on-air timeslot

##### full

Full E1/T1 timeslot connected to this on-air timeslot

---

### 1.13.2 hopping arfcn add <0-1023>

#### Command

```
hopping arfcn add <0-1023>
```

#### Parameters

##### hopping

Configure frequency hopping

##### arfcn

Configure hopping ARFCN list

##### add

Add an entry to the hopping ARFCN list

##### <0-1023>

ARFCN

### 1.13.3 hopping arfcn del <0-1023>

#### Command

```
hopping arfcn del <0-1023>
```

#### Parameters

##### hopping

Configure frequency hopping

##### arfcn

Configure hopping ARFCN list

##### del

Delete an entry to the hopping ARFCN list

##### <0-1023>

ARFCN

### 1.13.4 hopping enabled (0|1)

#### Command

```
hopping enabled (0|1)
```

#### Parameters

##### hopping

Configure frequency hopping



enabled

Enable or disable frequency hopping

0

Disable frequency hopping

1

Enable frequency hopping

### 1.13.5 hopping maio <0-63>

Command

```
hopping maio <0-63>
```

Parameters

hopping

Configure frequency hopping

maio

Which hopping MAIO to use for this channel

<0-63>

Mobile Allocation Index Offset (MAIO)

### 1.13.6 hopping sequence-number <0-63>

Command

```
hopping sequence-number <0-63>
```

Parameters

hopping

Configure frequency hopping

sequence-number

Which hopping sequence to use for this channel

<0-63>

Hopping Sequence Number (HSN)

### 1.13.7 phys\_chan\_config (none|ccch|ccch+sdccch4|tch/f|tch/h|sdccch8|pdch|tch/f\_pdch|unkno...

#### Command

```
phys_chan_config (none|ccch|ccch+sdccch4|tch/f|tch/h|sdccch8|pdch|tch/f_pdch|unknown|ccch ↔
+sdccch4+cbch|sdccch8+cbch|tch/f_tch/h_pdch)
```

#### Parameters

##### phys\_chan\_config

Physical Channel Combination

##### none

Physical Channel not configured

##### ccch

FCCH + SCH + BCCH + CCCH (Comb. IV)

##### ccch+sdccch4

FCCH + SCH + BCCH + CCCH + 4 SDCCH + 2 SACCH (Comb. V)

##### tch/f

TCH/F + FACCH/F + SACCH (Comb. I)

##### tch/h

2 TCH/H + 2 FACCH/H + 2 SACCH (Comb. II)

##### sdccch8

8 SDCCH + 4 SACCH (Comb. VII)

##### pdch

Packet Data Channel for GPRS/EDGE

##### tch/f\_pdch

Dynamic TCH/F or GPRS PDCH

##### unknown

Unknown / Unsupported channel combination

##### ccch+sdccch4+cbch

FCCH + SCH + BCCH + CCCH + CBCH + 3 SDCCH + 2 SACCH (Comb. V)

##### sdccch8+cbch

7 SDCCH + 4 SACCH + CBCH (Comb. VII)

##### tch/f\_tch/h\_pdch

Dynamic TCH/F or TCH/H or GPRS PDCH

### 1.13.8 training\_sequence\_code <0-7>

#### Command

```
training_sequence_code <0-7>
```

#### Parameters

training\_sequence\_code

Training Sequence Code of the Timeslot

<0-7>

TSC

## 1.14 oml

### 1.14.1 change-adm-state (locked|unlocked|shutdown|null)

#### Command

```
change-adm-state (locked|unlocked|shutdown|null)
```

#### Parameters

change-adm-state

Change the Administrative State

locked

Locked

unlocked

Unlocked

shutdown

Shutdown

null

NULL

### 1.14.2 opstart

#### Command

```
opstart
```

#### Parameters

opstart

Send an OPSTART message to the object

---

## 1.15 om2k

### 1.15.1 capabilities-request

Command

```
capabilities-request
```

Parameters

capabilities-request

Request MO capabilities

### 1.15.2 configuration-request

Command

```
configuration-request
```

Parameters

configuration-request

Send the configuration request for current MO

### 1.15.3 connect-command

Command

```
connect-command
```

Parameters

connect-command

Connect the MO

### 1.15.4 disable-request

Command

```
disable-request
```

Parameters

disable-request

Disable the MO

---

### 1.15.5 disconnect-command

#### Command

```
disconnect-command
```

#### Parameters

disconnect-command

Disconnect the MO

### 1.15.6 enable-request

#### Command

```
enable-request
```

#### Parameters

enable-request

Enable the MO

### 1.15.7 operational-info <0-1>

#### Command

```
operational-info <0-1>
```

#### Parameters

operational-info

Set operational information

<0-1>

Set operational info to 0 or 1

### 1.15.8 reset-command

#### Command

```
reset-command
```

#### Parameters

reset-command

Reset the MO

---

### 1.15.9 start-request

#### Command

```
start-request
```

#### Parameters

start-request

Start the MO

### 1.15.10 status-request

#### Command

```
status-request
```

#### Parameters

status-request

Get the MO Status

### 1.15.11 test-request

#### Command

```
test-request
```

#### Parameters

test-request

Test the MO

## 1.16 om2k-con-group

### 1.16.1 con-path (add|del) <0-2047> <0-255> concentrated <1-16>

#### Command

```
con-path (add|del) <0-2047> <0-255> concentrated <1-16>
```

#### Parameters

con-path

CON Path (In/Out)

---

add

Add CON Path to Concentration Group

del

Delete CON Path from Concentration Group

<0-2047>

CON Connection Point

<0-255>

Contiguity Index

concentrated

Concentrated in/outlet

<1-16>

Tag Number

### 1.16.2 con-path (add|del) <0-2047> <0-255> deconcentrated <0-63>

Command

```
con-path (add|del) <0-2047> <0-255> deconcentrated <0-63>
```

Parameters

con-path

CON Path (In/Out)

add

Add CON Path to Concentration Group

del

Delete CON Path from Concentration Group

<0-2047>

CON Connection Point

<0-255>

Contiguity Index

deconcentrated

De-concentrated in/outlet

<0-63>

TEI Value

## 1.17 config-mncc-int

This node allows to configure the default codecs for the internal call control handling.

### 1.17.1 default-codec tch-f (fr|EFR|amr)

#### Command

```
default-codec tch-f (fr|EFR|amr)
```

#### Parameters

##### default-codec

Set default codec

##### tch-f

Codec for TCH/F

##### fr

Full-Rate

##### EFR

Enhanced Full-Rate

##### amr

Adaptive Multi-Rate

### 1.17.2 default-codec tch-h (hr|amr)

#### Command

```
default-codec tch-h (hr|amr)
```

#### Parameters

##### default-codec

Set default codec

##### tch-h

Codec for TCH/H

##### hr

Half-Rate

##### amr

Adaptive Multi-Rate

### 1.17.3 meas-feed destination ADDR <0-65535>

#### Command

```
meas-feed destination ADDR <0-65535>
```

#### Parameters

---



meas-feed

Measurement export related

destination

destination

ADDR

address or hostname

<0-65535>

port number

### 1.17.4 meas-feed scenario NAME

Command

```
meas-feed scenario NAME
```

Parameters

meas-feed

Measurement export related

scenario

scenario

NAME

Name up to 31 characters included in report

## 1.18 config-nitb

### 1.18.1 assign-tmsi

Command

```
assign-tmsi
```

Parameters

assign-tmsi

Assign TMSI during Location Updating.

### 1.18.2 no assign-tmsi

Command

```
no assign-tmsi
```

Parameters

no

Negate a command or set its defaults

assign-tmsi

Assign TMSI during Location Updating.

### 1.18.3 no subscriber-create-on-demand

#### Command

```
no subscriber-create-on-demand
```

#### Parameters

no

Negate a command or set its defaults

subscriber-create-on-demand

Make a new record when a subscriber is first seen.

### 1.18.4 subscriber-create-on-demand [no-extension]

#### Command

```
subscriber-create-on-demand [no-extension]
```

#### Parameters

subscriber-create-on-demand

Make a new record when a subscriber is first seen.

[no-extension]

Do not automatically assign extension to created subscribers

### 1.18.5 subscriber-create-on-demand random <1-9999999999> <2-9999999999>

#### Command

```
subscriber-create-on-demand random <1-9999999999> <2-9999999999>
```

#### Parameters

subscriber-create-on-demand

Set random parameters for a new record when a subscriber is first seen.

random

Set random parameters for a new record when a subscriber is first seen.

<1-9999999999>

Minimum for subscriber extension

<2-9999999999>

Maximum for subscriber extension

## 1.19 config-smpp

This node allows to configure the SMPP interface for interfacing with external SMS applications. This section contains generic/common SMPP related configuration, and no per-ESME specific parameters.

### 1.19.1 esme NAME

#### Command

```
esme NAME
```

#### Parameters

esme

Configure a particular ESME

NAME

Alphanumeric System ID of the ESME to be configured

### 1.19.2 local-tcp-ip A.B.C.D <1-65535>

#### Command

```
local-tcp-ip A.B.C.D <1-65535>
```

#### Parameters

local-tcp-ip

Set the local IP address and TCP port on which we listen for SMPP

A.B.C.D

Local IP address

<1-65535>

TCP port number

### 1.19.3 local-tcp-port <1-65535>

#### Command

```
local-tcp-port <1-65535>
```

#### Parameters

local-tcp-port

Set the local TCP port on which we listen for SMPP

<1-65535>

TCP port number

### 1.19.4 no esme NAME

#### Command

```
no esme NAME
```

#### Parameters

no

Negate a command or set its defaults

esme

Remove ESME configuration

NAME

Alphanumeric System ID of the ESME to be removed

### 1.19.5 no smpp-first

#### Command

```
no smpp-first
```

#### Parameters

no

Negate a command or set its defaults

smpp-first

Try SMPP before routes before the subscriber DB

### 1.19.6 policy (accept-all|closed)

#### Command

```
policy (accept-all|closed)
```

#### Parameters

policy

Set the authentication policy of this SMSC

accept-all

Accept all SMPP connections independent of system ID / password

closed

Accept only SMPP connections from ESMEs explicitly configured

---

### 1.19.7 smpp-first

Command

```
smpp-first
```

Parameters

smpp-first

Try SMPP routes before the subscriber DB

### 1.19.8 system-id ID

Command

```
system-id ID
```

Parameters

system-id

Set the System ID of this SMSC

ID

Alphanumeric SMSC System ID

## 1.20 config-smpp-esme

This node allows to configure one particular SMPP ESME, which is an External SMS Entity such as a SMS based application server. You can define any number of ESME within the SMPP node of the OsmoNITB VTY.

### 1.20.1 alert-notifications

Command

```
alert-notifications
```

Parameters

alert-notifications

Disable sending of SMPP Alert Notifications for this ESME

### 1.20.2 dcs-transparent

Command

```
dcs-transparent
```

Parameters

dcs-transparent

Enable the transparent pass-through of TP-DCS to SMPP DataCoding

---

### 1.20.3 default-route

Command

```
default-route
```

Parameters

default-route

Set this ESME as default-route for all SMS to unknown destinations

### 1.20.4 deliver-src-imsi

Command

```
deliver-src-imsi
```

Parameters

deliver-src-imsi

Enable the use of IMSI as source address in DELIVER

### 1.20.5 no alert-notifications

Command

```
no alert-notifications
```

Parameters

no

Negate a command or set its defaults

alert-notifications

Disable sending of SMPP Alert Notifications for this ESME

### 1.20.6 no dcs-transparent

Command

```
no dcs-transparent
```

Parameters

no

Negate a command or set its defaults

dcs-transparent

Disable the transparent pass-through of TP-DCS to SMPP DataCoding

---

### 1.20.7 no default-route

#### Command

```
no default-route
```

#### Parameters

no

Negate a command or set its defaults

default-route

Remove this ESME as default-route for all SMS to unknown destinations

### 1.20.8 no deliver-src-imsi

#### Command

```
no deliver-src-imsi
```

#### Parameters

no

Negate a command or set its defaults

deliver-src-imsi

Disable the use of IMSI as source address in DELIVER

### 1.20.9 no osmocom-extensions

#### Command

```
no osmocom-extensions
```

#### Parameters

no

Negate a command or set its defaults

osmocom-extensions

Disable the use of Osmocom SMPP Extensions for this ESME

### 1.20.10 no password

#### Command

```
no password
```

#### Parameters

no

Negate a command or set its defaults

password

Remove the password for this ESME

---

### 1.20.11 no route prefix (unknown|international|national|network|subscriber|alpha|abbrev)...

#### Command

```
no route prefix (unknown|international|national|network|subscriber|alpha|abbrev) ( ←  
unknown|isdn|x121|f69|e212|national|private|ermes|ip|wap) PREFIX
```

#### Parameters

no

Negate a command or set its defaults

route

Configure a route for MO-SMS to be sent to this ESME

prefix

Prefix-match route

unknown

Unknown type-of-number

international

International type-of-number

national

National type-of-number

network

Network specific type-of-number

subscriber

Subscriber type-of-number

alpha

Alphanumeric type-of-number

abbrev

Abbreviated type-of-number

unknown

Unknown numbering plan

isdn

ISDN (E.164) numbering plan

x121

X.121 numbering plan

f69

F.69 numbering plan

e212

E.212 numbering plan

national

National numbering plan

---



private  
    Private numbering plan

ermes  
    ERMES numbering plan

ip  
    IP numbering plan

wap  
    WAP numbeing plan

PREFIX  
    Destination number prefix

### 1.20.12 osmocom-extensions

Command

```
osmocom-extensions
```

Parameters

osmocom-extensions

Enable the use of Osmocom SMPP Extensions for this ESME

### 1.20.13 password PASSWORD

Command

```
password PASSWORD
```

Parameters

password

Set the password for this ESME

PASSWORD

Alphanumeric password string

### 1.20.14 route prefix (unknown|international|national|network|subscriber|alpha|abbrev) (u...

Command

```
route prefix (unknown|international|national|network|subscriber|alpha|abbrev) (unknown| ←  
    isdn|x121|f69|e212|national|private|ermes|ip|wap) PREFIX
```

Parameters

---

---

**route**

Configure a route for MO-SMS to be sent to this ESME

**prefix**

Prefix-match route

**unknown**

Unknown type-of-number

**international**

International type-of-number

**national**

National type-of-number

**network**

Network specific type-of-number

**subscriber**

Subscriber type-of-number

**alpha**

Alphanumeric type-of-number

**abbrev**

Abbreviated type-of-number

**unknown**

Unknown numbering plan

**isdn**

ISDN (E.164) numbering plan

**x121**

X.121 numbering plan

**f69**

F.69 numbering plan

**e212**

E.212 numbering plan

**national**

National numbering plan

**private**

Private numbering plan

**ermes**

ERMES numbering plan

**ip**

IP numbering plan

**wap**

WAP numbeing plan

**PREFIX**

Destination number prefix

---