

# **OsmoBSCMGCP VTY Reference**

Copyright © 2012-2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

---

**COLLABORATORS**

	<i>TITLE :</i> OsmoBSCMGCP VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		October 3, 2023	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
DRAFT 1.4.2-8-g8c1a5	2023-Mar-07	Automatically Generated VTY Reference	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	.....	1
1.1.1	echo .MESSAGE	1
1.1.2	enable	2
1.1.3	exit	2
1.1.4	help	2
1.1.5	list	3
1.1.6	logging color (0 1)	3
1.1.7	logging disable	3
1.1.8	logging enable	4
1.1.9	logging filter all (0 1)	4
1.1.10	logging level (all rl lcl mml rr rs ln ml mn cc pag meas sc pl ms cl mg cp hold b ref gpr.....)	5
1.1.11	logging set log mask MASK	7
1.1.12	logging set-log-mask MASK	7
1.1.13	logging timestamp (0 1)	8
1.1.14	show alarms	8
1.1.15	show history	8
1.1.16	show logging vty	9
1.1.17	show mgcp [stats]	9
1.1.18	show online-help	9
1.1.19	show version	10
1.1.20	terminal length <0-512>	10
1.1.21	terminal no length	10
1.1.22	who	11
1.2	.....	11
1.2.1	configure terminal	11
1.2.2	copy running-config startup-config	11
1.2.3	disable	12
1.2.4	echo .MESSAGE	12
1.2.5	exit	12

1.2.6	free-endpoint <0-64> NUMBER . . . . .	12
1.2.7	help . . . . .	13
1.2.8	list . . . . .	13
1.2.9	logging color (01) . . . . .	13
1.2.10	logging disable . . . . .	14
1.2.11	logging enable . . . . .	14
1.2.12	logging filter all (01) . . . . .	14
1.2.13	logging level (all rl lcl mml rr rs ln ml mn ccl pag meas sc pl ms cl mg cp hold bl ref l pr... . . . .	15
1.2.14	logging set log mask MASK . . . . .	17
1.2.15	logging set-log-mask MASK . . . . .	18
1.2.16	logging timestamp (01) . . . . .	18
1.2.17	loop-endpoint <0-64> NAME (01) . . . . .	18
1.2.18	reset-all-endpoints . . . . .	19
1.2.19	reset-endpoint <0-64> NUMBER . . . . .	19
1.2.20	show alarms . . . . .	19
1.2.21	show history . . . . .	20
1.2.22	show logging vty . . . . .	20
1.2.23	show mgcp [stats] . . . . .	20
1.2.24	show online-help . . . . .	21
1.2.25	show running-config . . . . .	21
1.2.26	show startup-config . . . . .	21
1.2.27	show version . . . . .	22
1.2.28	tap-call <0-64> ENDPOINT (bts-in bts-out net-in net-out) A.B.C.D <0-65534> . . . . .	22
1.2.29	terminal length <0-512> . . . . .	23
1.2.30	terminal monitor . . . . .	23
1.2.31	terminal no length . . . . .	23
1.2.32	terminal no monitor . . . . .	24
1.2.33	who . . . . .	24
1.2.34	write . . . . .	24
1.2.35	write file . . . . .	24
1.2.36	write memory . . . . .	25
1.2.37	write terminal . . . . .	25
1.3	. . . . .	25
1.3.1	banner motd default . . . . .	25
1.3.2	banner motd file [FILE] . . . . .	26
1.3.3	enable password (8l) WORD . . . . .	26
1.3.4	enable password LINE . . . . .	27
1.3.5	end . . . . .	27
1.3.6	exit . . . . .	27

1.3.7	help	27
1.3.8	hostname WORD	28
1.3.9	line vty	28
1.3.10	list	28
1.3.11	log alarms <2-32700>	29
1.3.12	log file .FILENAME	29
1.3.13	log stderr	29
1.3.14	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	30
1.3.15	log syslog local <0-7>	30
1.3.16	mgcp	31
1.3.17	no banner motd	31
1.3.18	no enable password	31
1.3.19	no hostname [HOSTNAME]	32
1.3.20	no log alarms	32
1.3.21	no log file .FILENAME	32
1.3.22	no log stderr	33
1.3.23	no log syslog	33
1.3.24	no service advanced-vty	33
1.3.25	no service terminal-length [<0-512>]	34
1.3.26	password (8) WORD	34
1.3.27	password LINE	34
1.3.28	service advanced-vty	35
1.3.29	service terminal-length <0-512>	35
1.3.30	show history	35
1.3.31	show running-config	36
1.3.32	write	36
1.3.33	write file	36
1.3.34	write memory	36
1.3.35	write terminal	37
1.4		37
1.4.1	end	37
1.4.2	exit	37
1.4.3	help	37
1.4.4	list	38
1.4.5	logging color (0 1)	38
1.4.6	logging filter all (0 1)	38
1.4.7	logging level (all rl lcl mml rr rs ln ml mn ccl pag meas sc pl ms cl mg cp hold bl ref gr...)	39
1.4.8	logging timestamp (0 1)	41
1.4.9	show running-config	42

---

1.4.10	write	42
1.4.11	write file	42
1.4.12	write memory	42
1.4.13	write terminal	43
1.5	MGCP Global Commands	43
1.5.1	bind early (011)	43
1.5.2	bind ip A.B.C.D	43
1.5.3	bind port <0-65534>	44
1.5.4	bts ip A.B.C.D	44
1.5.5	call agent ip A.B.C.D	44
1.5.6	call-agent ip A.B.C.D	45
1.5.7	end	45
1.5.8	exit	45
1.5.9	help	45
1.5.10	list	46
1.5.11	local ip A.B.C.D	46
1.5.12	loop (011)	46
1.5.13	no rtcp-omit	47
1.5.14	no rtp keep-alive	47
1.5.15	no rtp-patch	47
1.5.16	no rtp-patch ssrc	48
1.5.17	no rtp-patch timestamp	48
1.5.18	no sdp audio-payload send-ptime	48
1.5.19	no transcoder-mgw	49
1.5.20	number endpoints <0-65534>	49
1.5.21	rtcp-omit	49
1.5.22	rtp base <0-65534>	50
1.5.23	rtp bts-base <0-65534>	50
1.5.24	rtp bts-range <0-65534> <0-65534>	50
1.5.25	rtp ip-dscp <0-255>	51
1.5.26	rtp ip-tos <0-255>	51
1.5.27	rtp keep-alive <1-120>	51
1.5.28	rtp keep-alive once	52
1.5.29	rtp net-base <0-65534>	52
1.5.30	rtp net-range <0-65534> <0-65534>	52
1.5.31	rtp transcoder-base <0-65534>	53
1.5.32	rtp transcoder-range <0-65534> <0-65534>	53
1.5.33	rtp-patch ssrc	53
1.5.34	rtp-patch timestamp	54

---

1.5.35	sdp audio fmtp-extra .NAME . . . . .	54
1.5.36	sdp audio payload name NAME . . . . .	54
1.5.37	sdp audio payload number <1-255> . . . . .	55
1.5.38	sdp audio-payload name NAME . . . . .	55
1.5.39	sdp audio-payload number <1-255> . . . . .	56
1.5.40	sdp audio-payload send-ptime . . . . .	56
1.5.41	show running-config . . . . .	56
1.5.42	transcoder-mgw A.B.C.D . . . . .	57
1.5.43	transcoder-remote-base <0-65534> . . . . .	57
1.5.44	trunk <1-64> . . . . .	57
1.5.45	write . . . . .	58
1.5.46	write file . . . . .	58
1.5.47	write memory . . . . .	58
1.5.48	write terminal . . . . .	58
1.6	MGCP Trunk Command . . . . .	59
1.6.1	end . . . . .	59
1.6.2	exit . . . . .	59
1.6.3	help . . . . .	59
1.6.4	list . . . . .	59
1.6.5	loop (011) . . . . .	60
1.6.6	no rtcp-omit . . . . .	60
1.6.7	no rtp keep-alive . . . . .	60
1.6.8	no rtp-patch . . . . .	61
1.6.9	no rtp-patch ssrc . . . . .	61
1.6.10	no rtp-patch timestamp . . . . .	61
1.6.11	no sdp audio-payload send-ptime . . . . .	62
1.6.12	rtcp-omit . . . . .	62
1.6.13	rtp keep-alive <1-120> . . . . .	62
1.6.14	rtp keep-alive once . . . . .	63
1.6.15	rtp-patch ssrc . . . . .	63
1.6.16	rtp-patch timestamp . . . . .	63
1.6.17	sdp audio fmtp-extra .NAME . . . . .	64
1.6.18	sdp audio payload name NAME . . . . .	64
1.6.19	sdp audio payload number <1-255> . . . . .	65
1.6.20	sdp audio-payload name NAME . . . . .	65
1.6.21	sdp audio-payload number <1-255> . . . . .	66
1.6.22	sdp audio-payload send-ptime . . . . .	66
1.6.23	show running-config . . . . .	66
1.6.24	write . . . . .	67
1.6.25	write file . . . . .	67
1.6.26	write memory . . . . .	67
1.6.27	write terminal . . . . .	67



# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

## 1.1

### 1.1.1 echo .MESSAGE

### Command

```
echo .MESSAGE
```

### Parameters

echo

Echo a message back to the vty

.MESSAGE

The message to echo

## 1.1.2 enable

### Command

```
enable
```

### Parameters

enable

Turn on privileged mode command

## 1.1.3 exit

### Command

```
exit
```

### Parameters

exit

Exit current mode and down to previous mode

## 1.1.4 help

### Command

```
help
```

### Parameters

help

Description of the interactive help system

---

### 1.1.5 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.1.6 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure log message to this terminal

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.1.7 logging disable

#### Command

```
logging disable
```

#### Parameters

logging

Configure log message to this terminal

disable

Disables logging to this vty

---

### 1.1.8 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure log message to this terminal

##### enable

Enables logging to this vty

### 1.1.9 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

## 1.1.10 logging level (all|rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gpr...

### Command

```
logging level (all|rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns|↵
             bssgp|llc|sndcp|nat|ctrl|smpp|lglobal|llapd|linp|lmux|lmi|lmib|lsms) (everything|↵
             debug|info|notice|error|fatal)
```

### Parameters

#### logging

Configure log message to this terminal

#### level

Set the log level for a specified category

#### all

Global setting for all subsystems

#### rll

A-bis Radio Link Layer (RLL)

#### cc

Layer3 Call Control (CC)

#### mm

Layer3 Mobility Management (MM)

#### rr

Layer3 Radio Resource (RR)

#### rsl

A-bis Radio Siganlling Link (RSL)

#### nm

A-bis Network Management / O&M (NM/OML)

#### mncc

MNCC API for Call Control application

#### pag

Paging Subsystem

#### meas

Radio Measurement Processing

#### sccp

SCCP Protocol

#### msc

Mobile Switching Center

#### mgcp

Media Gateway Control Protocol

---

ho  
Hand-Over

db  
Database Layer

ref  
Reference Counting

gprs  
GPRS Packet Service

ns  
GPRS Network Service (NS)

bssgp  
GPRS BSS Gateway Protocol (BSSGP)

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

nat  
GSM 08.08 NAT/Multiplexer

ctrl  
Control interface

smpp  
SMPP interface for external SMS apps

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

everything  
Log simply everything

---

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.1.11 logging set log mask MASK

Command

```
logging set log mask MASK
```

Parameters

logging

Configure log message to this terminal

set

Decide which categories to output.

log

Log commands

mask

Mask commands

MASK

The logmask to use

### 1.1.12 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure log message to this terminal

set-log-mask

Set the logmask of this logging target

MASK

The logmask to use



### 1.1.13 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.1.14 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.1.15 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

---

### 1.1.16 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.1.17 show mgcp [stats]

#### Command

```
show mgcp [stats]
```

#### Parameters

##### show

Show running system information

##### mgcp

Display information about the MGCP Media Gateway

##### [stats]

Include Statistics

### 1.1.18 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

---

### 1.1.19 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.1.20 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.1.21 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---

## 1.1.22 who

### Command

```
who
```

### Parameters

who

Display who is on vty

## 1.2

### 1.2.1 configure terminal

#### Command

```
configure terminal
```

#### Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.2.2 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

---

### 1.2.3 disable

#### Command

```
disable
```

#### Parameters

disable

Turn off privileged mode command

### 1.2.4 echo .MESSAGE

#### Command

```
echo .MESSAGE
```

#### Parameters

echo

Echo a message back to the vty

.MESSAGE

The message to echo

### 1.2.5 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.2.6 free-endpoint <0-64> NUMBER

#### Command

```
free-endpoint <0-64> NUMBER
```

#### Parameters

free-endpoint

Free the given endpoint

<0-64>

Trunk number

NUMBER

Endpoint number in hex.

---

## 1.2.7 help

### Command

```
help
```

### Parameters

help

Description of the interactive help system

## 1.2.8 list

### Command

```
list
```

### Parameters

list

Print command list

## 1.2.9 logging color (0|1)

### Command

```
logging color (0|1)
```

### Parameters

logging

Configure log message to this terminal

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

---

### 1.2.10 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure log message to this terminal

##### disable

Disables logging to this vty

### 1.2.11 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure log message to this terminal

##### enable

Enables logging to this vty

### 1.2.12 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### filter

Filter log messages

---

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.2.13 logging level (all|rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gpr...

Command

```
logging level (all|rll|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns|↵
             bssgp|llc|sndcp|nat|ctrl|smpp|lglobal|llapd|linp|lmux|lmi|lmib|lsms) (everything|↵
             debug|info|notice|error|fatal)
```

Parameters

logging

Configure log message to this terminal

level

Set the log level for a specified category

all

Global setting for all subsystems

rll

A-bis Radio Link Layer (RLL)

cc

Layer3 Call Control (CC)

mm

Layer3 Mobility Management (MM)

rr

Layer3 Radio Resource (RR)

rsl

A-bis Radio Signalling Link (RSL)

nm

A-bis Network Management / O&M (NM/OML)

mncc

MNCC API for Call Control application

pag

Paging Subsystem

meas

Radio Measurement Processing



---

sccp  
    SCCP Protocol

msc  
    Mobile Switching Center

mgcp  
    Media Gateway Control Protocol

ho  
    Hand-Over

db  
    Database Layer

ref  
    Reference Counting

gprs  
    GPRS Packet Service

ns  
    GPRS Network Service (NS)

bssgp  
    GPRS BSS Gateway Protocol (BSSGP)

llc  
    GPRS Logical Link Control Protocol (LLC)

sndcp  
    GPRS Sub-Network Dependent Control Protocol (SNDCP)

nat  
    GSM 08.08 NAT/Multiplexer

ctrl  
    Control interface

smpp  
    SMPP interface for external SMS apps

lglobal  
    Library-internal global log family

llapd  
    LAPD in libosmogsm

linp  
    A-bis Input Subsystem

lmux  
    A-bis B-Subchannel TRAU Frame Multiplex

lmi  
    A-bis Input Driver for Signalling

---

- lmib
  - A-bis Input Driver for B-Channels (voice)
- lsms
  - Layer3 Short Message Service (SMS)
- everything
  - Log simply everything
- debug
  - Log debug messages and higher levels
- info
  - Log informational messages and higher levels
- notice
  - Log noticable messages and higher levels
- error
  - Log error messages and higher levels
- fatal
  - Log only fatal messages

### 1.2.14 logging set log mask MASK

#### Command

```
logging set log mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set

Decide which categories to output.

##### log

Log commands

##### mask

Mask commands

##### MASK

The logmask to use

### 1.2.15 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure log message to this terminal

##### set-log-mask

Set the logmask of this logging target

##### MASK

The logmask to use

### 1.2.16 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure log message to this terminal

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.17 loop-endpoint <0-64> NAME (0|1)

#### Command

```
loop-endpoint <0-64> NAME (0|1)
```

#### Parameters

##### loop-endpoint

Loop a given endpoint

<0-64>

Trunk number

NAME

The name in hex of the endpoint

0

Disable the loop

1

Enable the loop

### 1.2.18 reset-all-endpoints

Command

```
reset-all-endpoints
```

Parameters

reset-all-endpoints

Reset all endpoints

### 1.2.19 reset-endpoint <0-64> NUMBER

Command

```
reset-endpoint <0-64> NUMBER
```

Parameters

reset-endpoint

Reset the given endpoint

<0-64>

Trunk number

NUMBER

Endpoint number in hex.

### 1.2.20 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.21 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.2.22 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.2.23 show mgcp [stats]

#### Command

```
show mgcp [stats]
```

#### Parameters

##### show

Show running system information

##### mgcp

Display information about the MGCP Media Gateway

##### [stats]

Include Statistics

---

### 1.2.24 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.2.25 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.2.26 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.2.27 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.2.28 tap-call <0-64> ENDPOINT (bts-in|bts-out|net-in|net-out) A.B.C.D <0-65534>

#### Command

```
tap-call <0-64> ENDPOINT (bts-in|bts-out|net-in|net-out) A.B.C.D <0-65534>
```

#### Parameters

##### tap-call

Forward data on endpoint to a different system

##### <0-64>

Trunk number

##### ENDPOINT

The endpoint in hex

##### bts-in

Forward the data coming from the bts

##### bts-out

Forward the data coming from the bts leaving to the network

##### net-in

Forward the data coming from the net

##### net-out

Forward the data coming from the net leaving to the bts

##### A.B.C.D

destination IP of the data

##### <0-65534>

destination port

---

### 1.2.29 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.30 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.2.31 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---



### 1.2.32 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.2.33 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

### 1.2.34 write

#### Command

```
write
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

### 1.2.35 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

---

### 1.2.36 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

### 1.2.37 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.3

### 1.3.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

---

### 1.3.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

### 1.3.3 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

### 1.3.4 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.3.5 end

#### Command

```
end
```

#### Parameters

##### end

End current mode and change to enable mode.

### 1.3.6 exit

#### Command

```
exit
```

#### Parameters

##### exit

Exit current mode and down to previous mode

### 1.3.7 help

#### Command

```
help
```

#### Parameters

##### help

Description of the interactive help system

---

### 1.3.8 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.3.9 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vty

Virtual terminal

### 1.3.10 list

#### Command

```
list
```

#### Parameters

##### list

Print command list

---

### 1.3.11 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.3.12 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.3.13 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

---

### 1.3.14 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

### 1.3.15 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

---

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.3.16 mgcp

Command

```
mgcp
```

Parameters

mgcp

Configure the MGCP

### 1.3.17 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.3.18 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

---



### 1.3.19 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.3.20 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.3.21 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.3.22 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.3.23 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.3.24 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

---

### 1.3.25 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

### 1.3.26 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.3.27 password LINE

#### Command

```
password LINE
```

#### Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

### 1.3.28 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.3.29 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.3.30 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.3.31 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.3.32 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.3.33 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.3.34 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

---

### 1.3.35 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.4

### 1.4.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.4.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.4.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

---

#### 1.4.4 list

##### Command

```
list
```

##### Parameters

list

Print command list

#### 1.4.5 logging color (0|1)

##### Command

```
logging color (0|1)
```

##### Parameters

logging

Configure log message to this terminal

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

#### 1.4.6 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

##### Command

```
logging filter all (0|1)
```

##### Parameters

logging

Configure log message to this terminal

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.4.7 logging level (all|rl|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gpr...

Command

```
logging level (all|rl|cc|mm|rr|rsl|nm|mncc|pag|meas|sccp|msc|mgcp|ho|db|ref|gprs|ns| ←
             bssgp|llc|sndcp|nat|ctrl|smpp|lglobal|llapd|linp|lmux|lmi|lmib|lsms) (everything| ←
             debug|info|notice|error|fatal)
```

Parameters

logging

Configure log message to this terminal

level

Set the log level for a specified category

all

Global setting for all subsystems

rl

A-bis Radio Link Layer (RLL)

cc

Layer3 Call Control (CC)

mm

Layer3 Mobility Management (MM)

rr

Layer3 Radio Resource (RR)

rsl

A-bis Radio Signalling Link (RSL)

nm

A-bis Network Management / O&M (NM/OML)

mncc

MNCC API for Call Control application

pag

Paging Subsystem



---

meas  
Radio Measurement Processing

sccp  
SCCP Protocol

msc  
Mobile Switching Center

mgcp  
Media Gateway Control Protocol

ho  
Hand-Over

db  
Database Layer

ref  
Reference Counting

gprs  
GPRS Packet Service

ns  
GPRS Network Service (NS)

bssgp  
GPRS BSS Gateway Protocol (BSSGP)

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

nat  
GSM 08.08 NAT/Multiplexer

ctrl  
Control interface

smpp  
SMPP interface for external SMS apps

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

---

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

everything

Log simply everything

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.4.8 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure log message to this terminal

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

---

### 1.4.9 show running-config

#### Command

```
show running-config
```

#### Parameters

##### show

Show running system information

##### running-config

running configuration

### 1.4.10 write

#### Command

```
write
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

### 1.4.11 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

### 1.4.12 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

---

### 1.4.13 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.5 MGCP Global Commands

This node allows to configure global MGCP settings. These include the various port numbers.

### 1.5.1 bind early (0|1)

#### Command

```
bind early (0|1)
```

#### Parameters

##### bind

Listen/Bind related socket option

##### early

Bind local ports on start up

##### 0

Bind on demand

##### 1

Bind on startup

### 1.5.2 bind ip A.B.C.D

#### Command

```
bind ip A.B.C.D
```

#### Parameters

##### bind

Listen/Bind related socket option

##### ip

IP information

##### A.B.C.D

IPv4 Address to bind to

---

### 1.5.3 bind port <0-65534>

#### Command

```
bind port <0-65534>
```

#### Parameters

bind

Listen/Bind related socket option

port

Port information

<0-65534>

UDP port to listen for MGCP messages

### 1.5.4 bts ip A.B.C.D

#### Command

```
bts ip A.B.C.D
```

#### Parameters

bts

BTS Audio source/destination options

ip

IP information

A.B.C.D

IPv4 Address of the BTS

### 1.5.5 call agent ip A.B.C.D

#### Command

```
call agent ip A.B.C.D
```

#### Parameters

call

Callagent information

agent

Callagent information

ip

IP information

A.B.C.D

IPv4 Address of the callagent

### 1.5.6 call-agent ip A.B.C.D

#### Command

```
call-agent ip A.B.C.D
```

#### Parameters

call-agent

Callagent information

ip

IP information

A.B.C.D

IPv4 Address of the callagent

### 1.5.7 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.5.8 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.5.9 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

---

### 1.5.10 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.5.11 local ip A.B.C.D

#### Command

```
local ip A.B.C.D
```

#### Parameters

local

Local options for the SDP record

ip

IP information

A.B.C.D

IPv4 Address to use in SDP record

### 1.5.12 loop (0|1)

#### Command

```
loop (0|1)
```

#### Parameters

loop

Loop audio for all endpoints on main trunk

0

Don't Loop

1

Loop

---

### 1.5.13 no rtcp-omit

#### Command

```
no rtcp-omit
```

#### Parameters

no

Negate a command or set its defaults

rtcp-omit

Drop RTCP packets in both directions

### 1.5.14 no rtp keep-alive

#### Command

```
no rtp keep-alive
```

#### Parameters

no

Negate a command or set its defaults

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

### 1.5.15 no rtp-patch

#### Command

```
no rtp-patch
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions



### 1.5.16 no rtp-patch ssrc

#### Command

```
no rtp-patch ssrc
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions

ssrc

Force a fixed SSRC

### 1.5.17 no rtp-patch timestamp

#### Command

```
no rtp-patch timestamp
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions

timestamp

Adjust RTP timestamp

### 1.5.18 no sdp audio-payload send-ptime

#### Command

```
no sdp audio-payload send-ptime
```

#### Parameters

no

Negate a command or set its defaults

sdp

SDP File related options

audio-payload

Audio payload options

send-ptime

Send SDP ptime (packet duration) attribute

---

### 1.5.19 no transcoder-mgw

#### Command

```
no transcoder-mgw
```

#### Parameters

no

Negate a command or set its defaults

transcoder-mgw

Disable the transcoding

### 1.5.20 number endpoints <0-65534>

#### Command

```
number endpoints <0-65534>
```

#### Parameters

number

Number options

endpoints

Endpoints available

<0-65534>

Number endpoints

### 1.5.21 rtcp-omit

#### Command

```
rtcp-omit
```

#### Parameters

rtcp-omit

Drop RTCP packets in both directions

### 1.5.22 rtp base <0-65534>

#### Command

```
rtp base <0-65534>
```

#### Parameters

rtp

RTP configuration

base

First UDP port allocated for the BTS side

<0-65534>

UDP Port number

### 1.5.23 rtp bts-base <0-65534>

#### Command

```
rtp bts-base <0-65534>
```

#### Parameters

rtp

RTP configuration

bts-base

First UDP port allocated for the BTS side

<0-65534>

UDP Port number

### 1.5.24 rtp bts-range <0-65534> <0-65534>

#### Command

```
rtp bts-range <0-65534> <0-65534>
```

#### Parameters

rtp

RTP configuration

bts-range

Range of ports to use for the BTS side

<0-65534>

Start of the range of ports

<0-65534>

End of the range of ports

### 1.5.25 rtp ip-dscp <0-255>

#### Command

```
rtp ip-dscp <0-255>
```

#### Parameters

rtp

RTP configuration

ip-dscp

Apply IP\_TOS to the audio stream

<0-255>

The DSCP value

### 1.5.26 rtp ip-tos <0-255>

#### Command

```
rtp ip-tos <0-255>
```

#### Parameters

rtp

RTP configuration

ip-tos

Apply IP\_TOS to the audio stream

<0-255>

The DSCP value

### 1.5.27 rtp keep-alive <1-120>

#### Command

```
rtp keep-alive <1-120>
```

#### Parameters

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

<1-120>

Keep alive interval in secs

---

### 1.5.28 rtp keep-alive once

#### Command

```
rtp keep-alive once
```

#### Parameters

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

once

Send dummy packet only once after CRCX/MDCX

### 1.5.29 rtp net-base <0-65534>

#### Command

```
rtp net-base <0-65534>
```

#### Parameters

rtp

RTP configuration

net-base

First UDP port allocated for the NET side

<0-65534>

UDP Port number

### 1.5.30 rtp net-range <0-65534> <0-65534>

#### Command

```
rtp net-range <0-65534> <0-65534>
```

#### Parameters

rtp

RTP configuration

net-range

Range of ports to use for the NET side

<0-65534>

Start of the range of ports

<0-65534>

End of the range of ports

### 1.5.31 rtp transcoder-base <0-65534>

#### Command

```
rtp transcoder-base <0-65534>
```

#### Parameters

rtp

RTP configuration

transcoder-base

First UDP port allocated for the Transcoder side

<0-65534>

UDP Port number

### 1.5.32 rtp transcoder-range <0-65534> <0-65534>

#### Command

```
rtp transcoder-range <0-65534> <0-65534>
```

#### Parameters

rtp

RTP configuration

transcoder-range

Range of ports to use for the Transcoder

<0-65534>

Start of the range of ports

<0-65534>

End of the range of ports

### 1.5.33 rtp-patch ssrc

#### Command

```
rtp-patch ssrc
```

#### Parameters

rtp-patch

Modify RTP packet header in both directions

ssrc

Force a fixed SSRC

### 1.5.34 rtp-patch timestamp

#### Command

```
rtp-patch timestamp
```

#### Parameters

##### rtp-patch

Modify RTP packet header in both directions

##### timestamp

Adjust RTP timestamp

### 1.5.35 sdp audio fntp-extra .NAME

#### Command

```
sdp audio fntp-extra .NAME
```

#### Parameters

##### sdp

Add extra fntp for the SDP file

##### audio

Audio

##### fntp-extra

Fntp-extra

##### .NAME

Extra Information

### 1.5.36 sdp audio payload name NAME

#### Command

```
sdp audio payload name NAME
```

#### Parameters

##### sdp

SDP File related options

##### audio

Audio payload options

##### payload

Audio payload options

##### name

Name

##### NAME

Payload name

### 1.5.37 sdp audio payload number <1-255>

#### Command

```
sdp audio payload number <1-255>
```

#### Parameters

sdp

SDP File related options

audio

Audio payload options

payload

Audio payload options

number

Number

<1-255>

Payload number

### 1.5.38 sdp audio-payload name NAME

#### Command

```
sdp audio-payload name NAME
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

name

Name

NAME

Payload name



### 1.5.39 sdp audio-payload number <1-255>

#### Command

```
sdp audio-payload number <1-255>
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

number

Number

<1-255>

Payload number

### 1.5.40 sdp audio-payload send-ptime

#### Command

```
sdp audio-payload send-ptime
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

send-ptime

Send SDP ptime (packet duration) attribute

### 1.5.41 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.5.42 transcoder-mgw A.B.C.D

#### Command

```
transcoder-mgw A.B.C.D
```

#### Parameters

transcoder-mgw

Use a MGW to detranscoder RTP

A.B.C.D

The IP address of the MGW

### 1.5.43 transcoder-remote-base <0-65534>

#### Command

```
transcoder-remote-base <0-65534>
```

#### Parameters

transcoder-remote-base

Set the base port for the transcoder

<0-65534>

The RTP base port on the transcoder

### 1.5.44 trunk <1-64>

#### Command

```
trunk <1-64>
```

#### Parameters

trunk

Configure a SS7 trunk

<1-64>

Trunk Nr

---

### 1.5.45 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.5.46 write file

#### Command

```
write file
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.5.47 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.5.48 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.6 MGCP Trunk Command

This node allows to configure a MGCP trunk. These include the number, the local binding ports, SDP configuration.

### 1.6.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

### 1.6.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

### 1.6.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

### 1.6.4 list

Command

```
list
```

Parameters

list

Print command list

---

### 1.6.5 loop (0|1)

#### Command

```
loop (0|1)
```

#### Parameters

loop

Loop audio for all endpoints on this trunk

0

Don't Loop

1

Loop

### 1.6.6 no rtcp-omit

#### Command

```
no rtcp-omit
```

#### Parameters

no

Negate a command or set its defaults

rtcp-omit

Drop RTCP packets in both directions

### 1.6.7 no rtp keep-alive

#### Command

```
no rtp keep-alive
```

#### Parameters

no

Negate a command or set its defaults

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

---

### 1.6.8 no rtp-patch

#### Command

```
no rtp-patch
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions

### 1.6.9 no rtp-patch ssrc

#### Command

```
no rtp-patch ssrc
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions

ssrc

Force a fixed SSRC

### 1.6.10 no rtp-patch timestamp

#### Command

```
no rtp-patch timestamp
```

#### Parameters

no

Negate a command or set its defaults

rtp-patch

Modify RTP packet header in both directions

timestamp

Adjust RTP timestamp

---

### 1.6.11 no sdp audio-payload send-ptime

#### Command

```
no sdp audio-payload send-ptime
```

#### Parameters

no

Negate a command or set its defaults

sdp

SDP File related options

audio-payload

Audio payload options

send-ptime

Send SDP ptime (packet duration) attribute

### 1.6.12 rtcp-omit

#### Command

```
rtcp-omit
```

#### Parameters

rtcp-omit

Drop RTCP packets in both directions

### 1.6.13 rtp keep-alive <1-120>

#### Command

```
rtp keep-alive <1-120>
```

#### Parameters

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

<1-120>

Keep-alive interval in secs

---

### 1.6.14 rtp keep-alive once

#### Command

```
rtp keep-alive once
```

#### Parameters

rtp

RTP configuration

keep-alive

Send dummy UDP packet to net RTP destination

once

Send dummy packet only once after CRCX/MDCX

### 1.6.15 rtp-patch ssrc

#### Command

```
rtp-patch ssrc
```

#### Parameters

rtp-patch

Modify RTP packet header in both directions

ssrc

Force a fixed SSRC

### 1.6.16 rtp-patch timestamp

#### Command

```
rtp-patch timestamp
```

#### Parameters

rtp-patch

Modify RTP packet header in both directions

timestamp

Adjust RTP timestamp



### 1.6.17 sdp audio fntp-extra .NAME

#### Command

```
sdp audio fntp-extra .NAME
```

#### Parameters

sdp

Add extra fntp for the SDP file

audio

Audio

fntp-extra

Fntp-extra

.NAME

Extra Information

### 1.6.18 sdp audio payload name NAME

#### Command

```
sdp audio payload name NAME
```

#### Parameters

sdp

SDP File related options

audio

Audio payload options

payload

Audio payload options

name

Payload

NAME

Payload Name

### 1.6.19 sdp audio payload number <1-255>

#### Command

```
sdp audio payload number <1-255>
```

#### Parameters

sdp

SDP File related options

audio

Audio payload options

payload

Audio payload options

number

Number

<1-255>

Payload Number

### 1.6.20 sdp audio-payload name NAME

#### Command

```
sdp audio-payload name NAME
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

name

Payload

NAME

Payload Name

### 1.6.21 sdp audio-payload number <1-255>

#### Command

```
sdp audio-payload number <1-255>
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

number

Number

<1-255>

Payload Number

### 1.6.22 sdp audio-payload send-ptime

#### Command

```
sdp audio-payload send-ptime
```

#### Parameters

sdp

SDP File related options

audio-payload

Audio payload options

send-ptime

Send SDP ptime (packet duration) attribute

### 1.6.23 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.6.24 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.6.25 write file

Command

```
write file
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

### 1.6.26 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.6.27 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal