

## **OsmoPCU VTY Reference**

Copyright © 2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

**COLLABORATORS**

	<i>TITLE :</i> OsmoPCU VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		March 22, 2023	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	5th March 2014	Initial version for 0.2-307	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands . . . . .	1
1.1.1	end . . . . .	2
1.1.2	exit . . . . .	2
1.1.3	help . . . . .	2
1.1.4	list . . . . .	2
1.1.5	show running-config . . . . .	3
1.1.6	write . . . . .	3
1.1.7	write file . . . . .	3
1.1.8	write memory . . . . .	3
1.1.9	write terminal . . . . .	4
1.2	view . . . . .	4
1.2.1	enable . . . . .	4
1.2.2	logging color (0 1) . . . . .	4
1.2.3	logging disable . . . . .	5
1.2.4	logging enable . . . . .	5
1.2.5	logging filter all (0 1) . . . . .	5
1.2.6	logging filter nsvc (nseilnsvci) <0-65535> . . . . .	6
1.2.7	logging level (csn1 l1ifrlcmac rlcmacdata rlcmacdl rlcmacull rlcmacsched rlcmacm.. . . . .	6
1.2.8	logging level force-all (debug info notice error fatal) . . . . .	8
1.2.9	logging level set-all (debug info notice error fatal) . . . . .	9
1.2.10	logging print category (0 1) . . . . .	10
1.2.11	logging print category-hex (0 1) . . . . .	10
1.2.12	logging print extended-timestamp (0 1) . . . . .	11
1.2.13	logging print file (0 1 basename) [last] . . . . .	11
1.2.14	logging print level (0 1) . . . . .	12
1.2.15	logging set-log-mask MASK . . . . .	12
1.2.16	logging timestamp (0 1) . . . . .	12
1.2.17	no logging level force-all . . . . .	13
1.2.18	show alarms . . . . .	13

1.2.19	show asciidoc counters . . . . .	14
1.2.20	show bts statistics . . . . .	14
1.2.21	show history . . . . .	14
1.2.22	show logging vty . . . . .	15
1.2.23	show ms all . . . . .	15
1.2.24	show ms imsi IMSI . . . . .	15
1.2.25	show ms tlli TLLI . . . . .	16
1.2.26	show ns . . . . .	16
1.2.27	show ns (nseilnsvc) <0-65535> [stats] . . . . .	16
1.2.28	show ns persistent . . . . .	17
1.2.29	show ns stats . . . . .	17
1.2.30	show online-help . . . . .	17
1.2.31	show rate-counters . . . . .	18
1.2.32	show stats . . . . .	18
1.2.33	show stats level (global peer subscriber) . . . . .	18
1.2.34	show tbf (all ccch pacch) . . . . .	19
1.2.35	show version . . . . .	19
1.2.36	terminal length <0-512> . . . . .	19
1.2.37	terminal no length . . . . .	20
1.2.38	who . . . . .	20
1.3	enable . . . . .	20
1.3.1	configure terminal . . . . .	20
1.3.2	copy running-config startup-config . . . . .	21
1.3.3	disable . . . . .	21
1.3.4	logging color (0 1) . . . . .	21
1.3.5	logging disable . . . . .	22
1.3.6	logging enable . . . . .	22
1.3.7	logging filter all (0 1) . . . . .	22
1.3.8	logging filter nsvc (nseilnsvc) <0-65535> . . . . .	23
1.3.9	logging level (csn1 ll1 rlc mac rlc macdata rlc macd rlc macull rlc macsched rlc macm rlc mme rlc mme) . . . . .	23
1.3.10	logging level force-all (debug info notice error fatal) . . . . .	25
1.3.11	logging level set-all (debug info notice error fatal) . . . . .	26
1.3.12	logging print category (0 1) . . . . .	27
1.3.13	logging print category-hex (0 1) . . . . .	27
1.3.14	logging print extended-timestamp (0 1) . . . . .	28
1.3.15	logging print file (0 1 basename) [last] . . . . .	28
1.3.16	logging print level (0 1) . . . . .	29
1.3.17	logging set-log-mask MASK . . . . .	29
1.3.18	logging timestamp (0 1) . . . . .	29

1.3.19 no logging level force-all . . . . .	30
1.3.20 nsvc (nseilnsvc) <0-65535> (blocklunblocklreset) . . . . .	30
1.3.21 show alarms . . . . .	31
1.3.22 show asciidoc counters . . . . .	31
1.3.23 show bts statistics . . . . .	31
1.3.24 show history . . . . .	32
1.3.25 show logging vty . . . . .	32
1.3.26 show ms all . . . . .	32
1.3.27 show ms imsi IMSI . . . . .	33
1.3.28 show ms tlli TLLI . . . . .	33
1.3.29 show ns . . . . .	33
1.3.30 show ns (nseilnsvc) <0-65535> [stats] . . . . .	34
1.3.31 show ns persistent . . . . .	34
1.3.32 show ns stats . . . . .	34
1.3.33 show online-help . . . . .	35
1.3.34 show rate-counters . . . . .	35
1.3.35 show startup-config . . . . .	35
1.3.36 show stats . . . . .	36
1.3.37 show stats level (global peer subscriber) . . . . .	36
1.3.38 show tbf (all ccch pacch) . . . . .	36
1.3.39 show version . . . . .	37
1.3.40 terminal length <0-512> . . . . .	37
1.3.41 terminal monitor . . . . .	37
1.3.42 terminal no length . . . . .	38
1.3.43 terminal no monitor . . . . .	38
1.3.44 who . . . . .	38
1.4 config . . . . .	38
1.4.1 banner motd default . . . . .	39
1.4.2 banner motd file [FILE] . . . . .	39
1.4.3 enable password (8!) WORD . . . . .	39
1.4.4 enable password LINE . . . . .	40
1.4.5 hostname WORD . . . . .	40
1.4.6 line vty . . . . .	40
1.4.7 log alarms <2-32700> . . . . .	41
1.4.8 log file .FILENAME . . . . .	41
1.4.9 log gsmtap [HOSTNAME] . . . . .	41
1.4.10 log stderr . . . . .	42
1.4.11 log syslog (authpriv cron daemon ftp prlmail news user uucp) . . . . .	42
1.4.12 log syslog local <0-7> . . . . .	43

---

1.4.13 no banner motd . . . . .	43
1.4.14 no enable password . . . . .	43
1.4.15 no hostname [HOSTNAME] . . . . .	44
1.4.16 no log alarms . . . . .	44
1.4.17 no log file .FILENAME . . . . .	44
1.4.18 no log stderr . . . . .	45
1.4.19 no log syslog . . . . .	45
1.4.20 no service advanced-vty . . . . .	45
1.4.21 no service terminal-length [<0-512>] . . . . .	46
1.4.22 no stats reporter log . . . . .	46
1.4.23 no stats reporter statsd . . . . .	46
1.4.24 ns . . . . .	47
1.4.25 password (8!) WORD . . . . .	47
1.4.26 password LINE . . . . .	47
1.4.27 pcu . . . . .	48
1.4.28 service advanced-vty . . . . .	48
1.4.29 service terminal-length <0-512> . . . . .	48
1.4.30 show history . . . . .	48
1.4.31 stats interval <1-65535> . . . . .	49
1.4.32 stats reporter log . . . . .	49
1.4.33 stats reporter statsd . . . . .	49
1.5 config-log . . . . .	50
1.5.1 logging color (0 1) . . . . .	50
1.5.2 logging filter all (0 1) . . . . .	50
1.5.3 logging filter nsvc (nseil nsvci) <0-65535> . . . . .	51
1.5.4 logging level (csn1 l1if rlcmac rlcmacdata rlcmacd rlcmacu rlcmacsched rlcmacm... . . . . .	51
1.5.5 logging level force-all (debug info notice error fatal) . . . . .	53
1.5.6 logging level set-all (debug info notice error fatal) . . . . .	54
1.5.7 logging print category (0 1) . . . . .	55
1.5.8 logging print category-hex (0 1) . . . . .	55
1.5.9 logging print extended-timestamp (0 1) . . . . .	56
1.5.10 logging print file (0 1 basename) [last] . . . . .	56
1.5.11 logging print level (0 1) . . . . .	57
1.5.12 logging timestamp (0 1) . . . . .	57
1.5.13 no logging level force-all . . . . .	57
1.6 config-stats . . . . .	58
1.6.1 disable . . . . .	58
1.6.2 enable . . . . .	58
1.6.3 level (global peer subscriber) . . . . .	58

1.6.4	local-ip ADDR . . . . .	59
1.6.5	mtu <100-65535> . . . . .	59
1.6.6	no local-ip . . . . .	59
1.6.7	no mtu . . . . .	59
1.6.8	no prefix . . . . .	60
1.6.9	prefix PREFIX . . . . .	60
1.6.10	remote-ip ADDR . . . . .	60
1.6.11	remote-port <1-65535> . . . . .	60
1.7	config-line . . . . .	61
1.7.1	bind A.B.C.D [<0-65535>] . . . . .	61
1.7.2	login . . . . .	61
1.7.3	no login . . . . .	61
1.8	config-ns . . . . .	62
1.8.1	encapsulation framerelay-gre enabled (1 0) . . . . .	62
1.8.2	encapsulation framerelay-gre local-ip A.B.C.D . . . . .	62
1.8.3	encapsulation udp dscp <0-255> . . . . .	63
1.8.4	encapsulation udp local-ip A.B.C.D . . . . .	63
1.8.5	encapsulation udp local-port <0-65535> . . . . .	63
1.8.6	no nse <0-65535> . . . . .	64
1.8.7	nse <0-65535> encapsulation (udplframerelay-gre) . . . . .	64
1.8.8	nse <0-65535> fr-dlci <16-1007> . . . . .	65
1.8.9	nse <0-65535> nsvci <0-65534> . . . . .	65
1.8.10	nse <0-65535> remote-ip A.B.C.D . . . . .	65
1.8.11	nse <0-65535> remote-port <0-65535> . . . . .	66
1.8.12	nse <0-65535> remote-role (sgsn bss) . . . . .	66
1.8.13	timer (tns-block tns-block-retries tns-reset tns-reset-retries tns-test tns-aliv... . . . . .	67
1.9	config-pcu . . . . .	67
1.9.1	alloc-algorithm (alb dynamic) . . . . .	67
1.9.2	alpha <0-10> . . . . .	68
1.9.3	cs <1-4> [<1-4>] . . . . .	68
1.9.4	cs downgrade-threshold <1-10000> . . . . .	68
1.9.5	cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35> . . . . .	69
1.9.6	cs max <1-4> [<1-4>] . . . . .	69
1.9.7	cs threshold <0-100> <0-100> . . . . .	70
1.9.8	dl-tbf-idle-time <1-5000> . . . . .	70
1.9.9	egprs dl arq-type (spblarq2) . . . . .	71
1.9.10	egprs only . . . . .	71
1.9.11	flow-control bucket-time <1-65534> . . . . .	71
1.9.12	flow-control force-bvc-bucket-size <1-6553500> . . . . .	72

1.9.13 flow-control force-bvc-leak-rate <1-6553500>	72
1.9.14 flow-control force-ms-bucket-size <1-6553500>	72
1.9.15 flow-control force-ms-leak-rate <1-6553500>	73
1.9.16 flow-control-interval <1-10>	73
1.9.17 gamma <0-62>	73
1.9.18 gb-dialect (classiclip-sns)	74
1.9.19 gsmtap-category (dl-unknown dl-dummy dl-ctrl dl-data-gprs dl-data-egprs dl-ptcch...)	74
1.9.20 mcs <1-9> [<1-9>]	75
1.9.21 mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <...>	75
1.9.22 mcs max <1-9> [<1-9>]	77
1.9.23 ms-idle-time <1-7200>	77
1.9.24 no cs	77
1.9.25 no cs downgrade-threshold	78
1.9.26 no cs max	78
1.9.27 no cs threshold	78
1.9.28 no dl-tbf-idle-time	79
1.9.29 no egprs	79
1.9.30 no flow-control bucket-time	79
1.9.31 no flow-control force-bvc-bucket-size	80
1.9.32 no flow-control force-bvc-leak-rate	80
1.9.33 no flow-control force-ms-bucket-size	80
1.9.34 no flow-control force-ms-leak-rate	81
1.9.35 no gsmtap-category (dl-unknown dl-dummy dl-ctrl dl-data-gprs dl-data-egprs dl-ptcch...)	81
1.9.36 no mcs	82
1.9.37 no mcs max	82
1.9.38 no ms-idle-time	82
1.9.39 no queue codel	83
1.9.40 no queue hysteresis	83
1.9.41 no queue idle-ack-delay	83
1.9.42 no queue lifetime	84
1.9.43 no two-phase-access	84
1.9.44 pcu-socket PATH	84
1.9.45 queue codel	85
1.9.46 queue codel interval <1-1000>	85
1.9.47 queue hysteresis <1-65535>	85
1.9.48 queue idle-ack-delay <1-65535>	86
1.9.49 queue lifetime <1-65534>	86
1.9.50 queue lifetime infinite	86
1.9.51 two-phase-access	87
1.9.52 window-size <0-1024> [<0-256>]	87

# List of Tables

1.1	VTY Parameter Patterns	1
1.2	VTY port numbers	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

### 1.1.4 list

Command

```
list
```

Parameters

list

Print command list

### 1.1.5 show running-config

Command

```
show running-config
```

Parameters

show

    Show running system information

running-config

    running configuration

### 1.1.6 write

Command

```
write
```

Parameters

write

    Write running configuration to memory, network, or terminal

### 1.1.7 write file

Command

```
write file
```

Parameters

write

    Write running configuration to memory, network, or terminal

file

    Write to configuration file

### 1.1.8 write memory

Command

```
write memory
```

Parameters

write

    Write running configuration to memory, network, or terminal

memory

    Write configuration to the file (same as write file)

### 1.1.9 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable

Command

```
enable
```

Parameters

enable

Turn on privileged mode command

### 1.2.2 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.3 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

## 1.2.6 logging filter nservc (nsei|nsvci) <0-65535>

Command

```
logging filter nservc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nservc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

## 1.2.7 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacm...

Command

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacmeas|tbf ←
    |tbfndl|tbfndl|ns|bssgp|pcu|lgloba|l1apd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ←
    lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ←
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

csn1

Concrete Syntax Notation One (CSN1)

l1if

GPRS PCU L1 interface (L1IF)

rlcmac

GPRS RLC/MAC layer (RLCMAC)

rlcmacdata

GPRS RLC/MAC layer Data (RLCMAC)

---

rlcmacdl	GPRS RLC/MAC layer Downlink (RLCMAC)
rlcmacul	GPRS RLC/MAC layer Uplink (RLCMAC)
rlcmacsched	GPRS RLC/MAC layer Scheduling (RLCMAC)
rlcmacmeas	GPRS RLC/MAC layer Measurements (RLCMAC)
tbf	Temporary Block Flow (TBF)
tbfdl	Temporary Block Flow (TBF) Downlink
tbfu	Temporary Block Flow (TBF) Uplink
ns	GPRS Network Service Protocol (NS)
bssgp	GPRS BSS Gateway Protocol (BSSGP)
pcu	GPRS Packet Control Unit (PCU)
lglobal	Library-internal global log family
llapd	LAPD in libosmogsm
linp	A-bis Input Subsystem
lmux	A-bis B-Subchannel TRAU Frame Multiplex
lmi	A-bis Input Driver for Signalling
lmib	A-bis Input Driver for B-Channels (voice)
lsms	Layer3 Short Message Service (SMS)
lctrl	Control Interface
lgtp	GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljbuf

libosmo-netif Jitter Buffer

lrspc

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.8 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.9 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.10 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.11 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.12 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.13 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.14 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.15 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.16 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.17 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.18 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.19 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

    Show running system information

asciidoc

    Asciidoc generation

counters

    Generate table of all registered counters

### 1.2.20 show bts statistics

Command

```
show bts statistics
```

Parameters

show

    Show running system information

bts

    BTS related functionality

statistics

    Statistics

### 1.2.21 show history

Command

```
show history
```

Parameters

show

    Show running system information

history

    Display the session command history

### 1.2.22 show logging vty

Command

```
show logging vty
```

Parameters

show

    Show running system information

logging

    Show current logging configuration

vty

    Show current logging configuration for this vty

### 1.2.23 show ms all

Command

```
show ms all
```

Parameters

show

    Show running system information

ms

    information about MSs

all

    All TBFs

### 1.2.24 show ms imsi IMSI

Command

```
show ms imsi IMSI
```

Parameters

show

    Show running system information

ms

    information about MSs

imsi

    Select MS by IMSI

IMSI

    IMSI

### 1.2.25 show ms tlli TLLI

Command

```
show ms tlli TLLI
```

Parameters

show

    Show running system information

ms

    information about MSS

tlli

    Select MS by TLLI

TLLI

    TLLI as hex

### 1.2.26 show ns

Command

```
show ns
```

Parameters

show

    Show running system information

ns

    Display information about the NS protocol

### 1.2.27 show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

    Show running system information

ns

    Display information about the NS protocol

nsei

    Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.2.28 show ns persistent

Command

```
show ns persistent
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

### 1.2.29 show ns stats

Command

```
show ns stats
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

stats

Include statistics

### 1.2.30 show online-help

Command

```
show online-help
```

Parameters

show

Show running system information

online-help

Online help

### 1.2.31 show rate-counters

Command

```
show rate-counters
```

Parameters

show

    Show running system information

rate-counters

    Show all rate counters

### 1.2.32 show stats

Command

```
show stats
```

Parameters

show

    Show running system information

stats

    Show statistical values

### 1.2.33 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

    Show running system information

stats

    Show statistical values

level

    Set the maximum group level

global

    Show global groups only

peer

    Show global and network peer related groups

subscriber

    Show global, peer, and subscriber groups

### 1.2.34 show tbf (all|ccch|pacch)

Command

```
show tbf (all|ccch|pacch)
```

Parameters

show

    Show running system information

tbf

    information about TBFs

all

    All TBFs

ccch

    TBFs allocated via CCCH

pacch

    TBFs allocated via PACCH

### 1.2.35 show version

Command

```
show version
```

Parameters

show

    Show running system information

version

    Displays program version

### 1.2.36 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

    Set terminal line parameters

length

    Set number of lines on a screen

<0-512>

    Number of lines on screen (0 for no pausing)

### 1.2.37 terminal no length

Command

```
terminal no length
```

Parameters

terminal

    Set terminal line parameters

no

    Negate a command or set its defaults

length

    Set number of lines on a screen

### 1.2.38 who

Command

```
who
```

Parameters

who

    Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 configure terminal

Command

```
configure terminal
```

Parameters

configure

    Configuration from vty interface

terminal

    Configuration terminal

### 1.3.2 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

    Copy configuration

running-config

    Copy running config to...

startup-config

    Copy running config to startup config (same as write file)

### 1.3.3 disable

Command

```
disable
```

Parameters

disable

    Turn off privileged mode command

### 1.3.4 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

    Configure logging

color

    Configure color-printing for log messages

0

    Don't use color for printing messages

1

    Use color for printing messages

### 1.3.5 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

### 1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

### 1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.3.8 logging filter nservc (nsei|nsvci) <0-65535>

Command

```
logging filter nservc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nservc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

### 1.3.9 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacm...

Command

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacmeas|tbf ←
    |tbfndl|tbfndl|ns|bssgp|pcu|lgloba|l1apd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ←
    lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljbuf|lrspro) (debug|info|notice|error| ←
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

csn1

Concrete Syntax Notation One (CSN1)

l1if

GPRS PCU L1 interface (L1IF)

rlcmac

GPRS RLC/MAC layer (RLCMAC)

rlcmacdata

GPRS RLC/MAC layer Data (RLCMAC)

---

rlcmacdl	GPRS RLC/MAC layer Downlink (RLCMAC)
rlcmacul	GPRS RLC/MAC layer Uplink (RLCMAC)
rlcmacsched	GPRS RLC/MAC layer Scheduling (RLCMAC)
rlcmacmeas	GPRS RLC/MAC layer Measurements (RLCMAC)
tbf	Temporary Block Flow (TBF)
tbfdl	Temporary Block Flow (TBF) Downlink
tbfu	Temporary Block Flow (TBF) Uplink
ns	GPRS Network Service Protocol (NS)
bssgp	GPRS BSS Gateway Protocol (BSSGP)
pcu	GPRS Packet Control Unit (PCU)
lglobal	Library-internal global log family
llapd	LAPD in libosmogsm
linp	A-bis Input Subsystem
lmux	A-bis B-Subchannel TRAU Frame Multiplex
lmi	A-bis Input Driver for Signalling
lmib	A-bis Input Driver for B-Channels (voice)
lsms	Layer3 Short Message Service (SMS)
lctrl	Control Interface
lgtp	GPRS GTP library

lstats  
    Statistics messages and logging

lgsup  
    Generic Subscriber Update Protocol

loap  
    Osmocom Authentication Protocol

lss7  
    libosmo-sigtran Signalling System 7

lsccp  
    libosmo-sigtran SCCP Implementation

lsua  
    libosmo-sigtran SCCP User Adaptation

lm3ua  
    libosmo-sigtran MTP3 User Adaptation

lmgcp  
    libosmo-mgcp Media Gateway Control Protocol

ljbuf  
    libosmo-netif Jitter Buffer

lspro  
    Remote SIM protocol

debug  
    Log debug messages and higher levels

info  
    Log informational messages and higher levels

notice  
    Log noticeable messages and higher levels

error  
    Log error messages and higher levels

fatal  
    Log only fatal messages

### 1.3.10 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging  
    Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.11 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.12 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.3.13 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.14 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.15 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.16 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.17 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.18 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.3.19 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.20 nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)

Command

```
nsvc (nsei|nsvci) <0-65535> (block|unblock|reset)
```

Parameters

nsvc

Perform an operation on a NSVC

nsei

NSEI to identify NS-VC Identifier (NS-VCI)

nsvci

NS-VC Identifier (NS-VCI)

<0-65535>

The NSEI

block  
    Initiate BLOCK procedure  
unblock  
    Initiate UNBLOCK procedure  
reset  
    Initiate RESET procedure

### 1.3.21 show alarms

Command

```
show alarms
```

Parameters

show  
    Show running system information  
alarms  
    Show current logging configuration

### 1.3.22 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show  
    Show running system information  
asciidoc  
    Asciidoc generation  
counters  
    Generate table of all registered counters

### 1.3.23 show bts statistics

Command

```
show bts statistics
```

Parameters

show  
    Show running system information  
bts  
    BTS related functionality  
statistics  
    Statistics

### 1.3.24 show history

Command

```
show history
```

Parameters

show

    Show running system information

history

    Display the session command history

### 1.3.25 show logging vty

Command

```
show logging vty
```

Parameters

show

    Show running system information

logging

    Show current logging configuration

vty

    Show current logging configuration for this vty

### 1.3.26 show ms all

Command

```
show ms all
```

Parameters

show

    Show running system information

ms

    information about MSs

all

    All TBFs

### 1.3.27 show ms imsi IMSI

Command

```
show ms imsi IMSI
```

Parameters

show

    Show running system information

ms

    information about MSs

imsi

    Select MS by IMSI

IMSI

    IMSI

### 1.3.28 show ms tlli TLLI

Command

```
show ms tlli TLLI
```

Parameters

show

    Show running system information

ms

    information about MSs

tlli

    Select MS by TLLI

TLLI

    TLLI as hex

### 1.3.29 show ns

Command

```
show ns
```

Parameters

show

    Show running system information

ns

    Display information about the NS protocol

### 1.3.30 show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

    Show running system information

ns

    Display information about the NS protocol

nsei

    Select one NSE by its NSE Identifier

nsvc

    Select one NSE by its NS-VC Identifier

<0-65535>

    The Identifier of selected type

[stats]

    Include Statistics

### 1.3.31 show ns persistent

Command

```
show ns persistent
```

Parameters

show

    Show running system information

ns

    Display information about the NS protocol

persistent

    Show only persistent NS

### 1.3.32 show ns stats

Command

```
show ns stats
```

Parameters

show  
    Show running system information

ns  
    Display information about the NS protocol  
stats  
    Include statistics

### 1.3.33 show online-help

Command

```
show online-help
```

Parameters

show  
    Show running system information  
online-help  
    Online help

### 1.3.34 show rate-counters

Command

```
show rate-counters
```

Parameters

show  
    Show running system information  
rate-counters  
    Show all rate counters

### 1.3.35 show startup-config

Command

```
show startup-config
```

Parameters

show  
    Show running system information  
startup-config  
    Contentes of startup configuration

### 1.3.36 show stats

Command

```
show stats
```

Parameters

show

    Show running system information

stats

    Show statistical values

### 1.3.37 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

    Show running system information

stats

    Show statistical values

level

    Set the maximum group level

global

    Show global groups only

peer

    Show global and network peer related groups

subscriber

    Show global, peer, and subscriber groups

### 1.3.38 show tbf (all|ccch|pacch)

Command

```
show tbf (all|ccch|pacch)
```

Parameters

show

    Show running system information

tbf  
information about TBFs

all  
All TBFs

ccch  
TBFs allocated via CCCH

pacch  
TBFs allocated via PACCH

### 1.3.39 show version

Command

```
show version
```

Parameters

show  
Show running system information  
version  
Displays program version

### 1.3.40 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal  
Set terminal line parameters  
length  
Set number of lines on a screen  
<0-512>  
Number of lines on screen (0 for no pausing)

### 1.3.41 terminal monitor

Command

```
terminal monitor
```

Parameters

terminal  
Set terminal line parameters  
monitor  
Copy debug output to the current terminal line

### 1.3.42 terminal no length

Command

```
terminal no length
```

Parameters

terminal

    Set terminal line parameters

no

    Negate a command or set its defaults

length

    Set number of lines on a screen

### 1.3.43 terminal no monitor

Command

```
terminal no monitor
```

Parameters

terminal

    Set terminal line parameters

no

    Negate a command or set its defaults

monitor

    Copy debug output to the current terminal line

### 1.3.44 who

Command

```
who
```

Parameters

who

    Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

Command

```
banner motd default
```

Parameters

banner

    Set banner string

motd

    Strings for motd

default

    Default string

### 1.4.2 banner motd file [FILE]

Command

```
banner motd file [FILE]
```

Parameters

banner

    Set banner

motd

    Banner for motd

file

    Banner from a file

[FILE]

    Filename

### 1.4.3 enable password (8|) WORD

Command

```
enable password (8 |) WORD
```

Parameters

enable

    Modify enable password parameters

password

    Assign the privileged level password

8

    Specifies a HIDDEN password will follow

dummy string

WORD

    The HIDDEN 'enable' password string

#### 1.4.4 enable password LINE

Command

```
enable password LINE
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

LINE

The UNENCRYPTED (cleartext) 'enable' password

#### 1.4.5 hostname WORD

Command

```
hostname WORD
```

Parameters

hostname

Set system's network name

WORD

This system's network name

#### 1.4.6 line vty

Command

```
line vty
```

Parameters

line

Configure a terminal line

vty

Virtual terminal

### 1.4.7 log alarms <2-32700>

Command

```
log alarms <2-32700>
```

Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strb

<2-32700>

Maximum number of messages to log

### 1.4.8 log file .FILENAME

Command

```
log file .FILENAME
```

Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.9 log gsmtap [HOSTNAME]

Command

```
log gsmtap [HOSTNAME]
```

Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.10 log stderr

Command

```
log stderr
```

Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.11 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

#### 1.4.12 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

#### 1.4.13 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

#### 1.4.14 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.15 no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.16 no log alarms

Command

```
no log alarms
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.17 no log file .FILENAME

Command

```
no log file .FILENAME
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.18 no log stderr

Command

```
no log stderr
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.19 no log syslog

Command

```
no log syslog
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.20 no service advanced-vty

Command

```
no service advanced-vty
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.21 no service terminal-length [<0-512>]

Command

```
no service terminal-length [<0-512>]
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

### 1.4.22 no stats reporter log

Command

```
no stats reporter log
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.23 no stats reporter statsd

Command

```
no stats reporter statsd
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

#### 1.4.24 ns

Command

```
ns
```

Parameters

ns

Configure the GPRS Network Service

#### 1.4.25 password (8|) WORD

Command

```
password (8 | ) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

#### 1.4.26 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

### 1.4.27 pcu

Command

```
pcu
```

Parameters

pcu

BTS specific configure

### 1.4.28 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.29 service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

### 1.4.30 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

### 1.4.31 stats interval <1-65535>

Command

```
stats interval <1-65535>
```

Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<1-65535>

Interval in seconds

### 1.4.32 stats reporter log

Command

```
stats reporter log
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.33 stats reporter statsd

Command

```
stats reporter statsd
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.5.3 logging filter nservc (nsei|nsvci) <0-65535>

Command

```
logging filter nservc (nsei|nsvci) <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nservc

Filter based on NS Virtual Connection

nsei

Identify NS-VC by NSEI

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

### 1.5.4 logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacm...

Command

```
logging level (csn1|l1if|rlcmac|rlcmacdata|rlcmacd1|rlcmacul|rlcmacsched|rlcmacmeas|tbf ←
    |tbfndl|tbfndl|ns|bssgp|pcu|lgloba|l1apd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ←
    lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljbuf|lrspro) (debug|info|notice|error| ←
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

csn1

Concrete Syntax Notation One (CSN1)

l1if

GPRS PCU L1 interface (L1IF)

rlcmac

GPRS RLC/MAC layer (RLCMAC)

rlcmacdata

GPRS RLC/MAC layer Data (RLCMAC)

---

rlcmacdl	GPRS RLC/MAC layer Downlink (RLCMAC)
rlcmacul	GPRS RLC/MAC layer Uplink (RLCMAC)
rlcmacsched	GPRS RLC/MAC layer Scheduling (RLCMAC)
rlcmacmeas	GPRS RLC/MAC layer Measurements (RLCMAC)
tbf	Temporary Block Flow (TBF)
tbfdl	Temporary Block Flow (TBF) Downlink
tbfu	Temporary Block Flow (TBF) Uplink
ns	GPRS Network Service Protocol (NS)
bssgp	GPRS BSS Gateway Protocol (BSSGP)
pcu	GPRS Packet Control Unit (PCU)
lglobal	Library-internal global log family
llapd	LAPD in libosmogsm
linp	A-bis Input Subsystem
lmux	A-bis B-Subchannel TRAU Frame Multiplex
lmi	A-bis Input Driver for Signalling
lmib	A-bis Input Driver for B-Channels (voice)
lsms	Layer3 Short Message Service (SMS)
lctrl	Control Interface
lgtp	GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljbuf

libosmo-netif Jitter Buffer

lrspc

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.5 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.6 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.7 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.8 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.9 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.10 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.11 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.12 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.13 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no  
    Negate a command or set its defaults

logging  
    Configure logging

level  
    Set the log level for a specified category

force-all  
    Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

Command

```
disable
```

Parameters

disable  
    Disable the reporter

### 1.6.2 enable

Command

```
enable
```

Parameters

enable  
    Enable the reporter

### 1.6.3 level (global|peer|subscriber)

Command

```
level (global|peer|subscriber)
```

Parameters

level  
    Set the maximum group level

global  
    Report global groups only

peer  
    Report global and network peer related groups

subscriber  
    Report global, peer, and subscriber groups

#### 1.6.4 local-ip ADDR

Command

```
local-ip ADDR
```

Parameters

local-ip

Set the IP address to which we bind locally

ADDR

IP Address

#### 1.6.5 mtu <100-65535>

Command

```
mtu <100-65535>
```

Parameters

mtu

Set the maximum packet size

<100-65535>

Size in byte

#### 1.6.6 no local-ip

Command

```
no local-ip
```

Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

#### 1.6.7 no mtu

Command

```
no mtu
```

Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

### 1.6.8 no prefix

Command

```
no prefix
```

Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.9 prefix PREFIX

Command

```
prefix PREFIX
```

Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.10 remote-ip ADDR

Command

```
remote-ip ADDR
```

Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.11 remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

Command

```
bind A.B.C.D [<0-65535>]
```

Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

### 1.7.2 login

Command

```
login
```

Parameters

login

Enable password checking

### 1.7.3 no login

Command

```
no login
```

Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-ns

### 1.8.1 encapsulation framerelay-gre enabled (1|0)

Command

```
encapsulation framerelay-gre enabled (1|0)
```

Parameters

encapsulation

    NS encapsulation options

framerelay-gre

    NS over Frame Relay over GRE Encapsulation

enabled

    Enable or disable Frame Relay over GRE

1

    Enable

0

    Disable

### 1.8.2 encapsulation framerelay-gre local-ip A.B.C.D

Command

```
encapsulation framerelay-gre local-ip A.B.C.D
```

Parameters

encapsulation

    NS encapsulation options

framerelay-gre

    NS over Frame Relay over GRE Encapsulation

local-ip

    Set the IP address on which we listen for NS/FR/GRE

A.B.C.D

    IP Address

### 1.8.3 encapsulation udp dscp <0-255>

Command

```
encapsulation udp dscp <0-255>
```

Parameters

encapsulation

    NS encapsulation options

udp

    NS over UDP Encapsulation

dscp

    Set DSCP/TOS on the UDP socket

<0-255>

    DSCP Value

### 1.8.4 encapsulation udp local-ip A.B.C.D

Command

```
encapsulation udp local-ip A.B.C.D
```

Parameters

encapsulation

    NS encapsulation options

udp

    NS over UDP Encapsulation

local-ip

    Set the IP address on which we listen for NS/UDP

A.B.C.D

    IP Address

### 1.8.5 encapsulation udp local-port <0-65535>

Command

```
encapsulation udp local-port <0-65535>
```

Parameters

encapsulation

    NS encapsulation options

udp

NS over UDP Encapsulation

local-port

Set the UDP port on which we listen for NS/UDP

<0-65535>

UDP port number

### 1.8.6 no nse <0-65535>

Command

```
no nse <0-65535>
```

Parameters

no

Delete Persistent NS Entity

nse

Delete Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

### 1.8.7 nse <0-65535> encapsulation (udp|framerelay-gre)

Command

```
nse <0-65535> encapsulation (udp|framerelay-gre)
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

encapsulation

Encapsulation for NS

udp

UDP/IP Encapsulation

framerelay-gre

Frame-Relay/GRE/IP Encapsulation

### 1.8.8 nse <0-65535> fr-dlci <16-1007>

Command

```
nse <0-65535> fr-dlci <16-1007>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

fr-dlci

Frame Relay DLCI

<16-1007>

Frame Relay DLCI Number

### 1.8.9 nse <0-65535> nsvci <0-65534>

Command

```
nse <0-65535> nsvci <0-65534>
```

Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

nsvci

NS Virtual Connection

<0-65534>

NS Virtual Connection ID (NSVCI)

### 1.8.10 nse <0-65535> remote-ip A.B.C.D

Command

```
nse <0-65535> remote-ip A.B.C.D
```

Parameters

nse

Persistent NS Entity

```
<0-65535>
    NS Entity ID (NSEI)

remote-ip
    Remote IP Address

A.B.C.D
    Remote IP Address
```

### 1.8.11 nse <0-65535> remote-port <0-65535>

Command

```
nse <0-65535> remote-port <0-65535>
```

Parameters

```
nse
    Persistent NS Entity

<0-65535>
    NS Entity ID (NSEI)

remote-port
    Remote UDP Port

<0-65535>
    Remote UDP Port Number
```

### 1.8.12 nse <0-65535> remote-role (sgsn|bss)

Command

```
nse <0-65535> remote-role (sgsn|bss)
```

Parameters

```
nse
    Persistent NS Entity

<0-65535>
    NS Entity ID (NSEI)

remote-role
    Remote NSE Role

sgsn
    Remote Peer is SGSN

bss
    Remote Peer is BSS
```

### 1.8.13 timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-aliv...

Command

```
timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-alive|tns- ↵
      alive-retries|tsns-prov) <0-65535>
```

Parameters

timer

Network Service Timer

tns-block

(un)blocking Timer (Tns-block) timeout

tns-block-retries

(un)blocking Timer (Tns-block) number of retries

tns-reset

Reset Timer (Tns-reset) timeout

tns-reset-retries

Reset Timer (Tns-reset) number of retries

tns-test

Test Timer (Tns-test) timeout

tns-alive

Alive Timer (Tns-alive) timeout

tns-alive-retries

Alive Timer (Tns-alive) number of retries

tsns-prov

SNS Provision Timer (Tsns-prov) timeout

<0-65535>

Timer Value

## 1.9 config-pcu

### 1.9.1 alloc-algorithm (a|b|dynamic)

Command

```
alloc-algorithm (a|b|dynamic)
```

Parameters

alloc-algorithm

Select slot allocation algorithm to use when assigning timeslots on PACCH

- a Single slot is assigned only
  - b Multiple slots are assigned for semi-duplex operation
- dynamic
- Dynamically select the algorithm based on the system state

### 1.9.2 alpha <0-10>

Command

```
alpha <0-10>
```

Parameters

alpha

Alpha parameter for MS power control in units of 0.1 (see TS 05.08) NOTE: Be sure to set Alpha value at System information 13 too.

<0-10>

Alpha in units of 0.1

### 1.9.3 cs <1-4> [<1-4>]

Command

```
cs <1-4> [<1-4>]
```

Parameters

cs

Coding Scheme configuration

<1-4>

Initial CS value to be used (overrides BTS config)

[<1-4>]

Use a different initial CS value for the uplink

### 1.9.4 cs downgrade-threshold <1-10000>

Command

```
cs downgrade-threshold <1-10000>
```

Parameters

cs

Coding Scheme configuration

downgrade-threshold

set threshold for data size based CS downgrade

<1-10000>

downgrade if less octets left

### 1.9.5 cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35>

Command

```
cs link-quality-ranges cs1 <0-35> cs2 <0-35> <0-35> cs3 <0-35> <0-35> cs4 <0-35>
```

Parameters

cs

Coding Scheme configuration

link-quality-ranges

Set link quality ranges

cs1

Set quality range for CS-1 (high value only)

<0-35>

CS-1 high (dB)

cs2

Set quality range for CS-2

<0-35>

CS-2 low (dB)

<0-35>

CS-2 high (dB)

cs3

Set quality range for CS-3

<0-35>

CS-3 low (dB)

<0-35>

CS-3 high (dB)

cs4

Set quality range for CS-4 (low value only)

<0-35>

CS-4 low (dB)

### 1.9.6 cs max <1-4> [<1-4>]

Command

```
cs max <1-4> [<1-4>]
```

Parameters

cs

Coding Scheme configuration

max

Set maximum values for adaptive CS selection (overrides BTS config)

<1-4>

Maximum CS value to be used

[<1-4>]

Use a different maximum CS value for the uplink

### 1.9.7 cs threshold <0-100> <0-100>

Command

```
cs threshold <0-100> <0-100>
```

Parameters

cs

Coding Scheme configuration

threshold

set thresholds for error rate based CS adjustment

<0-100>

lower limit in %

<0-100>

upper limit in %

### 1.9.8 dl-tbf-idle-time <1-5000>

Command

```
dl-tbf-idle-time <1-5000>
```

Parameters

dl-tbf-idle-time

keep an idle DL TBF alive for the time given

<1-5000>

idle time in msec

### 1.9.9 egprs dl arq-type (spb|arq2)

Command

```
egprs dl arq-type (spb|arq2)
```

Parameters

egprs

    EGPRS configuration

dl

    downlink specific configuration

arq-type

    ARQ options

spb

    enable SPB(ARQ1) support

arq2

    enable ARQ2 support

### 1.9.10 egprs only

Command

```
egprs only
```

Parameters

egprs

    EGPRS configuration

only

    Use EGPRS and disable plain GPRS

### 1.9.11 flow-control bucket-time <1-65534>

Command

```
flow-control bucket-time <1-65534>
```

Parameters

flow-control

    BSSGP Flow Control configuration

bucket-time

    Set target downlink maximum queueing time (only affects the advertised bucket size)

<1-65534>

    Time in centi-seconds

### 1.9.12 flow-control force-bvc-bucket-size <1-6553500>

Command

```
flow-control force-bvc-bucket-size <1-6553500>
```

Parameters

flow-control

BSSGP Flow Control configuration

force-bvc-bucket-size

Force a fixed value for the BVC bucket size

<1-6553500>

Bucket size in octets

### 1.9.13 flow-control force-bvc-leak-rate <1-6553500>

Command

```
flow-control force-bvc-leak-rate <1-6553500>
```

Parameters

flow-control

BSSGP Flow Control configuration

force-bvc-leak-rate

Force a fixed value for the BVC leak rate

<1-6553500>

Leak rate in bit/s

### 1.9.14 flow-control force-ms-bucket-size <1-6553500>

Command

```
flow-control force-ms-bucket-size <1-6553500>
```

Parameters

flow-control

BSSGP Flow Control configuration

force-ms-bucket-size

Force a fixed value for the default MS bucket size

<1-6553500>

Bucket size in octets

### 1.9.15 flow-control force-ms-leak-rate <1-6553500>

Command

```
flow-control force-ms-leak-rate <1-6553500>
```

Parameters

flow-control

BSSGP Flow Control configuration

force-ms-leak-rate

Force a fixed value for the default MS leak rate

<1-6553500>

Leak rate in bit/s

### 1.9.16 flow-control-interval <1-10>

Command

```
flow-control-interval <1-10>
```

Parameters

flow-control-interval

Interval between sending subsequent Flow Control PDUs

<1-10>

Interval time in seconds

### 1.9.17 gamma <0-62>

Command

```
gamma <0-62>
```

Parameters

gamma

Gamma parameter for MS power control in units of dB (see TS 05.08)

<0-62>

Gamma in even unit of dBs

### 1.9.18 gb-dialect (classic|ip-sns)

Command

```
gb-dialect (classic|ip-sns)
```

Parameters

gb-dialect

Select which Gb interface dialect to use

classic

Classic Gb interface with NS-{RESET,BLOCK,UNBLOCK} and static configuration

ip-sns

Modern Gb interface with IP-SNS (Sub Network Service) and dynamic configuration

### 1.9.19 gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch...)

Command

```
gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch|ul-  
unknown|ul-dummy|ul-ctrl|ul-data-gprs|ul-data-egprs)
```

Parameters

gsmtap-category

GSMTAP Category

dl-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

dl-dummy

Downlink Dummy Blocks

dl-ctrl

Downlink Control Blocks

dl-data-gprs

Downlink Data Blocks (GPRS)

dl-data-egprs

Downlink Data Blocks (EGPRS)

dl-ptcch

Downlink PTCCH Blocks

ul-unknown

Unknown / Unparseable / Erroneous Uplink Blocks

ul-dummy

Uplink Dummy Blocks

ul-ctrl  
    Uplink Control Blocks  
ul-data-gprs  
    Uplink Data Blocks (GPRS)  
ul-data-egprs  
    Uplink Data Blocks (EGPRS)

### 1.9.20 mcs <1-9> [<1-9>]

Command

```
mcs <1-9> [<1-9>]
```

Parameters

mcs  
    Modulation and Coding Scheme configuration (EGPRS)  
<1-9>  
    Initial MCS value to be used (default 1)  
[<1-9>]  
    Use a different initial MCS value for the uplink

### 1.9.21 mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <...>

Command

```
mcs link-quality-ranges mcs1 <0-35> mcs2 <0-35> <0-35> mcs3 <0-35> <0-35> mcs4 <0-35> ↵
    <0-35> mcs5 <0-35> <0-35> mcs6 <0-35> <0-35> mcs7 <0-35> <0-35> mcs8 <0-35> <0-35> ↵
    mcs9 <0-35>
```

Parameters

mcs  
    Coding Scheme configuration  
link-quality-ranges  
    Set link quality ranges  
mcs1  
    Set quality range for MCS-1 (high value only)  
<0-35>  
    MCS-1 high (dB)  
mcs2  
    Set quality range for MCS-2  
<0-35>  
    MCS-2 high (dB)

<0-35>

MCS-2 low (dB)

mcs3

Set quality range for MCS-3

<0-35>

MCS-3 high (dB)

<0-35>

MCS-3 low (dB)

mcs4

Set quality range for MCS-4

<0-35>

MCS-4 high (dB)

<0-35>

MCS-4 low (dB)

mcs5

Set quality range for MCS-5

<0-35>

MCS-5 high (dB)

<0-35>

MCS-5 low (dB)

mcs6

Set quality range for MCS-6

<0-35>

MCS-6 low (dB)

<0-35>

MCS-6 high (dB)

mcs7

Set quality range for MCS-7

<0-35>

MCS-7 low (dB)

<0-35>

MCS-7 high (dB)

mcs8

Set quality range for MCS-8

<0-35>

MCS-8 low (dB)

<0-35>

MCS-8 high (dB)

---

mcs9

Set quality range for MCS-9 (low value only)

<0-35>

MCS-9 low (dB)

### 1.9.22 mcs max <1-9> [<1-9>]

Command

```
mcs max <1-9> [<1-9>]
```

Parameters

mcs

Modulation and Coding Scheme configuration (EGPRS)

max

Set maximum values for adaptive CS selection (overrides BTS config)

<1-9>

Maximum MCS value to be used

[<1-9>]

Use a different maximum MCS value for the uplink

### 1.9.23 ms-idle-time <1-7200>

Command

```
ms-idle-time <1-7200>
```

Parameters

ms-idle-time

keep an idle MS object alive for the time given

<1-7200>

idle time in sec

### 1.9.24 no cs

Command

```
no cs
```

Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

### 1.9.25 no cs downgrade-threshold

Command

```
no cs downgrade-threshold
```

Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

downgrade-threshold

set threshold for data size based CS downgrade

### 1.9.26 no cs max

Command

```
no cs max
```

Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

max

Set maximum values for adaptive CS selection (overrides BTS config)

### 1.9.27 no cs threshold

Command

```
no cs threshold
```

Parameters

no

Negate a command or set its defaults

cs

Coding Scheme configuration

threshold

set thresholds for error rate based CS adjustment

### 1.9.28 no dl-tbf-idle-time

Command

```
no dl-tbf-idle-time
```

Parameters

no

Negate a command or set its defaults

dl-tbf-idle-time

keep an idle DL TBF alive for the time given

### 1.9.29 no egprs

Command

```
no egprs
```

Parameters

no

Negate a command or set its defaults

egprs

EGPRS configuration

### 1.9.30 no flow-control bucket-time

Command

```
no flow-control bucket-time
```

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

bucket-time

Set target downlink maximum queueing time (only affects the advertised bucket size)

### 1.9.31 no flow-control force-bvc-bucket-size

Command

```
no flow-control force-bvc-bucket-size
```

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-bvc-bucket-size

Force a fixed value for the BVC bucket size

### 1.9.32 no flow-control force-bvc-leak-rate

Command

```
no flow-control force-bvc-leak-rate
```

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-bvc-leak-rate

Force a fixed value for the BVC leak rate

### 1.9.33 no flow-control force-ms-bucket-size

Command

```
no flow-control force-ms-bucket-size
```

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-ms-bucket-size

Force a fixed value for the default MS bucket size

### 1.9.34 no flow-control force-ms-leak-rate

Command

```
no flow-control force-ms-leak-rate
```

Parameters

no

Negate a command or set its defaults

flow-control

BSSGP Flow Control configuration

force-ms-leak-rate

Force a fixed value for the default MS leak rate

### 1.9.35 no gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-pt...

Command

```
no gsmtap-category (dl-unknown|dl-dummy|dl-ctrl|dl-data-gprs|dl-data-egprs|dl-ptcch|ul- ↵
    unknown|ul-dummy|ul-ctrl|ul-data-gprs|ul-data-egprs)
```

Parameters

no

Negate a command or set its defaults

gsmtap-category

GSMTAP Category

dl-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

dl-dummy

Downlink Dummy Blocks

dl-ctrl

Downlink Control Blocks

dl-data-gprs

Downlink Data Blocks (GPRS)

dl-data-egprs

Downlink Data Blocks (EGPRS)

dl-ptcch

Downlink PTCCH Blocks

ul-unknown

Unknown / Unparseable / Erroneous Downlink Blocks

ul-dummy  
    Uplink Dummy Blocks

ul-ctrl  
    Uplink Control Blocks

ul-data-gprs  
    Uplink Data Blocks (GPRS)

ul-data-egprs  
    Uplink Data Blocks (EGPRS)

### 1.9.36 no mcs

Command

```
no mcs
```

Parameters

no  
    Negate a command or set its defaults

mcs  
    Modulation and Coding Scheme configuration (EGPRS)

### 1.9.37 no mcs max

Command

```
no mcs max
```

Parameters

no  
    Negate a command or set its defaults

mcs  
    Modulation and Coding Scheme configuration (EGPRS)

max  
    Set maximum values for adaptive CS selection (overrides BTS config)

### 1.9.38 no ms-idle-time

Command

```
no ms-idle-time
```

Parameters

no  
    Negate a command or set its defaults

ms-idle-time  
    keep an idle MS object alive for the time given

### 1.9.39 no queue codel

Command

```
no queue codel
```

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

codel

Set CoDel queue management

### 1.9.40 no queue hysteresis

Command

```
no queue hysteresis
```

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

hysteresis

Set lifetime hysteresis of LLC frame in centi-seconds (continue discarding until lifetime-hysteresis is reached)

### 1.9.41 no queue idle-ack-delay

Command

```
no queue idle-ack-delay
```

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

idle-ack-delay

Request an ACK after the last DL LLC frame in centi-seconds

### 1.9.42 no queue lifetime

Command

```
no queue lifetime
```

Parameters

no

Negate a command or set its defaults

queue

Packet queue options

lifetime

Disable lifetime limit of LLC frame (use value given by SGSN)

### 1.9.43 no two-phase-access

Command

```
no two-phase-access
```

Parameters

no

Negate a command or set its defaults

two-phase-access

Only use two phase access when requested my MS

### 1.9.44 pcu-socket PATH

Command

```
pcu-socket PATH
```

Parameters

pcu-socket

Configure the osmo-bts PCU socket file/path name

PATH

Path of the socket to connect to

### 1.9.45 queue codel

Command

```
queue codel
```

Parameters

queue

Packet queue options

codel

Set CoDel queue management

### 1.9.46 queue codel interval <1-1000>

Command

```
queue codel interval <1-1000>
```

Parameters

queue

Packet queue options

codel

Set CoDel queue management

interval

Specify interval

<1-1000>

Interval in centi-seconds

### 1.9.47 queue hysteresis <1-65535>

Command

```
queue hysteresis <1-65535>
```

Parameters

queue

Packet queue options

hysteresis

Set lifetime hysteresis of LLC frame in centi-seconds (continue discarding until lifetime-hysteresis is reached)

<1-65535>

Hysteresis in centi-seconds

### 1.9.48 queue idle-ack-delay <1-65535>

Command

```
queue idle-ack-delay <1-65535>
```

Parameters

queue

Packet queue options

idle-ack-delay

Request an ACK after the last DL LLC frame in centi-seconds

<1-65535>

Idle ACK delay in centi-seconds

### 1.9.49 queue lifetime <1-65534>

Command

```
queue lifetime <1-65534>
```

Parameters

queue

Packet queue options

lifetime

Set lifetime limit of LLC frame in centi-seconds (overrides the value given by SGSN)

<1-65534>

Lifetime in centi-seconds

### 1.9.50 queue lifetime infinite

Command

```
queue lifetime infinite
```

Parameters

queue

Packet queue options

lifetime

Set lifetime limit of LLC frame in centi-seconds (overrides the value given by SGSN)

infinite

Infinite lifetime

### 1.9.51 two-phase-access

Command

```
two-phase-access
```

Parameters

two-phase-access

Force two phase access when MS requests single phase access

### 1.9.52 window-size <0-1024> [<0-256>]

Command

```
window-size <0-1024> [<0-256>]
```

Parameters

window-size

Window size configuration (b + N\_PDCH \* f)

<0-1024>

Base value (b)

[<0-256>]

Factor for number of PDCH (f)